## SYMBOLES UTILISES DANS LE TEXTE SYMBOLS USED IN THE TEXT

SYMBOLS	FRENCH	ENGLISH			
> 3523	JUSQUE	UNTIL			
3524 >	DEPUIS	SINCE			
1 POS	PREMIERE POSSIBILITE	FIRST POSSIBILITY			
1E - 2E	PREMIERE - DEUXIEME VITESSE	FIRST - SECOND GEAR			
Α	AMPERE	AMPERE			
ABR	ANTI BLOC ROUE	ABS			
ADM	ADMISSION	INLET			
AH	AMPERE HEURES	AMPERE HOUR			
AR	ARRIERE	REAR			
AV	AVANT	FRONT			
BV	BOITE DE VITESSES	GEARBOX			
BVA	BOITE DE VITESSES AUTOMATIQUE	AUTOMATIC GEARBOX			
С	COUPLE TWO-GEAR SE				
CAD	DIRECTION A DROITE	RHD			
CAG	DIRECTION A GAUCHE	LHD			
CAGE	ECROU CAGE	CAGE NUT			
CAN	CANNELURES	SPLINES			
CC	CAOUTCHOUC	RUBBER			
CENT	CENTRAL	CENTRAL			
CHC	VIS TETE 6 PANS CREUX	SCREW WITH HEXAGON GROOT			
COL	VIS COLONETTE	SHOULDERED SCREW			
D	COTE DROIT	RIGHT HAND SIDE			
DENT	DENTS ou DENTELURES	TOOTH or NOTCHES			
DEO	DEMANDER EN OUTRE	ORDER IN ADDITION			
DIAM	DIAMETRE	DIAMETER			
E	EPAISSEUR	THICKNESS			
ECH	ECHAPPEMENT	EXHAUST,			
ELAS	ELASTIQUE	FLEXIBLE			
ENS	ENSEMBLE	PARTS SET			
EXT	EXTERIEUR	external			
FIL	FIL	WIRE			
G	COTE GAUCHE	LEFT HAND SIDE			

SYMBOLS	FRENCH	ENGLISH		
GW	RONDELLE GROWER	GROWER RING		
Н	HAUTEUR	HEIGHT		
HE	HEXAGONAL	HEXAGONAL		
HEF	ECROU AUTO-FREINE	SELF LOCKING NUT		
HEMB	ECROU A EMBASE	NUT WITH LARGE BASE		
HERI	ECROU A RONDELLE IMPERDABLE	NUT WITH WASHER		
INF	INFERIEUR	LOWER		
INT	INTERIEUR	INTERNAL		
INTM	INTERMEDIAIRE	INTERMEDIATE		
LAR	LARGEUR	WIDTH		
LAT	LATERAL	LATERAL		
LON	LONGUEUR	LENGTH		
M.AR	MARCHE ARRIERE	REVERSE		
NFP	NE FOURNISSONS PLUS	NO LONGER SUPPLIED		
PMH	POINT MORT HAUT	TOP DEAD CENTER		
REP	REPERE	MARKING		
RMP	REMPLACE MODELE PRECEDENT	REPLACES PREVIOUS MODELS		
RP	REMPLACE PAR	SUPERSEDED BY		
SAUF	SAUF	EXCEPT		
SUP	SUPERIEUR	UPPER		
TCB	TETE CYLINDRIQUE BOMBEE	ROUNDED CYLINDRICAL HEAD		
TCF	TETE CYLINDRIQUE FENDUE	SLOTTED CYLINDRICAL HEAD		
TF	TETE FRAISEE	COUNTERSUNK HEAD		
HT	TETE HEXAGONALE	HEXAGONAL HEAD		
THEMB	VIS A EMBASE	SCREW WITH LARGE BASE		
THR	VIS A RONDELLE IMPERDABLE	SCREW WITH WASHER		
TO	JOINT TORIQUE	RING SEAL		
TR	TETE RONDE	ROUND HEAD		
- 11	TOUS TYPES	ALL TYPES		
V	VOLT	VOLT		
VOIES	VOIES	WAYS		
W	WATT	WATT		

EXPRESSIONS COURANTES	COMMON EXPRESSIONS
FRENCH	ENGLISH
AIGU	HIGH
ANTI-BROUILLARD	FOG LIGHT
ASSEMBLE	ASSY
AVEC	WITH
BOITE A GANTS	GLOVE BOX
BOUCHON	PLUG
BRANCHES	BRANCHES
CEINTURES AVEC PRETENSIONNEURS	WITH PRETENSIONING STRAPS
CHROMEE	SILVER PLATED or CHROMIUM PLATED
CLASSE	CLASS
COMPLET	COMPLETE
CONDAMNATION DES PORTES	CENTRAL DOOR LOCKING
CONDUCTEUR	DRIVER
COTE BV	GEARBOX SIDE
COTE CAISSE	BODY SIDE
COTE COMPTEUR	SPEEDOMETER SIDE
COTE DISTRIBUTION	TIMING GEAR SIDE
COTE HABITACLE	INTERIOR SIDE
COTE MOTEUR	ENGINE SIDE
COTE REPARATION	REPAIR SETTING
COTE ROUE	WHEEL SIDE
COTE VOLANT (MOTEUR)	FLYWHEEL SIDE
COUPURE PURGE CANISTER	ABSORBER DRAIN POWER CUT
COURSE	STROKE
COUSSIN	CUSHION DEGRE
DEGRE	
DOSSIER	SQUAB
EMBOUTS	NOZZLES
EMBRAYAGE	CLUTCH
ENS INFRAROUGE	INFRARED SET
ESSUIE VITRE	WINDOW WIPER
FEU DE RECUL	REVERSING LIGHT
FINITION BOIS	WOOD FINISHING
FINIT. TR	19 TRI
FINIT, TZ	16 TZI - 19 TZI
FREIN A MAIN	HANDBRAKE
GRAVE	LOW
HAUT PARLEUR	LOUDSPEAKER
LEVE VITRE ÉLECT.	ELECT, WINDOW LIFTER
LISSE	SMOOTH
MAILLONS	LINKS
NIVEAU	TEAET
NIVEAU D'EAU	WATER LEVEL

FRENCH	ENGLISH			
NIVEAU D'HUILE	Oil LEVEL			
NU	NUDE			
OPTION CUIR	LEATHER OPTION			
OPTION REGULATION DE VITESSE	SPEED REGULATION OPTION			
PALES	BLADES			
PASSAGER	PASSENGER			
A PEINDRE	MUST BE PAINTED			
PRET A PEINDRE	READY TO PAINT			
POULIE	PULLEY			
RAINURE	GROOVE			
REPARATION	REPAIRING			
RESSORT	SPRING			
ROUE ALU,	LIGHT ALLOY WHEEL			
ROUE TOLE	STEEL WHEEL			
ROULEAU	ROLL			
SANS	WITHOUT			
SUR BERCEAU	ON CRADDLE			
SUR BRAS AV	ON FRONT ARM			
SUR CAISSE	ON BODY SHELL			
SPIRES	COILS			
TEINTEE	TINTED			
TEMPERATURE D'EAU	WATER TEMP.			
TEMPERATURE D'HUILE	OIL TEMP.			
TOIT OUVRANT	SUNROOF			
VOLET AR	TAILGATE			
VOYANT DE CHARGE	CHARGE INDICATOR			

BLANC	WHITE
BLEU	BLUE
GRIS	GREY
INCOLORE	COLOURLESS
JAUNE	YELLOW
MARRON	CHESTNUT
MAUVE	MALLOW
NOIR	BLACK
NATUREL	NATURAL
ORANGE	ORANGE
ROUGE	RED
ROSE	PINK
VERT	GREEN
VIOLET	VIOLET

	2010110			
CODES				
CD	BLOND TOBACCO			
DR	SAVANE			
ET	BROWN			
FCD	BLOND TOBACCO			
FLE	SODALITE BLUE (DARK)			
FLG	SODALITE BLUE			
FTL	GREY			
FTR	BITUME GREY			
FWT	MEIJE WHITE			
FXX	BLACK			
FYE	GREY			
FYG	DARK GREY			
JU	RED			
JX	FURIO RED			
LD	SODALITE BLUE			
LE	SODALITE BLUE (DARK)			
LG				
TL	ASPHALTE GREY			
TR	BITUME GREY			
TU	GREY			
TX	GREY + RED			
VE	GREY			
VQ	LIGHT GREY			
VT	GREY			
VU	LIGHT GREY			
W	ASPHALTE GREY + BITUME GREY			
VW	GREY			
WK	WHITE			

CODES	COLOURS
WT	MEIJE WHITE
XA	BLACK + GREY
XF	DARK GREY
XH	BLACK + RED
XL	BLACK + GREY
XX	BLACK
YB	TORNADE GREY
YC	LIGHT GREY
YD	DARK GREY
YE	GREY
YF	LIGHT GREY
YJ	LIGHT GREY
YL	DARK GREY
ZA	BLACK + LIGHT GREY
ZF	CHESTNUT
ZG	LIGHT GREY
ZH	BRUME
ZJ	GREY + BLUE
ZL	OURAGAN GREY
ZN	GREY
ZP	DARK GREY
ZQ	DOLMEN GREY
	·


## **VEHICLE TYPE**


	вх									'90 mode	el year	
MODEL	SILHOUETTE	FINISH	LEVEL	MOTOR	CUBIC CAPACITY	GEARBOX	TYPE	STEERING	TYRES	BRAKES Front	BRAKES Rear	A.B.R.
19 TRI	5 door saloon		4	XU9J1/Z	1905	Automatic	4HP14	Assisted	175/65 R14	Ventilated Disc	Disc	Option
19 TZI	5 door saloon		4	XU9J1/Z	1905	Automatic	4HP14	Assisted	175/65 R14	Ventilated Disc	Disc	Option
GTI	5 door saloon		5	XU9JA/Z	1905	Automatic	4HP14	Assisted	185/60 R14	Ventilated Disc	Disc	Option
16 VALVE	5 door saloon		5	XU9J4/Z	1905	Mechanical	BE3	Assisted	195/60 R14	Ventilated Disc	Disc	Series
19 TRI	5 door estate		4	XU9JA/Z	1905	Automatic	4HP14	Assisted	175/65 R14	Ventilated Disc	Disc	Option
19 TZI	5 door estate		4	XU9JA/Z	1905	Automatic	4HP14	Assisted	175/65 R14	Ventilated Disc	Disc	Option
BX '91 model year												
MODEL	SILHOUETTE	FINISH	LEVEL		CAPACITY	GEARBOX	<u> </u>	STEERING	TYRES	BRAKES Front	BRAKES Rear	A.B.R.
16 TZI	5 door saloon		4	XU5M3/Z			4HP14	Assisted	165/70 R14	Ventilated Disc	Disc	
19 TZI	5 door saloon		4	XU9J1/Z	1905		4HP14	Assisted	175/65 R14	Ventilated Disc	Disc	Option
GTI	5 door saloon		.5	XU9JA/Z	1905		4HP14	Assisted	185/60 R14	Ventilated Disc	Disc	Option
16 VALVE	5 door saloon		5	XU9J4/Z	1905	Mechanical	BE3	Assisted	195/60 R14	Ventilated Disc	Disc	Series
19 TZI	5 door estate		4	XU9JA/Z	1905	Automatic	4HP14	Assisted	175/65 R14	Ventilated Disc	Disc	Option
	вх									'92 mode	l year	
MODEL	SILHOUETTE	FINISH			CUBIC CAPACITY	GEARBOX	TYPE	STEERING	TYRES	BRAKES Front	BRAKES Rear	A.B.R.
16 TZI	5 door saloon		4	XU5M3/Z	1580	Automatic	4HP14	Assisted	165/70 R14	Ventilated Disc	Disc	
19 TZI	5 door saloon		4	XU9J1/Z	1905	Automatic	4HP14	Assisted	175/65 R14	Ventilated Disc	Disc	Option
GTI	5 door saloon		5	XU9JA/Z	1905	Automatic	4HP14	Assisted	185/60 R14	Ventilated Disc	Disc	Option
16 VALVE	5 door saloon		5	XU9J4/Z	1905	Mechanical	BE3	Assisted	195/60 R14	Ventilated Disc	Disc	Series
19 TZI	5 door estate		4	XU9JA/Z	1905	Automatic	4HP14	Assisted	175/65 R14	Ventilated Disc	Disc	Option
	BX '93 model year											
	SILHOUETTE	FINISH	LEVEL		CUBIC CAPACITY	GEARBOX	TYPE	STEERING	TYRES	BRAKES Front	BRAKES Rear	A.B.R.
16 TZI	5 door saloon	I	4	XU5M3/Z	1580	Automatic	4HP14	Assisted	165/70 R14	Ventilated Disc	Disc	Option
19 TZI	5 door saloon		4	XU9J1/Z	1905	Automatic	4HP14	Assisted	175/65 R14	Ventilated Disc	Disc	Option
GTI	5 door saloon		5	XU9JA/Z	1905	Automatic	4HP14	Assisted	185/60 R14	Ventilated Disc	Disc	Series
16 VALVE	5 door saloon		5	XU9J4/Z	1905	Mechanical	BE3	Assisted	195/60 R14	Ventilated Disc	Disc	Series
19 TZI	5 door estate		4	XU9JA/Z	1905	Automatic	4HP14	Assisted	175/65 R14	Ventilated Disc	Disc	Option

		·		r	
1235	SYMBOLS USED IN THE TEXT	E	THICKNESS	NFP	NO LONGER SUPPLIED
	GB	ECH	EXHAUST	OPTION	OPTIONAL
1 POS	FIRST POSSIBILITY	ELAS	FLEXIBLE WASHER	PORCOU	PORTE LATERALE COULISSANTE
1E-2E	FIRST-SECOND GEAR	ENS	PARTS SET	PORTLAT	PORTE LATERALE BATTANTE
A	AMPERE	ENT	DISTANCE BETWEEN CENTRES	PRETI	PRESTIGE
ADM	INLET	EXT	EXTERNAL	PT	PRESTIGE
АН	AMPERE HOUR	FHC	COUNTERSUNK HEAD WITH HEX. GROOVE	Q	SQUARE NUT
AR	REAR	GLACE	EQUIPMENT WITH GLAZED SIDE PANELS	RAPVOL	VOLUMETRIC RATIO
ASS	ASSEMBLY	GW	GROWER RING	REP	MARKING
AV	FRONT	н	HEIGHT	REPERE	ID. REF
BV	GEARBOX	нс	HEX. GROOVE SCREW W/O HEAD	RMP	REPLACES PREVIOUS MODELS
BVA	AUTOMATIC GEARBOX	HE	HEXAGONAL	RP	SUPERSEDED BY
вум	GEARBOX (MANUAL CONTROL)	HEF	SELF LOCKING NUT	SAUF	EXCEPT
c	TWO-GEAR SET	HEK	CASTELLATED NUT	SUP	UPPER
CAGE	CAGE NUT	немв	NUT WITH LARGE BASE	TA	THREADCUTTER SCREW
CAN	SPLINES	HERI	NUT WITH WASHER	TCA	SQUARE HEAD SCREW
CC	RUBBER	HRDL	HEXAGONAL HEAD WITH WASHER	тсв	ROUNDED CYLINDRICAL HEAD
CDE	CONTROL	INF	LOWER	TCF	SLOTTED CYLINDRICAL HEAD
CENT	CENTRAL	INT	INTERNAL	TF	COUNTERSUNK HEAD
СНС	SCREW WITH HEXAGON GROOVE	INTM	IMTERMEDIATE	TFB	ROUDED COUNTERSUNK HEAD
co	SHAKE-PROOF WASHER	KIT PRO	PARTS SET	тн	HEXAGONAL HEAD
COL	SHOULDERED SCREW	LAR	WIDTH	ТНЕМВ	SCREW WITH LARGE HEAD
CR	TOOTHED WASHER	LAT	LATERAL	THRI	SCREW WITH WASHER
CU	COPPER	LIM	LIMOUSINE	то	RING SEAL
DENT		LIMOU	LIMOUSINE		EQUIPMENT WITH UNGLAZED SIDE PAN-
DEO		LON	LEIGHT	1	ELS
DIAM		M.AR	REVERSE	TPB	SCREW WITH ROUNDED HEAD
	O'AIRE IEIX			i	i


1235	SYMBOLS USED IN THE TEXT				1	
	GB					
ΓR	ROUND HEAD		ļ			
īτ	ALL TYPES					
าบ	TURBO					
TU2	TURBO 2					
v	VOLT					
W	WATT					
					[ .	
		[			1	
				j		
	<u> </u>					 


	COLOUR CODIFYING	}	GREY	200	RED	!	1
	GB	GR	GREY	700	BLACK	İ	
ODE	DESCRIPTION OF COLOUR	JN	YELLOW				
		JX	FURIO RED				
ВА	WHITE	LD	MEDIUM SODALITE BLUE				
BE	BLUE	LE	DARK SODALITE BLUE				
CD	FAIR TOBACCO	LG	SODALITE BLUE				
сн	HAVANE BEIGE	MA	MED. SODAL. BLUE + DARK SODAL. BLUE				
ст	MAFIA BEIGE	MR	MAROON				
	FAIR TOBACCO + HAVANE						
	BEIGE	NR	BLACK				
FCD	FAIR TOBACCO	RG	RED				
FCG	VIRGINIA BEIGE	TD	BLUISH GREY				
FCH	HAVANA BEIGE	πL	ASPHALT MEDIUM GREY				
FED	MAROON	TR	BITUMEN GREY				
FKT	RED	TS	MACADAM LIGHT GREY				
FLD	MEDIUM SODALITE BLUE	VE	GREEN				
FLE	DARK SODALITE BLUE	vv	ASPHALT MEDIUM GREY +				
FLG	SODALITE BLUE	XL	BLACK + GREY				
FTD	BLUISH GREY	XX	BLACK				
ттн	ANTHRACITE GREY	XY	ONYX BLACK				
-ու	ASPHALT MEDIUM GREY	YB	TORNADO GREY				
TR	BITUMEN GREY	YD	DARK GREY				
TS	LIGHT GREY	YX	MEDIUM GREY				
ХX	BLACK	ZN	GREY				







30/01/98 GB C04 † 30/05/98 1235 01 <b>0010</b> 40 PAGE 1	GTI 16V
200	THE ENGINE IS SUPPLIED WITHOUT: FLYWHEEL, CLUTCH, EXHAUST PIPE, IGNITION DISTRIBUTOR, STARTER, ALTERNATOR
	95 646 306 01 NEW ENGINE REP DFW REPERE DFW
	2 95 625 018 01 A003 WITH ASBESTOS RP 0197 J3 01
	0197 J3 01 A005 WITHOUT ASBESTOS
	3 95 625 019 01 AOO3 WITH ASBESTOS RP 0197 J2 01
	0197 J2 01 A005 WITHOUT ASBESTOS
[11/96] D0010310	
E0610	400









35 01 1120 30 CYLINDER-HEAD		19 TRI 19 TZI GTI	
DE 18_00 - 18_00		11 91 517 257 01 FILTER ELEMENT RP 1186 08 01	
16-0	—- <u>·</u> 1	12 96 007 553 OS RING-SEAL DIAM INT 5,10 RP 1166 21 01	
13		13 96 005 977 10 CYL-HEAD SCREW 11X1,50-175 RP 0204 57 01	
15 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		14 79 03 101 154 02 CAPSCREW 8X1,25-16 RP 6922 CB 01	
		15 96 005 979 10 SCREW WASHER EP 8 RP 0205 20 01	
11—	17	16 79 03 053 390 10 PLAIN WASHER 7X14-1,5	
4 - 1		17 79 03 057 005 01 FLEXIBLE WASHER DIAM 8X14 RP 6962 13 01	
9—12		18 79 03 032 036 01 HEXAGONAL NUT DIAM 7X100	
230 07/86	01,1120,30		
	E1120300		










01/98 GB C12 † 35 01 <b>1122</b> 20 GE 1	CYLINDER HEAD COVER				16 TZI 19 TRI 19 TZI GTI
Gt. 1	<u></u>		1	91 538 271 RP 0248 95	01 CYL-HEAD COVER
	<b>₽</b> ──⁴		2	1	01 COVER GASKET
		<b>)</b>	3		01 CYL HEAD LABEL
			4	1	01 SCREW COLUMN DIAM 6X100-37
3		1	5	79 03 053 028	03 PLAIN WASHER 6X12-1.2
				RP 6947 77	01
		2			
\					
A 1/2					
1230		an 01-1122-20			
1230	ins 7s	ন্ত্ৰী (1-1122-20			
	•				
		E1122200			


0/01/98 GB C13 ↑ 30/06/98 0235 01 1122 30 CYLINDER HEAD COVER	GTI 16V
3	1 95 622 325 01 CYL-HEAD COVER  COVER GASKET 01 UP 10 0 5500  RP 0249 74 01
8 10 0	96 159 009 01 SINCE O 5501 RP 0249 74 01 3 91 540 509 01 HARNESS PROTECT RP 5979 78 01
	4 91 538 906 03 COVER GASKET RP 0258 35 01
	RP 0213 06 01 6 91 540 503 01 DEFLECTOR SCREW COLUMN 7 91 539 063 08 DIAM 6X100 -47,7
2 5 0	RP 0250 24 01 8 91 539 064 02 DIAM 6 X 100 - 32,7 RP 0250 25 01 9 91 539 066 01 DIAM 6 X 100 -27
4	RP 0250 26 01 10 91 539 067 02 2 DIAM 6X 100-38,7 RP 0250 27 01
11 —————® 109/88	11 79 03 025 003 RP 6916 03 01 01 01 01 01 01 01 01 01 01 01 01 01
	:22300






0/01/98 GB D15 235 01 <b>1123</b> 10	WATER OUT-FLOW	16 TZI 19 TRI 19 TZI GTI
3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	3	16 — 18
	E11231	100










30/01/98 GB D11	16 TZI
PAGE 3 6	24 91 001 032 02 BRG CAP STUD 11X1,50-95 RP 0132 28 01
5 16 2 19 20 19 20 12 12 10 29 28 9 21 21 23 25 25 25 25 25 27 24 21 24 21 25 25 25 25 25 25 25 25 25 25 25 25 25	25
E1140200	


701/98 GB D10 1 30/06/98 CRANKCASE GGE 1	19 TRI 19 TZI GTI	
6	1 95 643 806 01UP TO 0 5545 RP 0130 L1 01	
22	95 644 355 01 SINCE O 5546 RP 0130 L1	
5 16 19 20	2 95 654 057 01 -SALOON 19 TR) -SALOON 19 TZI	
	95 648 516 01 -ESTATE 19 TRI -ESTATE 19 TZI -GTI	
	3 91 507 124 CYLD LINER SEAL DIAM 85,8X88,3X1.25	
22 32 7	4 93 501 985 02 BEARING SEAL LON 70 RP 0127 05 01	
15	5 91 535 610 01 ENGINE OIL GAUG LON 623 RP 1172 79 01	
21 10 30 28	6 95 572 129 01 OIL LEVEL PROBE D'HUILE RP 1131 52 01	
21 23	7 91 535 630 01 OIL GAUGE GUIDE RP 1171 71 01	
31 25	8 91 510 743 01 HSG GASKET PLAT RP 0145 25 01 UP TO 0 5135	
26 — O   17 24 7 33   09/93   01140210	96 014 452   01 LOCKING PLATE RP 0514 B1 01 SINCE O 5136 UP TO O 5545 + 0326 22 01	
	96 124 994 01 HSG GASKET PLAT RP 0514 81 01 SINCE O 5546	
	9 91 504 095 01 DIAM 25,5X50 RP 0129 06 01	
	10 91 509 685 01 DIAM 14.5 RP 0129 07 01 UP TO 0 5545	
E1140300		







00/01/98 GB D07	GTI 16V
	1 95 643 801 01 CYLINDER BLOCK RP 0130 F5 01
16 8 1	2 95 646 307 01 4 WTR JACK + PIS TAUX 9.7
	3 91 507 124 04 CYLD LINER SEAL DIAM 85,8X88,3X1,25 RP 0112 78 01
27-23-24	4 78 01 015 000   02 BEARING SEAL RP 0127 05 01
29 20 20	5 91 541 013 01 ENGINE OIL GAUG LON 491 RP 1172 99 01
	6 96 005 606 01 OIL GAUGE GUIDE
	7 95 572 129 01 OIL LEVEL PROBE D'HUILE RP 1131 52 01
12 2	8 91 539 562 01 HSG GASKET PLAT RP 0514 57 01 UP TO 0 5135
18 30 21 18	96 014 452   01 LOCKING PLATE RP 0514 81   01 SINCE 0 5136 UP TO 0 5545 + 0326 22   01
25 J 15 D 1140 250	96 124 994 01 HSG GASKET PLAT RP 0514 81 01 SINCE 0 5546
	SOCKET TOOL 9 91 504 095 01 DIAM 25,5X50 RP 0129 06 01
	10 91 509 685 01 DIAM 14,5 RP 0129 07 01
	OIL PRES SWITCH 01 DIAM 16X150 RP 1131 14
	12 97 518 408 01 DIAM 10X1,00 RP 1131 69 01 UP TO 0 5284
	96 130 791 01 SENDING UNIT DIAM 10X100 RP 1131 69 01 SINCE O 5285
E1i40400	










30/01/98 GB D07	GTI 16V
PAGE 1	1 95 643 801 01 CYLINDER BLOCK RP 0130 F5 01
16 B 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2 95 646 307 01 4 WTR JACK + PIS TAUX 9,7
	3 91 507 124 04 CYLD LINER SEAL DIAM 85,8X88,3X1,25 RP 0112 78 01
27—3	4 78 01 015 000 02 BEARING SEAL RP 0127 05 01
25 _ 26 _ 26	5 91 541 013 01 ENGINE OIL GAUG LON 491 RP 1172 99 01
29	6 96 005 606 01 OIL GAUGE GUIDE RP 1171 60 01
	7 95 572 129 01 OIL LEVEL PROBE D'HUILE RP 1131 52 01
22	8 91 539 562 01 HSG GASKET PLAT RP 0514 57 01 UP TO 0 5135
18 30 30 18	96 014 452 01 LOCKING PLATE  RP 0514 81 01 SINCE 0 5136 UP TO 0 5545 + 0326 22 01
7 p7.90) D1140 250	96 124 994 01 HSG GASKET PLAT RP 0514 81 01 SINCE O 5546
	9 91 504 095 01 DIAM 25,5X50 RP 0129 06 01
	10 91 509 685 01 DIAM 14,5 RP 0129 07 01
	OIL PRES SWITCH 01 DIAM 16X150 RP 1131 14 01
	12 97 518 408 01 DIAM 10X1,00 RP 1131 69 01 UP TO 0 5284
	96 130 791 01 SENDING UNIT DIAM 10X100 RP 1131 69 01 SINCE 0 5285
E1140400	














30/01/98 GB D02 ] 30/06/98 1235 01 <b>1145</b> 11 TIMING BELT SHIELDS	16 TZI 19 TRI 19 TZI GTI SINCE O 5546
70 77 72 73 70 70 70 70 70 70 70 70 70 70 70 70 70	1 96 059 593
Di:4510B	


















01/98 GB E06 † 30/06/98 035 01 <b>1210</b> 20 CRANKSHAFT	16 TZI	
AGE 1	1 91 520 243 01 CRANKSHAFT RP 0501 A0 01	
11	SET 10 1/2 BRNG 94 00 113 910 01 5L + 5R RP 0113 91 01 UP TO 0 5970	
	94 560 033 80 01 COTE REPARATION RP 0113 92 01 UP TO 0 5970	
	THRUST BEARING 3 94 00 117 790 01 DIAM 60 RP 0117 79 01	
	94 56 000 541 01 COTE REPARATION RP 0118 A8 01	
13.	4 93 510 910 01 BEARING SEAL DIAM 90X110-10 RP 0127 28 01	
14	5 91 504 836 01 CRANKSHAFT SEAL DIAM 42 X 62 X 8 RP 0326 22 01	
	6 79 03 070 005 02 CRANKSHAFT KEY 6X7X15 RP 6976 06 01	
	7 91 503 585 01 PUMP CONTR PINN 18 DENTS RP 0513 64 01	
	8 91 510 590 01 TIMING PINION 21 DTS RP 0513 37 01	
	9 91 512 174 01 CRKSHAFT PULLEY DIAM 127DIAM 59	
04/93 E1210200	10 91 000 370 01 PIN DIAM 8X15 RP 0537 33 01	
	11 97 599 221 01 PULLEY SCREW 14X150-70 RP 0516 49 01	
	12 79 10 019 504 01 PULLEY WASHER 14,25X40-10 RP 0512 10 01	
	13 96 150 130	
E1210200	RAINURE	


30/06/98 GB E07 1 30/06/98 CRANKSHAFT	16 TZI
235 01 <b>1210</b> 20 CRANKSHAFT  11	14 96 150 129 RP 0113 G7  96 150 128 RP 0113 G8  10 CN INF EP 1,848 RP 0113 G8  11 CN INF EP 1,848 RP 0113 G9  12 CN INF EP 1,848 RP 0113 G9  13 CN INF EP 1,859 RP 0113 G9  14 CN INF EP 1,859 RP 0113 G9  15 CN INF EP 1,859 RP 0113 H0  16 CN INF EP 1,859 RP 0113 H0  17 CN INF EP 1,870 RP 0113 H0  18 CN INF EP 1,870 RP 0113 H0  19 CN INF EP 1,870 RP 0113 H0  10 CN INF EP 1,870 RP 0113 H0  11 CN INF EP 1,870 RP 0113 H0  12 CN INF EP 1,870 RP 0113 H0  15 CN INF EP 1,870 RP 0113 H0  16 CN INF EP 1,870 RP 0113 H0  17 CN INF EP 1,870 RP 0113 H0 RP 011
E12:0200	


















1235 01 <b>1215</b> 30 CONNECTING RODS - RINGS	GTI 16V
1235 01 1215 30 CONNECTING RODS - KINGS PAGE 1  CONNECTING RODS - KINGS  PAGE 1  PAGE	1 95 624 943 01 SET 4 CONN ROD 2 97 90 009 500 01 CN DIAM 50 RP 0606 H1 01 94 56 001 561 01 REPARATION DIAM 49,7 RP 0606 F9 01 3 95 641 147 08 CONNEC ROD BOLT DIAM 9X100 4 95 624 942 04 SET 3 RING PIST 83 (1,5-1,5-3) 4 96 020 342 08 DIAM 24 EP 1,5 RP 0630 22 01 SINCE O 5563 PISTON OIL JET 6 91 541 547 RP 1168 07 01
E1215300	91 541 546 RP 1168 06 01 96 020 742 08 OIL JET SCREW DIAM 6 X 100 - 25 79 03 032 109 08 CONNECTING ROD 9X1,00-10


30/01/98 GB E15 † 30/06/98 1235 01 <b>1230</b> 20 PAGE 1 CAMSHAFT	16 TZI
32 36 January	1 97 521 729 01 REP - B1A/A RP 0801 89 01 UP TO 0 5256
31 35	91 515 386 01 SINCE O 5257 UP TO O 5652 RP 0801 N2 01 01 01 01 SINCE O 5653
A CONTOUR TO	RP 0801 N8 01 2 91 515 138 01 CAMSHAFT SEAL DIAM 36X50X8 RP 0236 44 01
5 4 2	3 91 516 208 01 CAMSHAFT BUFFER RP 0810 10 01 UP TO 0 5652
	4 96 020 713 01 CAMSHAF GEAR RP 0805 35 01
38 34 10	5 91 517 722 01 113 DENTS RP 0816 67 01 UP TO 0 5545
	96 100 168 01 114 DENTS RP 0816 71 01 SINCE O 5546
	6 96 058 681 01 SCREW COLUMN RP 0820 15 01 SINCE O 5546
33,7	7 91 508 050 O1 PT TENSION ROLLER O1UP TO 0 5545 RP 0829 12 01
9 ► 5545 7 30 03/94 E 1230200	96 052 662 01 SINCE O 5546 RP 0829 29 01
	8 91 507 345 O1 ROLLER RETAINER RP 0827 17 01 UP TO 0 5545
	9 91 000 854 01 SPRING RP 0827 18 01 UP TO 0 5545
	10 91 509 682 01 TENSION FINGER DIAM 10X1,50 RP 0820 10 01 UP TO 0 5545
	11 91 595 319 RP 6922 49 01 SOCKET SCREW DIAM 8X125-23
E1250200	
















0/01/98 GB F09   30/06/98 235 01 <b>1241</b> 20 <b>VALVES - TAPPET</b>					19 TRI 19 TZI GTI	
8—————————————————————————————————————		1		01	INTAKE VALVE DIAM 39.5 -SALOON 19 TRI -SALOON 19 TZI DIAM 41.6	
6			RP 0948 56		-ESTATE 19 TRI -ESTATE 19 TZI -GTI EXHAUST VALVE	
4		2	91 518 972 RP 0949 54 91 535 019	01	DIAM 33 -SALOON 19 TRI -SALOON 19 TZI DIAM 34,5	
9			RP 0949 57	01	-ESTATÉ 19 TRI -ESTATE 19 TZI -SALOON GTI	
2-12			97 504 707 RP 0956 22 91 535 896 RP 0953 08	01	VALVE STEM SEAL  VALV SPRG WASHR DIAM 24,5X34,6 - 0,5	
		5	91 517 760 95 607 615 RP 0951 18	08	VALVE SPRING NOIR SPRING RETAINER	
			96 035 074 RP 0950 05	01	VALVE DISTON	
(05/93)	D1241100		RP 0942 17	01	VALVE GUIDE	
		9	94 56 001 305 RP 0220 63 94 56 001 306 RP 0220 64	01 04	ADM DIAM 13,29 ADM DIAM 13,59	
		10		04	ECH DIAM 13,29	
	E1241200				  - 	


00/01/98 GB F08	19 TRI 19 TZI GTI
8—————————————————————————————————————	10 94 56 001 309 RP 0221 18 04 ECH DIAM 13,59 01 11 94 56 001 419 RP 0226 A2 12 94 56 001 422 RP 0227 93 01 EXH VALVE SEAT DIAM 36,57
E1241200	





30/01/98 GB F06 J 30/06/98 1235 01 <b>1242</b> 10 VALVE ADJ	USTING PIECES			
		1	91 507 487 RP 0906 62	ADJUSTING BALL 99 DIAM 13,5 E 2,225 01
1-			91 507 488 RP 0906 63	99 DIAM 13,5 E 2,250 01
·			91 507 489 RP 0906 64	99 DIAM 13,5 E 2,275 01
			91 507 490 RP 0906 65	99 <i>DIAM 13,5 E 2,300</i> 01
	9		91 507 491 RP 0906 66	99 DIAM 13,5 E 2,325 01
			91 507 492 RP 0906 67	99 DIAM 13,5 E 2,350 01
	<b>©</b>		91 507 493 RP 0906 68	99 DIAM 13,5 E 2,375
			91 507 494 RP 0906 69	99 DIAM 13,5 E 2,400 01
			91 507 495 RP 0906 46	99 DIAM 13,5 E 2,425 01
			91 507 496 RP 0906 70	99 DIAM 13,5 E 2,450 01
	111		91 507 497 RP 0906 71	99 DIAM 13,5 E 2,475 01
1230	02/88 01-1242-10		91 507 498 RP 0906 47	99 DIAM 13,5 E 2,500 01
			91 507 499 RP 0906 72	99 DIAM 13,5 E 2,525 01
			91 507 500 RP 0906 73	99 DIAM 13,5 E 2,550 01
			91 507 501 RP 0906 48	99 DIAM 13,5 E 2,575 01
	£1242100		91 507 502 RP 0906 74	99 DIAM 13.5 E 2.600 01


7/01/98 GB F05 J 30/06/98 VALVE	ADJUSTING PIECES			
100.1	[0-	1	91 507 503 RP 0906 7	ADJUSTING BALL 99 DIAM 13,5 E 2,625 15 01
1			91 507 504 RP 0906 4	99 DIAM 13,5 E 2,650 9 01
			91 507 505 RP 0906 7	99 DIAM 13,5 E 2,675
			91 507 506 RP 0906 7	99 DIAM 13,5 E 2,700 7 01
			91 507 507 RP 0906 5	
			91 507 508 RP 0906 7 91 507 509	99 DIAM 13,5 E 2,750 8 01 99 DIAM 13,5 E 2,775
			RP 0906 7	
THE			RP 0906 5	1 01 99 DIAM 13,5 E 2,825
11/			91 507 512 RP 0906 8	99 DIAM 13,5 E 2,850
	117		91 507 513 RP 0906 5	99 DIAM 13,5 E 2,875
1230	02/88 01-1242-10		91 507 514 RP 0906 8	99 DIAM 13,5 E 2,900 2 01
			91 507 515 RP 0906 8	99 DIAM 13,5 E 2,925 3 01
			91 507 516 RP 0906 5	1 1
			91 507 517 RP 0906 8 91 507 518	99 DIAM 13,5 E 2,975 4 01 99 DIAM 13,5 E 3,000
	E1242100		RP 0906 8	





















10/01/98 GB G04 † 30/06/98 1235 01 2221 20 OIL PUMP - FILTER CARTRIDGE				16 TZI 19 TRI 19 TZI GTI
PAGE 1		1	95 624 091 RP 1001 56	D1 ENGINE OIL PUMP
5	:	2	96 002 933 RP 1109 N3	OIL FILTER
			95 638 747 RP 1109 J9	D1 MANN D1
		3	93 501 722 RP 1103 54	OIL FILT INSERT
	1 1	4	91 506 597 RP 1018 37	OIL SUCTION
		1	RP 1033 06	OI OIL PUMP CHAIN 48 MAILLONS
	´		RP 1133 13	
14 10			RP 1157 11	
[11 <b>/h0</b> ] 82	221200		RP 0163 21 0	01 PLUG DIAM 16X1,50 01  01 CENTRING BUSH DIAM 15-20
	ľ	1	NFP NFP	CENTRING BUSH DIAM 15-20
	1	10	79 03 201 140 RP 6917 92	CAPSCREW 11 6X 100-20 11
		1	79 03 201 023 RP 6921 81	33 6 <i>X</i> 100-25 11
	]1	11	91 505 554 RP 1011 05	11 7X100-70
	11:		RP 6921 32 0	
			79 03 101 767 0 RP 1011 12	11 <sup>†</sup> 7 <i>X</i> 100-80
	E2221200			1










30/01/98 GB G08 1 30/06/98 1235 01 <b>2255</b> 10 OIL FILLER - BREATHER PAGE 1	16 TZI
2 2	1 91 508 955 01 OIL BREATHER RP 1178 24 01
	2 91 501 789 01 FILLER PLUG RP 0258 18 01
	3 91 509 680 01 01L VAPOR HOSE RP 1180 25 01
	4 91 538 412 01 DIAM 19X25 ET 14X20 RP 1180 58 01
13 12	5 91 538 413 01 DIAM 14X20 ET 12X18 RP 1180 C4 01
	6 96 076 918 01 7 96 076 815 01
	RP 1180 53 01  8 SRV 000 019 99 METALLIC CLAMP DIAM 25 A 47 LARG 9 RP 6981 39 01
3	9 79 03 065 065 01 PLUG SEAL DIAM 42X52X5
5	10 79 10 034 230 01 BRTHR BRACKET RP 1439 10 01
	11 79 03 079 095 01 SWIVEL CLIP 2 DIAM 18 RP 6992 39 01
<b>D</b> O-8	12 79 03 201 021 01 CAPSCREW 6X1,00-16 RP 6915 69 01
03/94 E 2255100	13 79 03 057 013 01 FLEXIBLE WASHER 6,4X12-0,5 RP 6962 04 01
	14 25 260 019 01 HEXAGONAL NUT DIAM 6X1,00
E2255100	









0/01/98 GB G12 1 235 01 <b>2310</b> 20	WATER PUMP					16 TZI 19 TRI 19 TZI GTI
235 01 <b>2310</b> 20 AGE 1	WATER PUMP	02/8x 1-231-20	2	95 656 566 RP 1201 63 95 656 567 RP 1201 61 96 042 956 RP 1206 A4 79 03 001 081 RP 6915 36 + 6962 12	01 01 01 01 01 05 05	WATER PUMP UP TO 0 5545 SINCE 0 5546 WTR PUMP GASKET WASHER-SCREW DIAM 7X1,00-20
		E7:110200				









10/01/98 GB H15 1 1235 01 <b>2410</b> 30	MOTOR-DRIVEN FAN					GTI 16V	
PAGE 1			1	95 636 664	01	FAN BRACKET	
	M ii	N 14-7	2	95 636 643	01	RECYCL PANEL	
	Ø -6 4~		3	95 593 547	02	MOTOR DRIVN FAN	
7~ "]			4	95 593 548 RP 1254 41		MOTOR DRIV FAN	
			5	95 591 751		FAN BRACKET	
<u></u> 10	A MARIE H		6	95 608 293	01	SUP	
8/	SON I	2	7	95 585 433 RP 0382 53		SPACER	
			8	95 635 732	02	RADIATR BRACKET	
3(#			9	95 592 530	05	RUBBER GROMMET DIAM 12 EXT 24	
4	5		10	79 03 201 265 RP 6921 53 + 6962 99	02 01		
1230	[02/ee]	1.242.20	11	79 03 020 002 RP 6915 84		6X100-12	
			12	79 03 001 894	03	WASHER-SCREW 6X1,00-14	
			13	79 03 005 026 RP 6905 64		CAPSCREW 4X80-8	
			14	79 03 056 054 RP 6959 55		SPRING WASHER 5,2X10-0,4	
			15	79 03 044 020 RP 6941 93		CAGED NUT 6x100-14-12,4-6	
		6Z410300					


30/01/98 GB C02 † 30/06/98 1235 01 3300 10 COMPLETE AUTOMATIC GEARBOX	BVA
1235 01 3300 10 PAGE 1  REPERE	1 96 079 333 NFP 11 96 079 333 NFP 12
[04/93] D330023C	
5330023C	






0/01/98 GB C05 235 01 <b>3314</b> 10	GEARBOX CASING - FASTENING			GTI 16V
AGE 1		1 79	03 067 033 03 RP 6968 42 01	PIN DIAM 12 LON 15
	1—@	8 2 79	03 201 781 06 RP 6923 09 01	SELF-TAP SCREWS HRDL 10X1,50-70
2 —		6 3 79	03 009 002 RP 6913 78 01	SOCKET SCREW 10X150-70
		)5   4   79	03 201 872 17 RP 6922 70 01	SELF-TAP SCREWS THRI 7X100-35
Co Co		5 79		CAPSCREW DIAM 10X1,50-65 UP TO B 2780499
			<b>6923 09</b> 04	SELF-TAP SCREWS 10X150-70 SINCE B 2780500
		6 79	03 027 298 02 RP 2210 09 01	SCREW COLUMN DIAM 7X100-15-35
		7 79	03 001 898 08 RP 6921 09 01	SELF-TAP SCREWS 7X100-22
		8 79	03 057 003 02 RP 6962 12 01	FLEXIBLE WASHER 7,4X14,2X0,8
3 - S - R	1	9 97	511 946 05 <b>RP 2221 26</b> 01	STOP PLATE 17X17
9		7		
30	[06/89]	01 3314 10#		
		E3314100		

01/98 GB C06 T	30/06/98		_	• • • • • • • • • • • • • • • • • • • •			
35 01 <b>3324</b> 10 GE 1	TACHOMETER CONTROL - AXLE HOUSING						
	11		1	97 500 373 RP 2641 50	01 01	CONTROL SUPPORT	
	14—————————————————————————————————————	:	2	97 500 211 RP 2228 12		EXTENSION -BVA UP TO O 4725	
12				94 02 228 108 RP 2228 12	01 01	EP = 8,65MM DIAM 6 -BVA SINCE O 4726	
,2				97 500 365 RP 2228 03		E = 8,65MM DIAM 7 -GTI 16V	
	93			97 512 714 RP 2228 04		E=10MM DIAM 7 -GTI 15V	
	2	;	3	97 504 735 RP <b>2649 04</b>	01	CONTROL PINION 19 DTS -16 TZI -GTI 16V	
13						17 DTSSALOON 19 TRISALOON 19 TZIESTATE 19 TRIESTATE 19 TZIESTATE 19 TZI	
15			4	97 504 694 RP 2643 02		TACHOMETR SCREW 22 DENTS -16 TZI -GTI 16V	
30	<u> 06/89</u> ] 01 3324 10	,				19 DTS -SALOON 19 TRI -SALOON 19 TZI -ESTATE 19 TRI -ESTATE 19 TZI -GTI	
			5	96 080 792 RP 3121 26		SEAL RIGHT DIAM 29,9X47-11,3	
			7	79 03 065 130 RP 2212 07	01	RING-SEAL 59 E 3	
	E3324100			RF 2212 07	01		







0/01/98 GB C09 1 235 01 <b>3330</b> 10 PAGE 2	GEAR-BOX COOLING		BVA
AGE 2			1 POS: CHAUSSON - 2 POS: MODINE
18	26 29_LZ	Salar Salar	9 93 501 368 01 DIST CHMBR SEAL DIAM 67,7 RP 1104 21 01 MODINE
	17 11 4	23_50	10 95 610 722 01 CHAUSSON
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\		7 27-	95 611 987 01 RP 2275 20 01
6	21	€65_20	11 95 614 476   01 RING SEAL   01   RING SEAL   01   01   01   01   01   01   01   0
		13 -22 24	12 95 614 483   01 WASHERS SET 18,2X22-1,4   01   13   95 614 471   01   SEAL DIAM 10X13,5-1
			RP 2106 06 01 RING SEAL
		50 <sup>19</sup> 16 28	14 95 614 478 02 52XTORE 2,65 RP 2312 18 01
OP 27 13	10		15 95 614 477   01 6 TORE 2   RP 2341 18   01
	9-06		16 95 614 470
	15 QQ		18 95 633 789 01 GRILLE
	14 7 7 11/92	E3330100	19 95 619 442 01 UNLOCKING CAM
			20 95 637 747 01 SWIVEL CLIP DIAM 9,5 DIAM 20 RP 6992 R4 01
			21 94 02 221 178   01 MAGNETIC BLOCK   01   01   01   01   01   01   01   0
		E3350100	


95 01 3330 10 GEAR-BOX COOLING	BVA
26 29_F3 18 25 3	1 POS: CHAUSSON - 2 POS: MODINE  22 91 537 031
6 - 21 - 21 - 20 - 20 - 20 - 21	23 96 008 837 RP 1664 A8 01 -SALOON 19 TRI -STATE 19 TZI -STATE 19 TZI -STATE 19 TZI -STATE 19 TZI -STATE 19 TZI -GTI
24 24 7 7 19 16 28	25
5 13 9 0 8 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	26 95 636 441 01 SUPPORT SPACER DIAM 16X7,5X5 -SALOON 19 TRI -SALOON 19 TZI -ESTATE 19 TRI -ESTATE 19 TZI -GTI  27 96 035 618 01 SWIVEL CLIP 27 6 L 32
15 6 6 7 14 15 11/92 E3330100	28 94 02 571 108 01 SELECT SPINDLE  RP 2571 10 01
	29 95 609 755 RP 1654 58 01


90/01/98 GB C11 1 30/06/98 1235 01 3331 10 GEARBOX - LOWER COPONENTS PAGE 1	BVA
	1 95 659 546 01 REP 097 -16 TZI GEARBOX 1036000137
	94 02 570 758 RP 2570 75 01 -16 TZI GEARBOX 1036000166
2 8	94 02 570 370   01 HYD CONTROL REP 054   RP 2570 37   01 -SALOON 19 TRI -SALOON 19 TZI   GEARBOX 1036000144
12 11	94 02 570 570 RP 2570 57 01 BVA HYD UNIT REP 079 101 -ESTATE 19 TRI -ESTATE 19 TZI -GTI GEARBOX 1036000091
59	2 95 614 484 01 STRAINER RP 2263 14 01
10 3	3 95 614 480   01 AGB OIL SUMP RP 2213 13 01   01 OIL GAUGE RP 2266 15 01 UP 70 0 4619
E3331100	96 065 786 01 GR-BX DIPSTICK RP 2266 22 01 SINCE O 4620
	5 96 045 254 01 FILLING PIPE VOIR NOTA RP 2270 40 01 -16 TZI
	96 045 041 01 FILLER PIPE VOIR NOTA -19 TRI -19 TZI -GTI
	6 95 614 474 OI CASING PLUG DIAM 10X100 RP 2208 23 01
	7 95 614 485 01 RING SEAL RP 2264 12 01
£7331100	8 95 614 486 OI FLAT SEAL OI/.



01/98 GB C13 T SECONDARY SHAFT - GEARS - SYNCHRONIZE	S GTI 16V
GE 1 13 1 7 12 9 2	1 94 02 316 710 01 SHAFT C14X62 RP 2316 A3 01
	2 97 534 314 01 1ER-38 DT (13X38) RP 2334 17 01
	3 94 02 335 410 01 2E -(20X37) RP 2335 47 01
	4 97 535 402 01 3E-4E - 31 X 32 RP 2336 1B 01
6	5 97 535 403 01 5E - 28 DENTS RP 2344 06 01
	6 94 02 323 660 01 SYNCHRONIZER 1E-2E RP 2323 70 01
	7 96 014 376 01 DIAM 36X72X17.5 RP 2317 66 01
15	8 97 500 132 01 DIAM 25X75X17 RP 2317 36 01
1230 (তি/েডরী ৩1 324	9 97 511 466 01 NEEDLE BEARING DIAM 35,8X52X2 RP 2317 41 01
	10 79 03 040 029 02 SELF LOCKG NUT 20X150-10 RP 2304 43 01
	11 79 03 066 124 01 DIAM 76,5 RP 2318 73 01
	12 79 03 066 197 01 DIAM INT 34 RP 2318 75 01
	13 97 504 923 01 OIL FITTING RP 2211 22 01
	14 00 80 624 600 01 CAPSCREW DIAM 7X1,00-22
	15 79 03 053 425 01 PLAIN WASHER DIAM 7,1X22X3 01 01 01 01 01 01 01 01 01 01 01 01 01
E334	00











235 01 <b>3351</b> 20 SPINDLES AND FORKS	GTI 16V	
AGE 2	16 96 035 199 01 SHAFT SEAL DIAM 16X30X7X11 RP 2515 22 01	
8——————————————————————————————————————	STOP-RING 17 79 03 066 095 01 19.8X22-1	
23	18 96 035 244 01 RP 6979 86 01	
17 0 22	19 79 03 065 008 02 RING-SEAL DIAM INT 15 X 20X2,5 RP 2541 20 01	
5 21-	20 79 03 067 063 03 DIAM 3-15 ELAST RP 6968 23 01	
15 27 27 15 15 15	21 97 520 820 01 DIAM 4,5-22 RP 6968 71 01	
31 26 20 18 20 13	22 97 599 251 01 DIAM 4.5 LON 30 RP 6969 05 01	
7 1 13-19-24-25-29 A	23 79 03 067 074 01 DIAM 7X30 RP 6969 45 01	
	24 79 03 067 037	
E3351200	25 79 03 067 038	
	26 97 599 241 01 SCREW CHC 7X1,00-22 RP 6913 98 01	
	27 00 80 624 600 01 CAPSCREW DIAM 7X1,00-22	
	PLAIN WASHER 28 79 03 053 425 02 DIAM 7,1X22X3 RP 6947 55 01	
	29 97 532 121 01 DIAM 28X16,5X1 RP 6947 84 01	
	30 79 03 062 014 01 GRBX SWITC SEAL DIAM 15,2X21X1	
	31 96 020 369 01 NUT WITH BASE DIAM 12X1,50 RP 6934 28 01	
E3351200		


35 01 3357 20 KICK DOWN CABLE	BVA
3 5 7	1 95 639 045 D1 CONTROL CABLE RP 2444 E1 D1
	2 95 597 355 01 STOP LUG RP 2437 15 01
	3 95 599 645 NFP 01 CONTROL BRACKET LEFT
10	4 75 527 220 01 STOP LUG
11 12	5 95 609 755 01 RETAINING CLIP RP 1654 58 01
	6 95 601 166 01 CONTROL LEVER RP 2435 67 01
7	7 96 059 996 02 CONTRL BALL END DIAM 5X0,80-39 RP 2454 A4 01
8 1 A 1	8 95 611 526 01 CLIP
6	9 79 03 201 150 02 CAPSCREW DIAM 8X1.25 - 20 RP 6917 03 01
	10 79 03 058 028 01 SPRING WASHER DIAM 6X14X1.4 RP 6962 99 01
	11 79 03 053 043 03 PLAIN WASHER 8X16-1,5 RP 6947 78 01
	12 25 260 019 01 HEXAGONAL NUT DIAM 6X1,00
	13 79 03 034 004 01 SELF LOCKG NUT HE 8X1,00 RP 6939 45 01
`	
E3957	200

















30/01/98 GB B02 T 30/06/98 1235 PAGE 2 01 ENGINE - GEARBOX		
MANUAL GEARBOX HOUSING - GTI 16V	3310-20	2-C04
GEARBOX CASING - FASTENING - GTI 16V	3314-10	2-C05
TACHOMETER CONTROL - AXLE HOUSING	3324-10	2-C06
GEAR-BOX COOLING - BVA	3330-10	2-C08
GEARBOX - LOWER COPONENTS - BVA	3331-10	2-C11
SECONDARY SHAFT - GEARS - SYNCHRONIZERS - GTI 16V	3344-70	2-C13
PRIMARY SHAFT-PINIONS-SYNCHRONISERS - GTI 16V	3346-40	2-C14
SPINDLES AND FORKS - GTI 16V	3351-20	2-D15
KICK DOWN CABLE - GTI 16V - BVA	3357-10 3357-20	2-D13 2-D12
GEAR-CHANGE CONTROL-BINACLE SIDE - GTI 16V - BVA	3358-10 3358-20	2-D11 2-D10
SEALING BELLOW F.GEAR-CHANGE LEVER - GTI 16V	3360-10	2-D08
DIFFERENTIAL	3430-40	2-D07
	`	
• .		

30/01/98 GB B01 1 30/06/98				T	1
1225			CONNECTING RODS - RINGS	1015 10	1-E12
PAGE 1 U1 ENGINE - GEARBOX			- 16 TZ1	1215-10	1
			- 19 TRI 19 TZI GTI	1215-20	1-E13
ENGINE - GASKET KIT			- GTI 16V	1215-30	1-E14
- 16 TZI	0010-20	1-002	CAMSHAFT	1	
- 19 TRI 19 TZI GTI	0010-30	1-C03	- 16 TZI	1230-20	1-E15
- GTI 16V	0010-40	1-C04	- 19 TRI 19 TZI GTI	1230-30	1-F14
- 011 104			- 19 141 19 121 G11	1230-40	1-F12
CYLINDER-HEAD .	1		- 611 100		
- 16 TZI	1120-20	1-C05	VALVES - TAPPET	1	l .
- 19 TRI 19 TZI GTI	1120-30	1-C07	- 16 TZI	1241-10	1-F10
- GTI 16V	1120-40	1-C09	- 19 TRI 19 TZI GTI	1241-20	1-F09
	1		- GTI 16V	1241-30	1-F07
CYLINDER-HEAD PLUGS AND SECURING	1121-10	1-C10		1	1
- GTI 16V	11.27 10	' ' ' '	VALVE ADJUSTING PIECES	1242-10	1-F06
CYLINDER HEAD COVER	1			12-10	,,,,,,
- 16 TZI 19 TRI 19 TZI GTI	1122-20	J-C12	INJECTION DEVICE	1	İ
- GTI 16V	1122-30	1-C13	- 19 TRI 19 TZI GTI	1440-10	1-F02
	i		- GTI 16V	1440-20	1-F01
WATER OUT-FLOW	4400 40			1	1
- 16 TZI 19 TRI 19 TZI GTI	1123-10	1-C14	MIXTURE - CONTROL UNIT	1	
- GTI 16V	1123-20	1-D14	- 16 TZ1	1441-10	1-G01
CRANKCASE		İ		1441-20	1-G02
- 16 TZI	1140-20	1-D13	- GTI 16V	1441-30	1-G03
- 19 TRI 19 TZI GTI	1140-30	1-D10	OIL PUMP - FILTER CARTRIDGE	1	
- GTI 16V	1140-40	1-D07	- 16 TZI 19 TRI 19 TZI GTI	2221-20	1-G04
- 011 107		1	- GTI 16V	2221-30	1-G06
TIMING BELT SHIELDS		1	- 011 194		
- 16 TZI 19 TRI 19 TZI GTI - UP TO O 5545	1145-10	1-D04	OIL FILLER - BREATHER	1	
- 16 TZI 19 TRI 19 TZI GTI - SINCE O 5546	1145-11	1-D02	- 16 TZI	2255-10	1-G08
- GTI 16V	1145-20	1-D01	- 19 TRI 19 TZI GTI	2255-15	1-G09
DIL CLIAAR		1	- GTI 16V	2255-20	1-G11
OIL SUMP	1147-20	1-E01	WATER BUMB	1	
- SALOON 16 TZI 19 TRI 19 TZI - UP TO O 6140	1147-20A	1-E03	WATER PUMP	2310-20	1-G12
- PETROL XU5 XU9 AIR CONDITIONING EXCEPT XU9J4 - SINCE O 6141	1	1 , 200	- 16 TZI 19 TRI 19 TZI GTI	1 -	
- SALOON GTI 16V ESTATE 19 TRI 19 TZI - UP TO O 6140	1147-30	1-E04	- GTI 16V	2310-30	1-G13
- SALOON GTI 16V 19 TZI ESTATE 19 TZI - SINCE O 6141	1147-30A	1-E05	MOTOR-DRIVEN FAN	1	
- SALOUR OTT TOV 13 TELESTATE 13 TELESTATE OF BILL			- 16 TZI 19 TRI 19 TZI GTI	2410-20	1-G14
CRANKSHAFT			- GT) 16V	2410-30	1-H15
- 16 TZI	1210-20	1-E06		1	
- 19 TRI 19 TZI GTI	1210-30	1-E08	COMPLETE AUTOMATIC GEARBOX		
- GTI 16V	1210-40	1-E10	BVA	3300-10	2-C02
			MANUAL GEARBOX		
			· GTI 16V	3300-30	2-C03
		İ	- GII 16V	3300-30	2.003

SE 1							IN	DEX						
NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	RI
22 363 019	01-2410-20	14	91 504 836	01-1210-30	05	91 508 955	01-2255-15	01	91 517 722	01-1230-30	05	91 538 612	01-1120-30	+ 7
22 470 009		05	91 504 836	01-1210-40	06		01-2255-20	01	91 517 722	01-1230-20	05	91 538 612	01-1120-20	1.
	01-1140-20	26	91 504 836	01-1210-20	05		01-2255-10	03	91 517 760	01-1241-20	05	91 538 721	01-1210-40	1
	01-1140-30	26	91 505 554	01-2221-30	14		01-1230-30	10	91 517 760	01-1241-10	05	91 538 722	01-1230-40	-
	01-1140-40	27	91 505 554	01-2221-20	111	91 509 682	01-1230-20	10	91 517 964	01-1123-10	09	91 538 906	01-1122-30	-
23 752 019		16	91 506 597	01-2221-20	04		01-1140-40	10	91 518 899	01-1210-30	01		01-1230-40	1
23 795 019		16	91 506 597	01-2221-30	05		01-1140-30	10	91 518 971	01-1241-20	01	91 538 926	01-1230-40	1
25 260 019		12		01-2221-30	111		01-1140-20	10	91 518 972	01-1241-20	02	91 539 063	01-1122-30	1
	01-1145-10	79	91 506 834	01-2221-20	09	91 509 921	01-1242-10	01	91 519 594	01-1230-30	01	91 539 064	01-1122-30	1
25 260 019		14	91 507 124		03		01-1242-10	01	91 520 152	01-1140-20	05	91 539 066	01-1122-30	1
	01-2255-15	16		01-1140-30	03		01-1242-10	01	91 520 243	01-1210-20	01	91 539 067	01-1122-30	1
	01-2410-20	15	91 507 124		03		01-1242-10	01	91 521 113		11		01-1440-20	-
	01-3357-20	12		01-1230-30	08		01-1242-10	01	91 521 113		11		01-2255-15	-
	01-1441-10	06		01-1230-20	08		01-1242-10	01	91 521 113		111		01-1145-20	- 1
	01-1120-20	04	91 507 487	01-1242-10	1 01	91 509 927	01-1242-10	01		01-1241-20	01	91 539 562	01-1140-40	-1
	01-1120-30	04	91 507 488	01-1242-10	101	91 509 928	01-1242-10	01	91 535 017	01-1241-10	01	91 639 711	01-1145-20	1
	01-1120-30	03	91 507 489	01-1242-10	01		01-1210-20	08	91 535 019	01-1241-10	02	91 539 750	01-1123-20	-
	01-1120-20	03		01-1242-10	01		01-1210-30	08	91 535 019	01-1241-20	02	91 539 867	01-2255-20	ı
75 527 220	01-3357-20	04	91 507 491	01-1242-10	1 10	91 510 743	01-1140-20	08	91 535 610	01-1140-30	05	91 539 899	01-1145-20	-
91 000 370	01-1147-20	07	91 507 492	01-1242-10	101	91 510 743	01-1140-30	08	91 535 630	01-1140-30	07	91 540 028	01-1120-40	
91 000 370	01-1210-20	10	91 507 493	01-1242-10	01	91 510 753	01-1145-10	75	91 535 630	01-1140-20	07	91 540 097	01-1123-10	Ţ
91 000 370	01-1210-40	12	91 507 494	01-1242-10	01		01-1145-10	73	91 535 896	01-1241-20	04		01-1122-30	- 1
	01-1210-30	10	91 507 495	01-1242-10	01		01-1120-30	05	91 535 896	01-1241-10	04	91 540 259		ı
91 000 374	01-1140-20	18	91 507 496	01-1242-10	01	91 511 858	01-1120-20	05	91 535 997	01-1242-10	01		01-1147-30	
91 000 374	01-1140-30	18		01-1242-10	01		01-1123-10	08	91 535 998	01-1242-10	01		01-1210-40	-
91 000 632	01-1140-30	22	91 507 498	01-1242-10	01		01-1210-30	09	91 535 999	01-1242-10	01	91 540 503		- [
91 000 632	01-1140-20	22	91 507 499	01-1242-10	01		01-1210-20	09 1	91 536 000	01-1242-10	01		01-1122-30	ł
91 000 632	01-1140-40	20		01-1242-10	01		01-1145-10	07	91 536 001	01-1242-10	01		01-1121-10	-1
91 000 754	01-1120-20	06	91 507 501	01-1242-10	01		01-3357-10	07		01-1242-10	01		01-1241-30	1
91 000 754	01-1120-30	06		01-1242-10	01	91 512 793	01-1145-10	06	91 536 003	01-1242-10	01	91 540 782		1
91 000 760	01-1123-10	17	91 507 503	01-1242-10	01	91 513 214	01-1440-10	04	91 536 004	01-1242-10	01	91 540 792	01-1121-10	1
91 000 760	01-1147-30	07	91 507 504	01-1242-10	01		01-1440-20	04	91 536 005	01-1242-10	01	91 540 843	01-1210-40	1
91 000 854	01-1230-20	09		01-1242-10	01		01-1241-10	08	91 536 006	01-1242-10	01	91 540 844		
91 000 854	01-1230-30	09	91 507 506	01-1242-10	l oi		01-1241-20	08	91 536 007	01-1242-10	01	91 540 905		1
91 001 032	01-1140-40	22	91 507 507	01-1242-10	01		01-1123-20	03	91 536 008	01-1242-10	01	91 540 905	01-1440-20	-
	01-1140-30	24		01-1242-10	01		01-1230-20	02	91 536 009	01-1242-10	01	91 540 934		1
	01-1140-20	24		01-1242-10	01		01-1230-30	02	91 536 154	01-1441-20	01			ł
91 001 034	01-1140-20	31	91 507 510	01-1242-10	01		01-1230-20	01	91 536 802	01-1440-10	04			-
91 001 034	01-1140-30	33	91 507 511	01-1242-10	01		01-1145-10	10	91 537 031	01-3330-10	22	91 540 948	01-1145-10	1
	01-1140-40	30		01-1242-10	01		01-1145-11	04		01-1230-30	01	91 541 013	01-1140-40	1
	01-2255-15	02		01-1242-10	01		01-1230-20	03		01-1122-20	01	91 541 228	01-1241-30	-
	01-2255-10	02	91 507 514	01-1242-10	01	91 516 208	01-1230-20	03	91 538 412		04	91 541 229	01-1241-30	-
	01-1210-20	07		01-1242-10	01		01-1440-10	01		01-2255-15	04	91 541 318	01-1230-40	
	01-1210-30	07	91 507 516	01-1242-10	01		01-1120-20	10	91 538 413	01-2255-15	05	91 541 324	01-2255-20	-
91 503 587	01-2221-20	05		01-1242-10	01		01-1120-20	10		01-2255-10	05	91 541 346	01-2255-20	-
	01-1140-40	09		01-1242-10	01	91 517 101	01-1120-30	04	91 538 414		06	91 541 347	01-1210-40	-
	01-1140-30	09	91 507 684	01-1123-10	02	91 517 257		11	91 538 416		03	91 541 348	01-1210-40	1
	01-1140-20	09		01-1230-20	07		01-1120-40	08	91 538 489		13	91 541 478	01-1241-30	+
	01-2221-20	06	91 508 050	01-1230-20	07		01-1120-20	11	91 538 611		02	91 541 546	01-1215-30	1
	01-2221-30	07		01-1730-30	02		(11-1145-10	1 02	91 538 611		02	91 541 547	01-1215-30	
	v1-1241-10	06	91 508 955		01	9: 517 <b>339</b> 9: 517 <b>41</b> 7			91 538 6		02	91 541 556	155-20	1

30/01/98 GB B05 1 1235 PAGE 2

INDEX

FAGE 2	ĺ													
NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP
	01-2221-30	08		01-3357-10	08		01-3357-20	08		01-2410-30	01	96 002 933	01-2221-20	02
91 541 566		07	95 567 915	01-2410-20	06		01-3330-10	02			02	96 003 302	01-3351-20	03
	01-1145-10	09	95 572 129	01-1140-20	06		01-3330-10	08	95 637 747	01-3330-10	20	96 003 339	01-3351-20	08
		04	95 572 129	01-1140-30	06		01-3330-10	10	95 638 556	01-1123-20	09	96 004 150	01-1230-40	08
91 541 776		08	95 572 129	01-1140-40	07		01-3330-10	16		01-2221-20	02	96 005 534	01-2255-15	03
	01-1145-20	09	95 579 254	01-3358-10	10		01-3330-10	13	95 638 747	01-2221-30	02	96 005 606	01-1140-40	06
	01-1145-20	04	95 579 683		06	95 614 471	01-3331-10	10	95 639 045	01-3357-20	01	96 005 977	01-1120-20	13
	01-1140-40	24	95 579 684	01-1123-20	06	95 614 472	01-3330-10	06	95 640 493	01-1123-10	07	96 005 977	01-1120-40	03
	01-1140-30	28	95 579 684	01-1123-10	07		01-3330-10	07		01-1120-30	01	96 005 977	01-1120-30	13
	01-1140-40	16	95 585 178	01-1122-20	03	95 614 474	01-3330-10	05		01-1215-10	01	96 005 978	01-1120-40	04
91 595 277	01-1230-40	11	95 585 433	01-2410-20	02	95 614 474	01-3331-10	06		01-1215-20	04	96 005 979	01-1120-20	15
91 595 279	01-1121-10	08	95 585 433	01-2410-30	07	95 614 476	01-3330-10	111		01-1215-30	03	96 005 979	01-1120-30	15
91 595 280	01-1140-40	19	95 587 296	01-1441-20	03		01-3330-10	15		01-1215-10	04		01-2255-15	
91 595 295	01-1121-10	13	95 591 751	01-2410-30	05		01-3330-10	14		01-1123-10	01			06
91 595 319	01-1230-30	111	95 591 751		04		01-3330-10	17		01-1215-20		96 007 553		12
91 595 319		11	95 592 505		07		01-3331-10	03			01	96 007 553		06
91 595 319	01-1230-40	15	95 592 530		05		01-3331-10	09		01-1140-40	01	96 007 553		12
91 595 336		80	95 592 530		09		01-3330-10			01-1140-30	01	96 008 217		02
93 010 170		10	95 593 547		03	95 614 484		12		01-1140-20	01	96 008 837		23
	01-1147-20A		95 593 548		04	95 614 485		02	95 643 847	01-1120-30	01	96 010 857		10
	01-2221-30	03	95 593 786		07	95 614 486		07		01-1120-20	01	96 011 198		25
	01-2221-30	04	95 597 355		02			08		01-1123-10	01	96 012 197		05
	01-2221-30	12	95 599 645		03	95 614 597 95 614 597	01-0010-30	02		01-1215-20	03	96 012 394		05
	01-3330-10	09	95 601 148		02	95 614 598		02		01-1215-10	03	96 012 462		06
93 501 396		05	95 601 151		11			03		01-1215-10	03	96 012 463		04
	01-1230-40	19	95 601 159				01-0010-30	03		01-1140-20	01	96 012 603		02
	01-1230-20	36	95 601 160		05	95 614 684		06		01-1140-30	01	96 012 834		09
	01-1230-20	36	95 601 164		03		01-1440-10	06		01-0010-40	01	96 012 927		01
	01-1147-20	03			80		01-1215-20	01		01-1140-40	02	96 012 928		01
	01-1123-10	12	95 601 166 95 601 820		06		01-3331-10	13		01-1140-30	02	96 013 227		111
	01-2221-20	03	95 601 821		06		01-1120-40	01		01-0010-30	01	96 013 401		01
	01-1123-20	02			07	95 619 442		19		01-3351-20	01	96 014 376		07
	01-1140-30	04	95 603 164		01		01-0010-30	01		01-1140-30	02	96 014 452		08
	01-1140-30	16	95 604 595 95 606 688	01-3358-20	01		01-3330-10	04		01-1140-20	02	96 014 452	01-1140-30	08
	01-1140-20	16			12	95 622 325		01		01-0010-20	01	96 015 473		09
	01-1147-30	04	95 607 615 95 608 293	01-1241-20	06		01-2221-20	01		01-3330-10	03	96 015 476	01-1230-40	10
	01-1147-30	02	95 608 293		03		01-2221-30	01		01-2310-20	01	96 017 206		10
	01-1123-20	04	95 609 084		06	95 624 942		04		01-2310-30	01	96 017 606		01
93 502 228		03			13		01-1215-30	01		01-2310-20	01	96 017 828	01-3430-40	09
93 510 261	01-1123-10		95 609 755		05		01-0010-40	02		01-1140-20	02	96 018 108	01-3310-20	09
93 510 910			95 609 755	01-3330-10	29	95 625 019		03		01-3330-10	03	96 019 896	01-3430-40	03
		04	95 609 905		11	95 630 788		09		01-3331-10	01	96 020 342	01-1215-30	05
93 510 910		05	95 609 906		05		01-3358-10	04	95 659 650		01	96 020 369	01-3351-20	31
93 510 910		04	95 609 908		08	95 632 820		02		01-0010-20	01	96 020 450		06
95 020 518		04	95 609 910		06	95 633 789		18		01-0010-30	01	96 020 713		04
95 496 925		01	95 610 656		10	95 635 353		08	95 662 978		01	96 020 713		04
	01-3358-20	07	95 610 657		14	95 635 573		06	96 002 074	01-1145-20	05	96 020 742		07
	01-3358-20	06	95 610 719		02	95 635 573		13	96 002 516	01-1121-10	11	96 021 820		01
	01-3360-10	02	95 610 720		08		01-3330-10	25	96 002 928	01-1140-20	19	96 022 323		06
	01-3331-10	111	95 610 721		09	95 635 732		80	96 002 928	01-1140-30	19	96 024 241		02
	01-3358-10	01	95 610 722		10	95 636 441	01-3330-10	26	96 002 928	01-1140-40	17	96 024 627	01-3430-40	07
95 567 221	ui-335 <b>8-10</b>	03	95 610 799	01-3358-10	09	95 636 643	01-2410-30	02	96 002 935	31-2221-30	02	96 026 883	ÚI-1230-40	03
,		1 1		I				1 :		1				1 22 1

35 GE 3							IN	DEX						
NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	R
96 027 111	01-1441-3		96 064 444		03		01-1210-30	14	97 532 121	01-3351-20	29	6962 50	01-1147-30A	1 0
96 029 207	01-1121-1		96 064 445		02		01-1210-30	14	97 532 122		13	77 03 009 016	01-1147-20	1
96 029 208 96 030 532	01-1121-1		96 065 786		04		01-1210-20	14	97 532 278		02	77 03 062 062	01-1140-30	-
96 030 535	01-3351-2 01-3351-2		96 067 758		10		01-1210-40	20	97 533 997	01-3430-40	04	78 01 015 000	01-1140-20	
	01-3351-2		96 069 933 96 069 936		08	96 150 129	01-1210-40	20	97 534 314		02	78 01 015 000	01-1140-40	1
96 030 983	01-3300-1			01-3357-10	02		01-1210-20	14	97 535 399		02	78 30 197 000	01-1147-20	1
96 031 464	01-1145-1		96 076 815		07	96 150 129 96 150 130	01-1210-30	14	97 535 402	01-3344-70	04	79 03 001 043	01-1145-10	1
96 031 465	01-1145-1		96 076 918		06		01-1210-30	13	97 535 403		05		01-2310-20	1
96 031 466	01-1145-1		96 077 209		14	96 150 130	01-1210-20	13	97 599 108		17	79 03 001 081	01-2310-30	1
96 032 825	01-3346-4		96 077 252		03	96 150 130 96 154 874	01-1210-40 01-2221-30	19	97 599 108		06		01-2221-30	1
96 032 965	01-3346-4		96 079 333	01-3310-20	01	96 158 120	01-2221-30	10	97 599 211		21	79 03 001 126	01-2221-20	-
96 035 074	01-1241-2		96 080 792		05	96 159 009	01-1122-30	02		01-1210-40	15	79 03 001 427	01-1210-40	1
96 035 074	01-1241-1		96 080 792		111	96 160 145	01-1230-30			01-1210-20	!!	79 03 001 535	01-1123-10	ì
96 035 199	01-3351-2		96 080 793		10	96 160 146	01-1230-30	01		01-1210-30	111	79 03 001 603	01-1123-10	ı
96 035 199	01-3310-2	0 05	96 080 981		01		01-3357-10	05	97 599 241 97 599 251	01-3351-20	26	79 03 001 623		1
96 035 244	01-3351-2	0   18	96 081 724		l oi l	96 995 092	01-1145-10	70	SRV 000 017		22	79 03 001 657	01-3310-20	1
96 035 536	01-1145-1	0   08	96 084 261		02	96 995 797	01-1123-10	04	SRV 000 017		07	79 03 001 707		1
96 035 618	01-3330-1	0   27	96 086 334		04		01-3310-20	04	SRV 000 019		07		01-1147-20	1
	01-3357-1		96 088 592		08		01-3344-70	08	SRV 000 019		11	79 03 001 844		ì
	01-3351-2		96 089 138		06	97 500 132	01-3324-10	02	ZF 04 351 552		08	79 03 001 851	01-1230-40	1
	01-1120-20		96 092 841		09		01-3346-40	12	ZF 05 934 435		08	79 03 001 894		-
	01-1120-3		96 097 701		08		01-3346-40	09	00 42 790 300		12	79 03 001 894	01-2410-20	1
96 042 653	01-1147-20		96 097 702		10		01-3351-20	14	00 80 624 600		07	79 03 001 898	01-3314-10	1
96 042 811	01-3346-4		96 100 168		05		01-3324-10	02	00 80 624 600		27	79 03 001 920	01-1147-30	ı
96 042 956	01-2310-30		96 100 168		05	97 500 373	01-3324-10	01	00 81 508 500		14	79 03 005 026	01-2410-30	ŀ
96 042 956	01-2310-20		96 100 346		09		01-3430-40	01		01-0010-20	16 03	79 03 008 012	01-1230-40	
96 045 041	01-3331-10		96 100 415		24	97 500 651	01-3430-40	01		01-0010-20	03	79 03 009 002	01-3314-10	П
96 045 186	01-1440-10		96 111 595		OI	97 500 652		01		01-0010-30			01-1123-20	П
96 045 186	01-1440-20		95 117 376		05	97 504 694	01-3324-10	04		01-0010-30	02	79 03 009 256	01-1147-20	П
96 045 254	01-3331-10		96 124 795		10	97 504 707	01-1241-10	03		01-0010-20	02	79 03 009 256 79 03 009 256	01-1230-30	П
96 045 490	01-1140-40	26	96 124 994		08	97 504 707	01-1241-20	03		01-0010-40	02	79 03 009 256	01-1230-20	Į
96 045 640	01-1230-40		96 124 994		08	97 504 735	01-3324-10	03		01-11120-20	02	79 03 016 076	01-3358-20 01-1441-10	1
96 045 641	01-1230-40	0 01	96 124 994		08	97 504 923	01-3344-70	13		01-1120-20	02		01-1441-10	ŀ
96 049 753	01-3357-10		96 125 130	01-1145-11	05	97 505 109	01-3310-20	12		01-1120-30 01-1147-30A	05	79 03 016 150	01-1441-20	ı
	01-1440-20	0 03	96 127 435		10	97 511 466	01-3344-70	09		01-1147-20A	11		01-3358-20	П
96 050 712	01-1440-10	0   03	96 127 435	01-1140-30	10	97 511 920	01-3430-40	08		01-1147-20A	01		01-2410-30	П
96 051 895	01-1210-40		96 130 791	01-1140-30	12	97 511 946	01-3314-10	09		01-1147-30A	01		01-1122-30	1
96 052 662	01-1230-30		96 130 791	01-1140-20	12	97 512 501	01-3310-20	07		01-1147-30A	08		01-1121-10	1
96 052 662	01-1230-20		96 130 791	01-1140-40	12	97 512 714	01-3324-10	02		01-1147-30A	03		01-1123-10	П
96 054 608	01-1441-10		96 134 237	01-3300-10	01	97 517 580	01-3351-20	10		01-1147-30A	04		01-1230-20	1
96 054 867	01-1120-20		96 136 790		06		01-3310-20	06		01-1147-30A	02		01-1230-20	1
96 058 053	01-3351-20		96 146 748		05	97 518 121	01-3430-40	05	05 22 395 100		10		01-1120-30	1
96 058 681	01-1230-20		96 146 865	01-1147-20A	03		01-3324-10	04		01-2221-30	03		01-1120-20	1
96 058 681	01-1230-30		96 147 128	01-1147-20A	04	97 518 193		03		01-3430-40	06		01-1147-20	Ì
96 058 681	01-1230-40	0   14	96 148 071		10	97 518 408		12		01-1147-20A	31		01-1120-20	
96 059 593	01-1145-11		96 150 122	01-1210-30	14	97 518 408	01-1140-20	12		01-3314-10	05	79 03 027 282	01.1120.20	
96 059 593	01-1145-10	0.5	96 150 122	01-1210-20	14		01-1140-30	12		01-1147-20A	30	79 03 027 298	01.3214.10	+
96 059 996	01-3357-20		96 150 122		20		01-3351-20	21		01-1147-30A	06	79 03 027 312	01-3314-10	
96 060 896			96 150 127	01-1210-40	20		01-1230-20	01		01-1730-20	37	79 03 027 312	61.1122.10	'
96 060 935	JI-1230-30	2 01	96 150 127	01-1210-20	14		01-1241-30	, v3 ;		01-1230-30	37	\A 03 035 006		

30/01/98 GB B07 **1** 1235


PAGE 4


INDEX


NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	2405	_
79 03 032 017 79 03 032 036 79 03 032 109 79 03 032 109 79 03 032 109 79 03 033 009 79 03 034 004 79 03 034 004	01-1123-10 01-1120-20 01-1120-30 01-1230-30 01-1230-20 01-1215-30 01-1215-20 01-1215-10 01-3358-20 01-3358-10	21 18 18 38 38 08 05 05 05 21 13	79 03 057 003 79 03 057 003 79 03 057 003 79 03 057 005 79 03 057 013	01-3314-10 01-3310-20 01-3324-10 01-3324-10 01-1120-20 01-1120-30 01-1121-10 01-1123-10 01-1140-30 01-1145-10 01-1143-20	08 15 14 15 17 17 17 20 32 76	79 03 067 023 79 03 067 023 79 03 067 023 79 03 067 023 79 03 067 033 79 03 067 033 79 03 067 037 79 03 067 051 79 03 067 051 79 03 067 051 79 03 067 074	01-1140-30 01-1140-20 01-1140-40 01-1123-10 01-3314-10 01-3351-20 01-3351-20 01-1120-40 01-3351-20	21 21 19 22 01 24 25 09 07 20 23	79 03 201 020 79 03 201 020 79 03 201 021 79 03 201 021 79 03 201 021 79 03 201 021 79 03 201 023 79 03 201 039 79 03 201 039 79 03 201 048 79 03 201 052	01-1145-10 01-1123-20 01-2255-10 01-2255-20 01-2255-15 01-2221-30 01-2221-20 01-3324-10 01-1230-30 01-1230-20	72 10 12 10 14 13 10 12 32 32 09	94 00 117 790 94 00 606 990 94 02 209 318 94 02 214 118 94 02 221 178 94 02 221 320 94 02 326 30 94 02 336 60 94 02 336 600 94 02 332 040	01-1215-20 01-3330-10 01-3331-10 01-3330-10 01-3310-20 01-3324-10 01-3344-70 01-3346-40	F
79 03 034 070   79 03 040 029		20	79 03 057 013		10	79 03 067 104	01-3346-40	11	79 03 201 054		05	94 02 333 120 94 02 335 410		Ľ


j	79 03 032 109		30	79 03 057 005 0	1-1120-20	17	79 03 067 033	01-3314-10	01	79 03 201 021	01-2255-15	14	04.02.221.170	07-3337-10	09	Į
1			08	79 03 057 005 0	1-1120-30	17	79 03 067 037	01-3351-20	24	79 03 201 023	01-2221-20	13	94 02 221 178	01-3330-10	21	1
1	79 03 032 109		05	79 03 057 005 0	1-1121-10	17	79 03 067 038	01-3351-20	25	79 03 201 023	01-2221-30		94 02 221 320	01-3310-20	10	i
į	79 03 032 109	01-1215-10	05	79 03 057 005 0	1-1123-10	20	79 03 067 051		09	79 03 201 039	01-2221-20	10	94 02 228 108	01-3324-10	02	1
Ī	79 03 033 009	01-3358-20	21	79 03 057 005 0		32	79 03 067 051		07	79 03 201 039	01-3324-10	12	94 02 316 710	01-3344-70	01	ł
J	79 03 034 004	01-3357-20	13	79 03 057 013 0	1-1145-10	76	79 03 067 063			79 03 201 048	01-1230-30	32	94 02 323 660	01-3344-70	06	1
ı	79 03 034 004	01-3358-10	18	79 03 057 013 01	1 1122 20	12			20	79 03 201 048	01-1230-20	32	94 02 332 040	01-3346-40	03	Ì
ł	79 03 034 070		20	79 03 057 013 01	1-1123-20		79 03 067 074	01-3351-20	23	79 03 201 052	01-3357-10	09	94 02 333 120	01-3346-40	04	ı
ı	79 03 040 029	01-3344-70	10	79 03 057 013 01	1-114/-20	10	79 03 067 104		11	79 03 201 054		05	94 02 335 410	01-3344-70	03	ł
١	79 03 040 029	01-2246-40	10	79 03 057 013 01	1-2221-30	16	79 03 067 107	01-3358-20	04	79 03 201 140	01-2410-20	10	94 02 353 310	01-3346-40	07	I
ı	79 03 044 020	01-33-10-10	15	79 03 057 013 01	1-2255-10	13	79 03 067 116		10	79 03 201 140	01-2221-20	10	94 02 353 340	01-2246 40	06	ı
ļ	79 03 044 020	01-2410-20	16	79 03 057 013 01	1-2255-20	11	79 03 070 002		13	79 03 201 140	01-2221-30	13	94 02 519 450	01-3340-40		I
I	79 03 046 009	01-3358-20		79 03 057 013 01	1-2255-15	15	79 03 070 005	01-1230-40	12	79 03 201 140	01-1145-11	72	94 02 558 110	01-3331-20	02	Ì
ł			19	79 03 057 013 01	1-2221-20	13	79 03 070 005	01-1210-40	07	79 03 201 150	01-1121-10	15	94 02 570 370	01-3351-20	04	i
l	79 03 053 028		17	79 03 057 013 01	1-1121-10	16	79 03 070 005	01-1210-30	06	79 03 201 150	01-3357-20	09	94 02 570 570	01-3331-10	01	ł
۱	79 03 053 028	01-1122-20	05	79 03 057 019 01	1-3358-10	16	79 03 070 005		06	79 03 201 265	01-1145-20	70	94 02 570 570	01-3331-10	01	١
ı	79 03 053 043		11	79 03 057 021 01	1-1123-10	19	79 03 075 007	01-1121-10	01	79 03 201 265	01 2440 20		94 02 570 758		01	ł
	79 03 053 390	01-1120-30	16	79 03 057 044 01	1-1147-20	11	79 03 075 018	01-1121-10	02	79 03 201 272	01-2410-30	10	94 02 571 108	01-3330-10	28	ı
ì	79 03 053 390	01-1120-20	16	79 03 057 044 01	-1147-30 6	99	79 03 075 066	01-2221-20	09	79 03 201 747	01-1145-11	70	94 02 579 488	01-3331-10	12	ĺ
ļ	79 03 053 394	01-3357-10	12	79 03 057 100 01		33	79 03 075 066	01-2221-30				71	94 05 953 068	01-1440-10	05	ĺ
ł	79 03 053 425	01-3344-70	15	79 03 057 100 01	-1230-30	33	79 03 075 067	01-2221-20	08	79 03 201 747	01-3324-10	11	94 557 379 80	01-3300-30	01	ĺ
ł	79 03 053 425	01-3351-20	28	79 03 058 019 01	-1210-40	ia 1	79 03 075 067	01-1140-20	19	79 03 201 758		74	94 56 000 541	01-1210-30	03	ı
l	79 03 053 <b>4</b> 30	01-3430-40	12	79 03 058 028 01	1123-20	3	79 03 075 099	01-1140-30	19		01-1140-30	29	94 56 000 541	01-1210-20	03	ĺ
l	79 03 053 431	01-3430-40	12	79 03 058 028 01	-3257.20	10			20	79 03 201 781	01-3314-10	02	94 56 001 305	01-1241-10	09	ı
Į	79 03 053 432	01-3430-40	12	79 03 058 057 01	-1145 11	73		01-1140-20	20		01-3314-10	04	94 56 001 305	01-1241-20	09	Į
1	79 03 053 439		13	79 03 062 001 01-	1140 20	4		01-1140-40	18	79 03 233 002	01-1441-30	04	94 56 001 305	01-1241-30	09	ı
ŀ	79 03 053 442	01-3346-40	13	79 03 062 001 01		4	79 03 079 095		111	79 030 090 80	01-1147-30	08	94 56 001 306	01-1241-30	09	
l	79 03 053 443	01-3346-40	13			4	79 03 081 073	01-1441-10	07	79 030 090 80	01-1121-10	14	94 56 001 306	01-1241-20	09	
ı	79 03 053 444	01-3346-40	13	79 03 062 002 01		5	79 03 081 073		05	79 10 005 487	01-3358-10	12	94 56 001 306	01-1241-10	09	
	79 03 053 445	01-3346-40	13	79 03 062 002 01-	1140-30	5	79 03 081 073	01-1441-20	04	79 10 017 318		21	94 56 001 308	01-1241-10	10	
ı	79 03 053 446	01-3346-40	13	79 03 062 003 01-			79 03 085 044	01-2410-20	17	79 10 017 318	01-1140-30	23	94 56 001 308	01-1241-20	10	
ļ	79 03 053 481		35	79 03 062 003 01-	1140-20	3	79 03 087 095	01-3324-10	09	79 10 017 318	01-1140-20	23	94 56 001 308	01-1241-30	10	
ı	79 03 053 481		35	79 03 062 003 01-	1140-40 1	3	79 03 090 022	01-3351-20	15	79 10 019 504	01-1210-20	12	94 56 001 309	01-1241-30	10	
	79 03 053 508		15	79 03 062 003 01-		6	79 03 101 154	01-1120-20	14	79 10 019 504	01-1210-30	12	94 56 001 309	01-1241-20	10	
	79 03 053 514	01-1140-20	30	79 03 062 014 01-			79 03 101 154	01-1120-30	14	79 10 019 504	01-1210-40	17	94 56 001 309	01-1241-10	10	
	79 03 053 514	01-1140-30	29			0	79 03 101 307	01-3346-40	15	79 10 023 759	01-3358-10	111	94 56 001 419	01-1241-10	11	
	79 03 053 515		18	79 03 062 030   01-	-3310-20 1	3	79 03 101 392	01-1440-20	07	79 10 026 432	01-1140-20	25	94 56 001 419	01-1241-20	ii	
	79 03 056 003		77			9	79 03 101 392	01-1440-10	07	79 10 026 432	01-1140-30	25	94 56 001 419	01-1241-20	111	
	79 03 056 008		13		-2255-15 1		79 03 101 393	01-3358-10	13	79 10 026 432	01-1140-40	23	94 56 001 422	01-1241-20	12	
	79 03 056 054	01-2410-20	14	79 03 065 065 01-	-2255-20 0		79 03 101 403	01-3358-10	14	79 10 034 230	01-2255-10	10	94 56 001 422	01-1241-20	12	
	79 03 057 002	01-2410-30	14	79 03 065 065 01-			79 03 101 473	01-2410-20	09	79 10 034 230	01-2255-15	13	94 56 001 422	01-1241-10	12	
	79 03 057 002	01-2221-20	17	79 03 065 130 01-			79 03 101 767		12		01-1140-30	17	94 56 001 426	01-1215-10	02	
	79 03 057 003	01-2221-30	34	79 03 065 134 01-	3324-10 0			01-2221-30	15	79 32 584 061	01-1140-40	15		01-1215-20	02	
	79 03 057 003	01-1230-30	34	79 03 066 095 01-	3351-20 1			01-1140-30	27	79 32 584 061	01-1140-20	17		01-1215-30	02	
	79 03 057 003		29	79 03 066 124 01-			79 03 101 805		28	94 00 113 910	01-1210-40	02	94 560 033 80	01-1210-20	02	
	79 03 057 003		31	79 03 066 197 01-	3344-70 17			01-1140-20	27	94 00 113 910	01-1210-30	02	94 560 033 80	01-1210-40	02	
	79 03 057 003	01-1140-30	30	79 03 067 006 01-			79 03 201 010		16	94 00 113 910	01-1210-20	02	94 560 033 80	01-1210-20	02	
	79 03 057 003	01-1147-20		79 03 067 009 01-	1140-30 2		79 03 201 011		05	94 00 117 790	01-1210-20	03	04 560 051 90	01 1120 40	02	
	, 3 03 03/ 1/03 .	U1-/11-/-ZU	11	79 03 067 013 01-	1210-40   13	3 1	79 03 201 013	01-1441-10	J4 ,	94 00 117 790	01-1210-30	03	95 US 907 FXX	2358-10	02	
		1	'	;	ł	1	1	1		.1		- 1			Jz :	
														•	,	
											•					


1235 PAGE <b>5</b>							IN	DEX	(					
NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	RE
97 90 006 100 97 90 009 500 97 90 009 500 97 90 157 500	01-1215-30	02 02 01												

















1/01/98 GB C08 1 235 02 <b>1416</b> 20 AGE 3	30/06/98 DISTRIBUTION PIPE-THROTTLE CASING				19 TRI 19 TZI GTI	
15 0	70 71 72 73 74 75 76		232 017 RP 6932 032 036 RP 6932	38 0	3 DIAM 7X100	
	00 15					
	18 76 14 14 P					
71 74	5 70 13 12 12 72 72 72 72 72 72 72 72 72 72 72 72 72					
	8 (12756)					
	E141620	,				


90/01/98 GB C09 1 1235 02 <b>1416</b> 40	DISTRIBUTION PIPE-THROTTLE CASING			GTI 16V
PAGE 1	170 5	1	96 002 712 RP 0342 67	01 AIR DISTRIBUTOR 01
7 3		2	91 541 600	01 REINFORCEMENT
	200-0-0	3	96 035 470 RP 1635 41	01 AIR INTAKE CASE 01 WEBER-
19		4	96 015 940 RP 1628 G4	ON CONTACT SWITCH ON BOSCH 6280 120 327.
	10 10 10	5	91 539 050 RP 0348 G4	MANIFOL GASKET 02/A003 WITH ASBESTOS 01
• -			0348 G4	02 A005 WITHOUT ASBESTOS
		6	96 028 466 RP 1635 65	01 SEAL PIECE
G	2 12 3	7	95 640 976 RP 1621 68	01 ELECTRO-VALVE DIAM 8
	3 5 15	8	96 003 087 RP 1628 F0	01 ELECTRO VALVE 01
	102/921 E1416400	9	96 995 727 RP 1505 F3	01 DEPRESSION HOSE DIAM INT 7
		10	79 03 067 051 RP 6965 20	02 PIN 7X14 01
		11	79 03 027 028 RP 6929 52	02 STUD 8X125-58 01
		12	95 650 879 RP 1412 A1	01 PROTECTOR PLUG 01
		1:	79 03 085 043 RP 6980 30	01 STRAP DIAM 100 01
		14	79 03 009 081 RP 6913 H6	SOCKET SCREW 06 8X125-30 01
		1!	79 03 009 014 RP 6913 44	04 DIAM 8 X 1,25-35 01
	E141640	,		









30/01/98 GB C13 1 30/06/98 1235 02 1419 40 ACCELERATOR CONTROL	GTI 16V
5	1 95 596 207 01 -LEFT HAND DRIVE
	95 593 854 01 -RIGHT HAND DRIVE
	CONTROL CABLE  2 96 004 440 01 LON 965  RP 1629 E8 01 -LEFT HAND DRIVE UP TO 0 4676
	96 076 821 01 LON 1025 RP 95 656 496 01 -LEFT HAND DRIVE SINCE O 4677
2 2	96 010 113 01 LON 1180 RP 95 656 496 01 -RIGHT HAND DRIVE
((    `	3 5 472 019 01 PEDAL SPINDLE DIAM-9X1,25 LON 9,32
7'	4 96 032 945 01 RETAINR BRACKET RP 1664 A4 01
70	5 79 03 079 097 01 LINE BRACKET RP 4814 48 01
	6 79 03 073 103 01 GROMMET RP 1639 21 01
72	70 79 03 053 510 01 PLAIN WASHER 14,5X27,5-1,5 RP 6947 27 01
	71 79 03 066 995 01 ACLTR CABLE PIN
5	72 79 03 085 045 01 STRAP LON 245 RP 6980 28 01
[17,56] D1419170	
D1419170	








0/01/98 GB D15 1 1235 02 <b>1439</b> 30 PAGE 1	30/06/98 SINGLE POINT INJECTION BODY			SOLEX 16135001 16 TZI SINCE O	
and the same of th			1	6 128 703 01 RP 1920 J9 01	,
			2	5 643 991 O1 ENS SUP	
			1	5 644 481 01 ENS INF RP 1920 L7 01	
0		)		5 658 554 01 POTENTIOMETER RP 1920 0F 01	!
				5 644 027 01 HARNESS RP 1920 E6 01	<del>.</del>
·		58 7 6		5 644 484   01 REGULATOR MO RP 1920 N1 01 6 062 192   01 MANIFOL GASKE	
4				RP 1920 J2 01	'
		1			
5—					
	[02/92]	D143919A			
	1-41	J. 130.12	ŀ		
		E1439300	1		


30/01/98 GB D14   30/06/9 1235 02 <b>1710</b> 10 AIR FI		16 TZI
	(01/sed ) 02 1710 T	1 96 011 847 RP 1427 98 01 RP 1444 A4 01 3 96 059 366 01 FILTER ELEMENT RP 1210 04 01 5 75 491 922 02 CLIP H55 6 79 03 073 147 RP 1327 05 01 7 79 03 201 139 RP 6915 69 01  8 79 03 044 020 RP 6941 93 01 WP TO O 5284 92 528 222 RP 6941 71 01 SINCE O 5285
	E171010	

















0/01/98 GB D07 1 30/06/98 235 02 1724 11 MIXER-INLET AIR HEATING	16 TZI SINCE O 5285
AGE 1	1 96 006 109 01 INTAK AIR MIXER
	2 96 139 508 01 AIR INTAKE PIPE
	3 96 134 097 01 HOT AIR PIPE 55X62-500
	4 91 538 275 01 AIR JACKET RP 1425 L5 01
	5 SRV 000 023 01 ADJUST CLAMP DIAM 60 A 80 LARG 9 RP 6981 43 01
	6 96 085 941 01 STRAP LONG 426 RP 6980 32 01
	7 SRV 000 021 01 ADJUST COLLAR DIAM 20 A 60 LARG 9 RP 6981 41 01
	8 79 03 001 885 02 SELF-TAP SCREWS DIAM 7X100-12 01
[16/81] (16/761) (16/	
·	
E:724110	


0/01/98 GB D06 L 235 02 <b>1726</b> 10	30/06/98 ADDITIONAL AIR CIRCUIT				16 TZI UP TO O 5306
•		2 3 4 5	2 96 068 715 RP 16 96 07 1 96 073 227 RP 03 5 96 038 953 RP 14 6 96 073 224 RP 16 7 96 073 225 RP 16	01 027 46 01 0327 46 01 0441 01 045 55 01 048 74 01 048 74 01 048 75 01	UP TO O 5306  COMPENSATOR  ADDIT AIR HOSE  IDLE COMP.SUPPT  ELASTIC BRACKET 2 DIAM 6X1,00-13  RETAINING LUG
7	[63791] B1776	) 9	79 03 079 04 RP 698	45 02 <b>87 Q6</b> 01 <b>9</b> 02 <b>981 38</b> 01	CLIP  METALLIC CLAMP DIAM 20 A 35 LARG 9  NUT WITH BASE DIAM 6X1,00
		1	1 79 03 056 06	]	SPRING WASHER DIAM 6X18
	£1726				








001/98 GB D03 1 30/06/98 235 02 1810 10 EXHAUST PIPE	16 TZI
· · · · · · · · · · · · · · · · · · ·	1 96 099 454 RP 0341 94 01 EXH MANIFOLD 2 96 028 464 RP 0349 70 01 3 96 054 867 RP 0355 37 01 4 79 03 053 392 RP 6947 78 01 5 91 595 290 RP 0341 22 01  01 EXH MANIFOLD GASKET 01
[04728] D161011E	




















0/01/98 GB E06 1 30/06/98 235 02 2118 10 ASSY DISTRIBUTOR			V	AL	EO (ALLUM) DUCELLIER 2525655 16 TZI UP TO O 5284
AGE 1	7	1	97 535 800 RP 5900 G8	01 01	DISTRIBUTOR 1 VALEO (ALLUM)
<u>~ 1</u>	2	2		01	DISTRIBUTR HEAD
	3	3		01	DISTRIBUT WASHR
	4	4		01	H TENS LEAD SET
	5	5	79 03 001 708 RP 6915 36	02 01	CAPSCREW 7X100-20
	6	6		02	SPRING WASHER DIAM 6X14X1.4
2					
(p.7/50) D 21	1090				
	·				
	E2118100				


0/01/98 GB E07 1 30/06/98 235 02 2118 30 ASSY DISTRIBUTOR AGE 1	VALEO (ALLUM) DUCELLIER 2525709A GTI ESTATE 19 TRI ESTATE 19 TZI
D 2116 25	1 96 041 373
E211830	00










30/01/98 GB E11 ↑ 30/06 1235 02 <b>2120</b> 20 PAGE 1	798 ITION HARNESS-SPARK PLUG-COIL				SALOON 19 TRI 19 TZI SINCE O 4680
	[© 761] B2120150		2 3 4 5 6 7 8 9	RP 5970 35  97 534 955  RP 95 659 596  96 009 090  96 024 614  97 532 831  RP 5945 48  97 522 876  RP 5945 48  96 035 027  RP 5971 33  91 518 232  RP 5979 63  79 03 007 062  RP 6912 87  79 03 027 312  RP 0250 17  79 03 053 028  RP 6947 77	SPARK-PLUG O4 EYQUEM FC 52 LS O4 CHAMPION C9YCX  MODULE O1 BOSCH O1 O1 O1 O1 COIL BRACKET O1 CAPSCREW 4X0,70-20 O2 SCREW COLUMN DIAM 6X100-37 O1 O2 PLAIN WASHER 6X12-1,2 O1 O2 NUT WITH BASE DIAM 6X1,00
	E21:	20200			










30/01/98 GB E15 ↑ 30/06/98 CLUTCH	GTI 16V
	1 96 085 306 01 CLUTCH MECHANIM DIAM 215 RP 2004 A1 01 VALEO (EMBRAY)
A-B-E	CLUTCH PLATE  2 96 052 160 01 DIAM 215  RP 2055 F3 01 UP TO 0 4952
	96 098 305 01 DIAM 215 RP 2055 F3 01 VALEO (EMBRAY) SINCE O 4953 UP TO O 5532
,1	96 153 979 01 DIAM 215 RP 2055 F3 01 VALEO (EMBRAY) SINCE O 5533
3-	3 96 090 882 01 BEARING BUFFER RP 2041 60 01
7 7	4 94 02 115 150 01 FORK LEVER ENS RP 2115 25 01
	5 97 532 100 01 SUP RP 2175 21 01
C23/gill 02,3120,18	6 96 021 053 01 INF RP 2175 20 01
	7 96 000 971 01 HSG LOCKG PLATE RP 2107 A5 01
	8 79 03 101 393 03 CAPSCREW THRI 6X1,00-16
	9 97 599 241 06 SCREW CHC 7X1,00-22 RP 6913 98 01
	10 96 052 214 01 PIN DIAM 7 - 51 RP 2172 06 01
E3120400	









701/98 GB F12 30/06/98 235 02 5320 10 ALTERNATOR	MITSUBISHI
E 5320100	1 95 608 785 RP 5705 G7 O1 CLASSE 8 O1 MISUBISHI A 003 T0 34591 -16 TZI -SALOON 19 TZI -SALOON 19 TZI -ESTATE 19 TZI -ESTATE 19 TZI -ESTATE 19 TZI -ESTATE 19 TZI -GTI  95 599 763 O1 CLASSE 8 RP 5705 A0 O1 MISUBISHI A 003 T 03298 MITSUBISHI A 003 T 03298 MITSUBISHI A 003 T 03298 MITSUBISHI A 003 T 03291 MITSUBISHI A 003 T 03291 MITSUBISHI A 003 T 03291 MITSUBISHI A 003 T 03291 MITSUBISHI A 003 T 03291 MITSUBISHI A 003 T 03291 MITSUBISHI A 003 T 03291 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03291 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03291 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03291 MITSUBISHI A 003 T 03292 MITSUBISHI A 003 T 03291 MITSUBISHI A 003
E53201	









30/01/98 GB F08 ] 30/06/98 1235 02 <b>5325</b> 40 ALTERNATOR - COMPONENTS PAGE 1	MITSUBISHI A 003 T 03298
"MITSUBISHI" 4	1 94 05 725 908 RP 5725 CB 01 2 97 90 260 608 RP 5725 CB 01 3 94 05 725 888 NFP 4 95 656 572 RP 5727 36 01 5 94 05 724 888 RP 5724 88 01 RP 5724 88 01 ALTERNT BEARING ALTERNATE ROTOR ALTERNATE ROTOR MITSUBISHIP 6 94 05 720 678 RP 5720 67 7 94 05 744 968 01 ALTERNAT STATOR 7 94 05 744 968 01 ALTERNAT STATOR
13 11 10 11 11 11 11 11 11 11 11 11 11 11	NFP 8 94 05 733 698 01 TERMIN PART SET ENS RP 5733 69 01 9 94 05 744 428 01 RIGHT 10 94 05 744 438 01 LEFT RP 5744 43 01 11 94 05 761 608 01 ALTERN REGULATR RP 5761 60 01
[11/92] E5325400	12 94 05 728 458 01 ALT BRUSH SET  13 94 05 730 068 01 SPRING SET  14 94 05 746 418 NFP  15 95 616 724 01 ALTERNATOR FAN ENS  NFP MITSUBISHI*
E5325400	16 94 05 734 418 NFP 01 ALTERN ROD SET


30/01/98 GB F07 1 1235 02 <b>5330</b> 10 PAGE 1	30/06/98 STARTER			PARIS RHONE
*PARIS - RHONI		RP 5802 E4	01 -16 01 D6F 01 -16 01 -SA -SA -ES	RAB - D6RA18 TZI LOON 19 TRI LOON 19 TZI TATE 19 TRI TATE 19 TZI I
	E5330100			





0/01/98 GB F05 ↓ 235 02 <b>5331</b> 10 AGE 1	STARTER MOTOR SECURING		1,580∟	
		<del></del>	1 79 03 067 034 01 CENTRING PIN DIAM 14 LON 15 RP 6968 43 01	
	4	6	2 79 03 009 248 03 SOCKET SCREW CHC10X1,50-60 RP 6913 D0 01	
		(SMANNING D)	3 79 03 053 372 04 PLAIN WASHER 5x16-1,5 RP 6949 29 01	
		2	4 79 03 057 100 03 FLEXIBLE WASHER 10,4X21,3-0,8 RP 6962 11 01	
			5 79 03 032 006 RP 6933 08 01 HEXAGONAL NUT 5X80-4	
30 C				
5				
0	[01/90]	02 5331 1(		
	127.4	02 0001 K		
		E5331100		-


235 02 5331 20 STARTER MOTOR SECURING AGE 1	1,905L
233 02 333 20	1 91 505 539
E5331200	











02 ENGINE EQUIPEMENT			- BOSCH 0237009051 - SALOON 19 TRI - UP TO 08/89	2112-20	1-ED
IR INTAKE THROTTLE VALV HOUSG	<del></del>	т	- BOSCH 0237009074 - SALOON 19 TRI SALOON 19 TZI	2112-21	1-E0
- 16 TZI - UP TO O 5284	1410-10		- SINCE 09/89 - DUCELLIER 2525678 - SALOON 19 TRI SALOON 19 TZI	2112-30	1-E0:
- 16 TZI - SINCE O 5285		1-C02	#[	2112-30	/
	1410-11	1-C04	ASSY DISTRIBUTOR		ļ
ISTRIBUTION PIPE-THROTTLE CASING			- VALEO (ALLUM) DUCELLIER 2525655 - 16 TZI - UP TO O 5284	2118-10	1-E0
- 19 TRI 19 TZI GTI	1416-20	1-C06	- VALEO (ALLUM) DUCELLIER 2525709A - GTI ESTATE 19 TRI ESTATE	2118-30	1-E0
- GTI 16V	1416-40	1-009	19 121	4	i
COTI PRATOR COMMO	1		- VALEO (ALLUM) DUCELLIER 2525628 - GTI 16V	2118-40	1-E0
CCELERATOR CONTROL	1	1	IGNITION HARNESS-SPARK PLUG-COIL	i	l .
- 16 TZI	1419-20	1-C11	- 16 TZI - UP TO O 5284	2120-10	1-E0
- 19 TRI 19 TZI GTI	1419-30	1-C12	- 16 TZI - SINCE O 5285	2120-11	1-E1
- GTI 16V	1419-40	1-C13	- SALOON 19 TRI 19 TZI - SINCE O 4680	2120-20	1-E1
NGLE POINT INJECTION BODY	i	1	- GTI ESTATE 19 TRI ESTATE 19 TZI - UP TO O 4983	2120-30	1-E1
SOLEX 16001 PSA 487 - 16 TZI - UP TO O 5225	1439-20	I-C14	- GTI ESTATE 19 TZI - SINCE O 4984	2120-31	1-E1
SOLEX 16068 PSA 564 - 16 TZI - SINCE O 5226 UP TO O 5306	1439-25	1-C15	· GTI 16V	2120-40	1-E1
SOLEX 16135001 PSA 579 - 18 TZI - SINCE O 5307	1439-30	1-D15		2720-40	'
	1	1-013	CLUTCH		l
R FILTER			- Gπ 16V	3120-40	1-E1
· 16 TZI	1710-10	I-D14	AUTOMATIC CLUTCH		1
R FILTER AND DUCTS	l .		- 16 TZI - UP TO O 5306	3220-10	1-F1
19 TRI 19 TZI GTI	1711-20	1-D13	- 16 TZI - SINCE O 5307	3220-10	1-F1
GTI 16V	1711-40	1-D13	- 19 TRI 19 TZI GTI	3220-11	1-F1
	1711-40	1-012	10 114 10 121 011	3220-20	1 -F1.
R FILTER-INJECTION BODY UNION	}		ALTERNATOR	i	1
18 TZI - UP TO O 5284	1716-10	1-D10	- MITSUBISHI	5320-10	1-F12
R FILTER-CARBURATTOR UNION	1		ALTERNATOR - BELT FASTENING		
16 TZI - SINCE O 5285	1716-11		- 16 TZI 19 TRI 19 TZI GTI		١
10 121 · SINCE O 3285	11,10-11	1-009	- 10 121 19 181 19 121 GH	5324-20	1-F1
XER-INLET AIR HEATING	1 1		- 611 100	5324-30	1-F10
16 TZI - UP TO O 5284	1724-10	1-D08	ALTERNATOR - COMPONENTS		
16 TZI - SINCE O 5285	1724-11	1-D07	- MITSUBISHI A 003 T 03291	5325-20	1-F09
DITIONAL AIR CIRCUIT			- MITSUBISHI A 003 T 03298	5325-40	1-F08
DITIONAL AIR CIRCUIT			STARTER		
16 TZI - UP TO O 5306	1726-10	1-D06			4.50
19 TRI 19 TZI GTI	1726-20	1-D05		5330-10	1-F07
GTI 16V	1726-30	1-D04	- BOSCH	5330-20	1-F06
HAUST PIPE		1	STARTER MOTOR SECURING		
16 TZI	1810-10	1-003	· · · · · · · · · · · · · · · · · · ·	5331-10	1-F05
19 TRI 19 TZI GTI	1810-20	1-D02	- 1,905L	5331-20	1-F04
GTI 16V	1810-30	1-D01			

30/01/36 GG GG I	30/06/98		
1235 PAGE 2	02 ENGINE EQUIPEM	ENT	
		<del></del>	
STARTER - DETAILS - PARIS RHONE D 6 RA 8		5332-20	1-F03
- PARIS RHONE D 6 RA 18		5332-21	1-F02
- BOSCH 0001208516		5332-30 5332-40	1-F01 1-G02
- PARIS RHONE D9E48		5332-40	1-G02
			[
			l
			ļ
		i i	

GE 1	l l						IN	DEX					
NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE
	02-1419-40	03	91 541 738	02-1711-20	04	95 599 763	02-5320-10	01	95 636 700	02-1711-40	05	96 009 090	02-2120-10
	02-1419-20 02-1419-30	02	91 541 738	02-1711-40	04	95 602 185	02-2112-20	04	95 636 923	02-1711-40	06	96 009 090	02-2120-31
25 223 019		74	91 541 740 91 541 839	02-1726-20	10	95 602 185	02-2112-21	04	95 638 397	02-1711-20	06	96 009 090	02-2120-20
	02-1716-10	06	91 595 090	02-1810-30 02-1810-20	10	95 602 188	02-2112-20	13	95 638 660	02-1726-30	03	96 009 090	02-2120-11
26 162 899	02-1416-20	70	91 595 090	02-1416-20	15	95 602 188	02-2112-21	12	95 638 661	02-1726-30	05	96 009 090	02-2120-30
	02-1710-10	05	91 595 090	02-1410-10	177	95 602 227 95 602 227	02-3220-20	05	95 638 876	02-1419-30	02	96 010 113	02-1419-40
	02-5332-40	05	91 595 290	02-1810-20	05	95 602 227 95 602 227	02-3220-11	05	95 640 497	02-1410-11	03	96 011 124	02-5324-30
	02-1716-10	l oi l	91 595 290	02-1810-10	05	95 604 818	02-3220-10	02	95 640 976 95 643 991	02-1416-40	07	96 011 847	02-1710-10
91 005 281	02-1716-10	02	91 595 290	02-1810-30	05	95 604 818	02-3220-10	02	95 643 991 95 643 991	02-1439-25	02	96 013 114	02-2120-10
91 505 539	02-5331-20	01	92 528 222	02-1710-10	08	95 604 818	02-3220-20	02	95 643 991 95 643 991	02-1439-30	02	96 014 184	02-5330-10
91 508 644	02-5330-10	02	95 011 190	02-3220-20	04	95 608 785	02-5320-10	01	95 644 026	02-1439-20 02-1439-20	02	96 014 241	02-5324-30
91 508 644	02-5330-20	l or l		02-3220-11	04	95 611 814	02-2120-31	06	95 644 027	02-1439-20	03	96 015 940	02-1416-20
91 510 845	02-5324-20	04		02-3220-10	04	95 611 814	02-2120-30	06	95 644 027	02-1439-20		96 015 940	02-1416-40
	02-5324-30	05		02-3220-10	06	95 611 814	02-2120-10	05	95 644 027	02-1439-25	05	96 015 959	02-1711-20
91 512 913		05		02-3220-11	06	95 616 038	02-3220-11	l oi l	95 644 481	02-1439-30	03	96 018 889 96 021 053	02-1416-20
91 512 913	02-1419-30	08		02-3220-20	06	95 616 038	02-3220-10	l or l	95 644 483	02-1439-25	03	96 023 978	02-3120-40 02-1716-11
91 514 613	02-1410-10	07	95 572 896	02-5332-30	04	95 616 724	02-5325-40	15	95 644 484	02-1439-30	06	96 024 614	02-2120-10
91 514 613	02-1410-11	08	95 572 905	02-5332-30	15	95 616 841	02-5332-30	1 13	95 650 879	02-1416-40	12	96 024 614	02-2120-10
91 516 814	02-1416-20	06	95 572 915	02-5332-30	08	95 618 183	02-5332-40	l og l	95 651 019		03	96 024 614	02-2120-30
91 516 978	02-1416-20	13		02-5324-20	02	95 618 194	02-5332-40	07	95 651 019	02-2118-30	03	96 024 614	02-2120-11
91 516 979	02-1416-20	14	95 586 679	02-2120-40	05	95 618 200	02-5332-40	04	95 651 019	02-2112-30	03	96 024 614	02-2120-20
91 516 981	02-1416-20	12	95 586 920	02-2120-40	06	95 618 207	02-5332-40	06	95 653 086	02-3220-20	01	96 026 983	02-1439-20
	02-1711-40	09	95 589 939	02-5332-40	02	95 618 396	02-2112-30	02		02-2112-30	04	96 028 464	02-1435-20
91 517 208	02-1711-20	08	95 589 941	02-5332-30	03	95 618 397	02-2112-30	06	95 656 572	02-5325-40	04	96 028 464	02-1810-20
	02-2120-20	06	95 589 942	02-5332-30	01	95 618 786	02-1710-10	02	95 658 554	02-1439-30	04	96 028 466	02-1416-40
	02-1419-30	06	95 589 943	02-5332-30	05	95 618 786	02-1711-20	02	95 658 554	02-1439-25	04	96 032 945	02-1419-40
	02-1724-10	04	95 589 944	02-5332-30	06	95 618 786	02-1711-40	02	95 659 459	02-2112-21	02	96 035 027	02-2120-31
	02-1810-20	01	95 589 945	02-5332-30	07	95 618 794	02-2112-20	111	95 659 459	02-2112-20	02	96 035 027	02-2120-30
91 535 633		01	95 589 946	02-5332-30	09	95 618 795	02-2112-20	06	95 661 856	02-1416-20	111	96 035 027	02-2120-20
	02-2120-20	01	95 589 947	02-5332-30	111	95 618 796	02-2112-20	07	96 000 783	02-5324-30	03	96 035 354	02-1416-20
	02-1726-20	10	95 589 948	02-5332-30	12	95 619 492	02-2112-21	06	96 000 795	02-5324-30	04	96 035 354	02-1410-11
	02-5324-20	01		02-5332-30	10	95 619 493	02-2112-21	07	96 000 971	02-3220-20	07	96 035 354	02-1410-10
	02-1711-20	01		02-5332-30	14	95 619 498	02-2112-21	08	96 000 971	02-3120-40	07	96 035 470	02-1416-40
	02-1711-40	01	95 589 951	02-5332-30	19	95 623 754	02-2120-10	09	96 002 516	02-1810-30	03	96 037 048	02-2120-30
	02-1711-40	08		02-5332-30	16	95 623 754	02-1726-10	10		02-1416-40	01	96 038 183	02-2118-40
91 536 808	02-1711-40	10	95 589 953	02-5332-30	17	95 623 754	02-1716-11	05		02-1416-40	08	96 038 185	02-2118-40
91 538 083	02-1711-40	07		02-5332-30	02	95 623 754	02-2120-20	10	96 003 087	02-1416-20	10	96 038 953	02-1726-10
91 538 083	02-1711-20	07		02-5324-20	03	95 623 754	02-2120-11	07	96 003 907	02-1410-11	09	96 039 962	02-2120-40
91 538 218		02		02-1419-30	01	95 623 754	02-2120-30	10	96 003 907	02-1410-10	08	96 040 166	02-3220-20
	02-1724-11	04		02-1419-40	01	95 623 754	02-2120-31	15	96 004 440	02-1419-40	02	96 040 762	02-5331-20
	02-1711-20	04		02-1419-20	01	95 623 758	02-1711-40	16	96 005 611	02-1726-30	02	96 040 824	02-2120-11
	02-2118-40	02		02-1419-20	01	95 623 758	02-1711-20	14	96 005 700	02-1410-10	12	96 041 373	02-2118-30
	02-1416-40	05		02-1419-40	01	95 624 501	02-3220-20	01	96 005 934	02-1724-10	02	96 041 737	02-1710-10
	02-1416-20	01		02-1419-30	01	95 624 952	02-2112-30	05		02-1724-10	01	96 041 879	02-3220-20
	02-1726-30	04		02-3220-20	10	95 62 <b>4</b> 985	02-2118-30	02		02-1724-11	01	96 041 879	02-3220-11
	02-1726-30	01		02-3220-11	17	95 624 985	02-2118-10	02	96 006 110	02-1716-11	03	96 041 879	02-3220-10
91 541 557	02-1419-30	05		02-3220-10	10	95 632 508	02-1726-20	03		02-1716-10	03	96 042 439	02-2118-30
	02-1726-30	08		102-3220-10	08	95 632 509	02-1726-20	02		02-1410-11	05	96 043 570	02-1416-20
	02-1416-40	02	95 599 406	02-3220-11	1 os 1	95 633 026	02-1726-30	07	96 007 707	02-1410-10	04	96 044 923	02-1724-10

30/06/98 30/01/98 GB B05 T 1235 **INDEX** PAGE 2 NUMERO PAGE REP NUMERO PAGE NUMERO DEP PAGE REP NUMERO PAGE REP NUMERO PAGE REP 96 049 353 02-1410-10 79 03 083 271 02-1711-20
79 03 083 271 02-1711-20
79 03 085 045 02-1416-40
79 03 085 045 02-1416-40
79 03 101 795 02-1416-20
79 03 101 756 02-1416-20
79 03 201 002 02-1416-20
79 03 201 002 02-1416-20
79 03 201 020 02-1220-40
79 03 201 020 02-1218-40
79 03 201 020 02-1218-40
79 03 201 032 02-2120-40
79 03 201 139 02-1711-20
79 03 201 139 02-1711-10
79 03 201 139 02-1711-10
79 03 201 140 02-1410-11
79 03 201 140 02-1410-10
79 03 201 140 02-1410-10
79 03 201 271 02-2120-11
79 03 201 271 02-2120-11
79 03 201 272 02-5324-30
79 03 201 747 02-3220-11
79 03 201 757 02-1410-11
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 23 07 77
79 03 233 07 70
72-1410-10
79 03 233 07 14 02-1410-10
79 03 233 07 14 02-1410-10
79 03 233 07 14 02-1410-10
79 03 233 07 17
79 17 18 18 1555 02-1410-11 96 111 900 02-1726-20 74 01 266 026 02-1416-20 79 03 053 372 02-5331-20 03 96 123 906 02-2120-40 96 127 996 02-1439-25 96 127 996 02-1439-30 96 134 097 02-1724-11 96 138 508 02-1724-11 74 01 266 026 02-1416-20 77 03 032 095 02-1416-30 78 10 177 000 02-1416-10 78 10 177 000 02-1416-10 79 03 001 708 02-2118-10 79 03 001 708 02-2118-30 79 03 001 885 02-1724-11 79 03 001 885 02-1724-11 79 03 007 062 02-2120-31 79 03 007 062 02-2120-31 79 03 083 271 96 052 160 02-3120-40 96 052 214 02-3120-40 96 053 199 02-1439-20 79 03 053 372 02-5331-10 79 03 053 392 02-5324-30 79 03 053 392 02-1810-30 79 03 053 392 02-1810-10 96 134 973 | 02-17493-30 | 186 138 508 | 02-1724-11 | 96 138 508 | 02-1724-11 | 96 138 508 | 02-1724-11 | 96 138 508 | 02-1724-11 | 96 138 509 | 02-3120-40 | 96 995 479 | 02-3120-10 | 97 500 379 | 02-3220-11 | 97 500 379 | 02-3220-10 | 97 530 780 | 02-2120-20 | 97 531 206 | 02-2120-40 | 97 532 631 | 02-2120-40 | 97 532 631 | 02-2120-40 | 97 532 631 | 02-2120-20 | 97 532 631 | 02-2120-20 | 97 533 794 | 02-2120-20 | 97 533 794 | 02-2120-20 | 97 533 794 | 02-2120-20 | 97 533 794 | 02-2120-20 | 97 533 794 | 02-2120-20 | 97 533 794 | 02-2120-20 | 97 533 794 | 02-2120-20 | 97 535 465 | 02-2120-20 | 97 535 465 | 02-2120-20 | 97 535 904 | 02-2120-20 | 97 535 904 | 02-2120-20 | 97 535 904 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-2120-20 | 02-90 054 475 02-3220-10 90 054 475 02-3220-11 79 03 053 392 | 02-1810-10 79 03 053 392 | 02-1810-20 79 03 053 510 | 02-1419-30 79 03 053 510 | 02-1419-40 79 03 055 510 | 02-1419-40 79 03 056 064 | 02-1726-10 79 03 057 003 | 02-1416-20 79 03 057 003 | 02-1416-20 96 054 475 | 02-3220-20 96 054 867 | 02-1410-11 96 054 867 | 02-1810-20 96 054 867 02-1810-10 96 059 366 02-1710-10 96 059 368 02-1711-20 79 03 007 062 02-2120-31 79 03 007 062 02-2120-30 79 03 007 062 02-2120-20 96 059 368 02-1711-40 96 061 366 02-1418-20 96 062 192 02-1439-30 79 03 057 003 02-1416-20 79 03 057 005 02-1410-10 79 03 057 005 02-1410-10 79 03 057 005 02-1419-30 79 03 055 006 02-2118-30 79 03 058 028 02-2118-30 79 03 058 028 02-2118-30 79 03 058 028 02-2118-30 79 03 058 028 02-2118-30 79 03 058 028 02-1716-10 79 03 058 030 02-1410-10 79 03 058 030 02-1410-10 79 03 058 030 02-1410-10 79 03 058 030 02-1410-20 79 03 055 016 02-2112-21 79 03 055 016 02-2112-21 79 03 056 016 02-2112-21 79 03 056 016 02-2112-21 79 03 058 016 02-2112-21 79 03 058 016 02-2112-20 79 03 058 016 02-2112 79 03 009 001 02-1416-40 79 03 009 014 02-1416-40 79 03 009 081 02-1416-40 96 062 192 02-1439-25 96 064 614 02-1439-20 79 03 009 081 02-1416-40
79 03 009 248 02-5331-20
79 03 027 006 02-2112-30
79 03 027 006 02-2112-20
79 03 027 006 02-2112-20
79 03 027 028 02-120-31
79 03 027 312 02-2120-31
79 03 027 312 02-2120-31
79 03 027 312 02-2120-31
79 03 027 312 02-2120-31
79 03 027 312 02-2120-31
79 03 027 06 02-5331-20
79 03 023 036 02-5331-20
79 03 023 036 02-5331-20
79 03 033 005 02-2112-30
79 03 037 050 02-2112-30
79 03 037 050 02-2112-30
79 03 037 070 02-2112-30 03 02 77 70 11 08 12 08 06 05 70 71 71 18 73 17 19 72 19 09 09 16 09 09 16 09 09 97 535 465 | 02-2120-40 | 97 539 580 | 02-2118-10 | 97 599 140 | 02-1726-20 | 97 599 241 | 02-3120-40 | SRV 000 017 | 02-1726-30 | SRV 000 019 | 02-1726-30 | SRV 000 021 | 02-1724-10 | SRV 000 021 | 02-1724-10 | SRV 000 023 | 02-1724-10 | SRV 000 023 | 02-1724-10 | SRV 000 024 | 02-1711-40 | SRV 000 024 | 02-1711-40 | SRV 000 024 | 02-1711-40 | SRV 000 024 | 02-1711-40 | O361 79 | 02-1416-20 | 0361 79 | 02-1416-20 | 0365 77 | 02-1416-20 | 1925 31 | 1925 31 | 1925 31 | 02-1711-20 | 5962 S0 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-2120-31 | 02-79 03 233 014 | 02-1410-10 79 03 233 014 | 02-1410-11 79 10 011 595 | 02-1410-11 79 10 011 595 | 02-1410-20 79 10 027 593 | 02-1416-20 79 10 032 930 | 02-2118-30 79 10 032 930 | 02-2118-30 79 03 037 005 02-2112-30 79 03 037 005 02-2112-30 79 03 037 005 02-2112-21 79 03 037 010 02-5324-30 79 03 044 020 02-1711-40 79 03 044 020 02-1711-40 79 03 044 050 02-1410-10 79 03 053 012 02-5224-30 79 03 053 028 02-2120-30 79 03 053 028 02-2120-30 79 03 053 039 02-2120-20 79 03 053 039 02-1416-20 79 03 053 039 02-1416-20 79 03 053 039 02-21416-20 96 084 499 02-2120-11 96 084 912 02-1419-20 96 085 306 02-3120-40 96 085 941 02-1716-11 96 085 941 02-1724-11 96 088 268 02-1410-11 79 10 032 930 02-2118-30 79 10 032 930 02-2112-30 79 10 032 930 02-2112-20 79 10 032 930 02-2112-20 79 10 032 930 02-2112-20 94 05 726 678 02-2120-40 94 05 720 678 02-5325-40 94 05 724 888 02-5325-40 94 05 725 988 02-5325-40 94 05 725 988 02-5325-40 94 05 725 988 02-5325-40 94 05 727 968 02-5325-20 94 05 727 368 02-5325-20 94 05 728 458 02-5325-20 94 05 728 458 02-5325-20 94 05 728 458 02-5325-20 79 03 073 103 02-1419-30 79 03 073 147 02-1711-40 79 03 073 147 02-1711-20 79 03 073 147 02-1710-10 96 088 269 02-1410-11 96 088 270 02-1716-11 96 089 220 02-2120-11 96 090 882 02-3120-40 96 092 693 02-1410-10 96 098 305 02-3120-40 96 099 454 02-1810-10 79 03 075 007 02-1710-10 79 03 075 018 02-1410-11 79 03 075 018 02-1410-11 79 03 079 004 02-1410-11 79 03 079 007 02-1419-30 79 03 079 018 02-1726-20 79 03 079 045 02-1726-10 96 099 454 02-1810-20 96 099 833 02-1410-11 96 099 923 02-1410-11 01 01 02 06 02 79 03 053 039 02-5331-20 79 03 053 041 02-5324-20 79 03 053 046 02-2120-10


79 03 079 097 | 02-1720-10 79 03 083 208 | 02-1711-20 79 03 083 208 | 02-1711-40


94 05 728 458


30/01/98 GB 1235	1	0/06/98							,					
PAGE 3	[						II.	IDEX						
NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP
94 05 730 068	02-5325-40	13			1		<del> </del>	<del>-                                    </del>		<del></del>			1772	1
94 05 730 068		12		i .			1	1 1		ŀ	1 1		1	
	02-5325-20	07		]	1 1		1	1 1		l l	1 1		1	- 1
	02-5325-40	08		1	1 1		1	1 1		1	1 1		l	1
94 05 734 418 94 05 744 428	02-5325-40	16		1			ļ			1	1 1			
94 05 744 428	02-0320-40	09		ł			1	1 1		1	1 1		i	1
94 05 744 438	02-3323-20	08		1	1 1		ì	1 1		1	1 1		1	1
94 05 744 438	02-5325-20	10		ĺ	1 1		1	1 1		1	1 1		1	1
	02-5325-40	07		ļ	1 1		1	1 1			1 1			1
94 05 744 968		06			1 1		ſ				1 1			
94 05 746 418	02-5325-20			1	1 1		1	1 1		1	1 1		ŀ	1
94 05 761 608		111					I	1 1		1	1.1		ł	
94 05 761 608		10		1	1 1			1 1		1				1
94 05 807 228		l or l			1 1		l	1 1		ŀ	1 1		,	ł
94 05 816 118	02-5332-40	09			1 1		1	1 1		1	1 1		İ	1
94 05 817 018		01					1	1 1			1 1		Į.	1
94 05 817 028		07			1 1		[	1 1		1	11		l	i
94 05 827 818	02-5332-20	06			I i		i	1 1		1	1 1			1
94 05 827 818	02-5332-21	06			1 1			1 1			1 !		i	
	02-5332-20	05			1 1		1	1 1		1	1 1		1	1
	02-5332-21	05			1		ŀ	1 1		1	1 1		l	1
	02-5332-30	18			1 1		1	1 1		1	1 1		1	1
	02-5332-40	03			1 1		l	1 !		1	1 1		i	1
	02-5332-20	03	i		1 1		1				1 1		l	1
	02-5332-20	02			1 1			1 1		l .	l 1			
	02-5332-21	02								1	!!		İ	
	02-5332-21	04	- 1		1 1			1 1		1	1			1
94 05 855 778	02-5332-20	04	1		1					i			i	ì
	02-2112-21	09			1			1		1	1 1			1
	02-2112-20	09			1 1			1 1		i			l	i
	02-2112-20	10			1 1						1 1			1
94 05 911 328 (	02-2112-20	08	1		1 1					i	[		Í	
94 05 926 088 (	02-2112-20	14	1		1 1			]					ł	1
	02-2112-21	13	J								1			1
	02-2112-21	05	1					1 1						1
	02-2112-20	05	1			į		1 1		1				1
	02-2118-10	04	ĺ			ĺ		1 1		1				1
	02-2118-30	04	1		1 1			1 1		]				i
	02-2112-21	03	Í					1 1		j l				1
	02-2112-20	03	ļ		1	1		1 1		<b>i</b>	- 1			1
	02-2112-20	12	i		1	j		1 1		1	- 1		-	1
	02-2112-21	11	1			ł		I I			- 1			1
	02-2112-21	10	J			1		1 1			- !			1
	02-2112-20	16	1			1		1 1						1
	2-2112-21	15			1	ŀ		1						j
	2-2112-30	08	1			ļ						1		i i
	02-5325-40	.02			L			l						l
	2-5325-20	02									$\neg \tau$			1
97 90 260 708 0	02-5332-21	03						!			- 1			1
Ī		-	f		1 1						ļ			
4	- 1	- 1	- 1		l i	i		1 1		: I		:		1


79 03 053 087 02-1416-40 79 03 053 122 02-5324-20


96 102 312 02-2120-11 96 111 899 02-1726-20



















































30/01/98 GB D11 \$\frac{1}{1235} 03 <b>3945</b> 10 PAGE 1	1ST PART
PAGE I	LINE BRACKET 1 5 444 869 01 4T 4 TROU 6.5
	2 95 499 060 02 ST 3,5A4,5 TROU 7,8 -WITH ABS BRAKES
3 4 5 6	3 79 03 079 110 02 1T 3
12	4 79 03 079 111 01 1T 4
	5 79 03 079 173 02 1 DIAM RP 96 995 726 01
7 8 9 10 11	6 26 199 449 05 1T 3,5 TROU 6,5
	7 95 499 139 02 2T 3,5A4,5 TROU 6,5
	8 79 03 079 109 02 4 DIAM NFP
13 14 15 16 17	9 79 03 079 126 01 2T 8-1T 3,5 TROU 6,5
	10 79 03 079 175 10 4 DIAM
Project Con Con Contract Contr	11 95 499 137 99 -WITH ABS BRAKES
	12 95 499 136 99 -WITH ABS BRAKES
	13 79 03 079 192 05 3T 8-4-10 TROU 6,5
	14 26 199 569 01 1T 9 TROU6,5
	15 79 03 079 108 01 CONNECT BRACKET RP 95 499 140 01
23   24   25   26   27   28   602/92   €3945100	16 95 499 140 02 LINE BRACKET 2T 3,2 -WITH ABS BRAKES
	17 79 03 079 098 02 CONNECT BRACKET
	18 79 03 079 099 01 LINE BRACKET 1T 13-1T 10
	19 79 03 079 093 01 CLIP 2 DIAM RP 6994 71 01 + 6994 72 01
	LINE BRACKET
E3945100	20 96 995 893 01 2T 14A16-1T 18A20/


30/01/98 GB D10 ] 30/06/98 1235 03 <b>3945</b> 10 PAGE 2	1ST PART
PAGE 2  1	21 26 199 999 RP 6995 J9 01 22 95 499 138 04 2T 3,5A4,8 -WITH ABS BRAKES  CLIP RP 6987 91 11 24 79 03 079 018 RP 6987 91 10 25 79 03 079 134 RP 96 118 503 01 95 499 148 RP 96 118 503 01 95 499 196 25 79 03 079 163 PF 96 118 504 01 JIAM RP 96 118 504 01 WITH ABS BRAKES  25 79 03 079 163 PF 96 118 504 01 JIAM RP 96 118 504 01 WITH ABS BRAKES  26 95 499 196 05 1 DIAM -WITH ABS BRAKES  27 96 995 040 01 6T 6,3 LONG 102,5 -GTI 167 -GTI 167 -WITH ABS BRAKES  28 96 995 784 01 3T 3,5-3T 4,5 -WITH ABS BRAKES
	E3945100


30/01/98 GB D09 1 30/06/98 1235 03 <b>3945</b> 11 PAGE 1 PIPING BRACKETS	2ND PART
	2ND PART  1 96 995 493
E3545110	





30/01/98 GB D07 1 1235 03 <b>3946</b> 11	30/06/98 PIPING-PLATE-BRACKET				2ND PART
PAGE 1			1 2 3	26 197 999	99 CLIP 1T 5,5 PINC E2,5 99 HARNESS CLIP 1T 9,4PINCE E0,2A0,5 99 CLIP 01
	তিহ/ছা	03948110			
		E39:46110			


30/01/98 GB D06 1 30/06/98 PIPING-SHEATH-COLLAR PAGE 1	
55 0−18 57 0−18	1 79 03 083 250 99 LONG 580 LARG 5 01
	2 SRV 000 017 01 DIAM 16 A 27 LARG 9 01
	3 26 141 629 01 LONG 151,5 LARG 8 UP TO 0 5650
	96 162 039 01 LONG 180 LARG 8 SINCE O 5651
	4 26 141 639 NFP 02 LON 100
	5 79 03 085 044 01 LON 200 LARG 4,6 RP 6547 08 01
	6 79 03 085 045 02 LON 245 01
10 15 3	7 SRV 000 015 01 ADJUST CLAMP DIAM 8 A 16 LARG 8 01 01 01 01 01 01 01 01 01 01 01 01 01
152411 03241100	8 26 189 549 08 PIPE SLEEVE DIAM INT 3,5 RP 4828 06 01
	96 061 612 99 OUTER SLEEVE DIAM 3,5 A 5-160 9 21 073 009 NED 02 RUBBER GROMMET DIAM 8
	NFP   TUBE RING   10   26 208 089 01 19X23X15
	11 26 208 159 01 8,5X12,5-15
	12 <b>26 208 169</b> 01 17X21-45
	13 75 413 089 03 DIAM 4,5X13
	14 5 411 956 02 PROTECT SLEEVE DIAM 4X9 L = 15
E3547100	

















30/01/98 GB E02 1 30/06/98  1235 03 <b>4162</b> 20 WHEEL CAPS PAGE 1	SINCE 0 4741
	1 96 039 221 04 DIAM 390 -SALOON 19 TZI -ESTATE 19 TZI -SALOON 16 TZI
	2 96 039 223 04 DIAM 390 -ESTATE 19 TZI -GTI
(01/92) E4162200	
E4162200	


0/01/98 GB E03	30/06/98					
235 03 4163 20	"LIGHT ALLOY" WHEEL					
AGE 1			1	96 084 709	04	ALLOY WHEEL 5 50JX14 CH 4 18 -EXCEPT GTI 16V
				96 085 499	04	6JX14 CH 4 15 -GTI 16V
			2	95 591 953	16	MONTING SCREW DIAM 12X1,25
			3	95 602 717 ZN		WHEEL CAP DIAM 65 -1,905L
			4	5 458 682 RP 5404 01		ASSEMBLY VALVE
			5	75 491 339 RP 5404 02	05 01	VALVE PLUG
	O-,		6	95 494 867		WEIGHT SPRING
	——————————————————————————————————————			5 508 765	99	
			7	91 507 609 RP 5435 65	99	BALANCE WEIGHT 10 GR
	<del>[01792]</del>	£4163200		5 508 766		
		. 41		95 584 324	99	20GR
				5 508 768	99	25GR
				95 584 325	99	30GR
		:		5 508 770	99	35GR
				95 584 326	99	40GR
				75 522 918	99	45GR
		:		95 584 327	99	sogr
				75 522 920	99	55GR
				75 522 921	99	60GR
			A	96 078 385	01	SPARE WHEEL 5 50 JX14 FH 4 18 -GTI 16V
		E4163200		l	1_	1-G11 10V


30/01/98 GB E04 1 30/06/98		Т			
1235 03 <b>4220</b> 10 REAR ARM					
/ <sup>16</sup> 15 / 12		1	95 571 695	5 0	SUSPENSION ARM
		i	95 571 696	5 0	RIGHT
			95 630 227	7 01	LEFT -WITH ABS BRAKES
			95 630 228	01	RIGHT -WITH ABS BRAKES
		2	95 616 019	02	RR WHEEL SWIVEL
		3	95 496 146 RP 3701 42	02	WHEEL HUB
	ĺ				-WITH ABS BRAKES
		4		1	HUB REPAIR KIT
	l	5		1	CIRCLIP 32X34-2
		6	95 559 360 RP <b>3726 14</b>	02	BEARING CUP DIAM 47.3 FXT 75
11 14 14 12 14 D4220100		7	79 03 074 114	04	PLUG DIAM 12 H 10
	•	8	91 502 315 RP 5179 12	02 01	SEAL PROTECTOR DIAM 37,2 LON 140,5
	0	9	75 472 408	04	ARM BEARING 22X41X14,4
		10	91 501 057 LISTE 9306	99	ADJUSTMENT SHIM 22 X 30 - 0,15
		1	91 501 058 LISTE 9305		22 X 30 - 0,25
•		9	01 501 059 LISTE 9305	99	22 X 30 - 0,35
		9	01 501 060 LISTE 9306	99	22 X 30 - 0,45
		S	01 501 061 LISTE 9306	99	22 X 30 - 0,55











































30/01/98 GB F12 1 30/06/98	
STEERING WHEEL - ANTITHEFT DEVICE	
PAGE 2	6 96 070 197 01 UP TO 0 5956 ANTIVOL AVEC 8 FILS
18	95 662 479 01 SINCE O 5957 RP 96 070 197 01 AVEC ANTIVOL A 6 FILS
15	7 95 638 762 01 STRG LOCK GASKT 38X52
	8 96 032 545 01 UP TO 0 5438
	96 140 643 01 SINCE O 5439
	9 95 593 577 01 STRG WHL SHAFT -RIGHT HAND DRIVE
	10 95 654 324 01 STEERING GASKET
	11 95 585 707 02 BUSHING
13	12 79 03 080 002 01 RETAINING CLIP RP 6986 75 01
10 	13 96 021 419 01 JOINT SCREW 8X1.25-35 RP 4105 24 01
	14 79 03 201 001 01 CAPSCREW 4X70-8 RP 6914 26 01
	15 79 03 056 003 01 SPRING WASHER 4,2X8-0,5 01
	16 79 03 053 510 01 PLAIN WASHER 14.5X27.5-1.5
	17 79 03 058 030 04 SPRING WASHER 8X;18-1,4 01
	18 79 03 234 055 01 HEF 14X1,50-H12 RP 6939 91 01
	19 79 03 034 079 O1 HEF 8X1,25
	20 79 03 234 024 04 HEF 8X125 RP 6939 83 01
E4412100	

















1235 PAGE 1 03 HYDRAULICS - RUN	NING GEAR		FRONT PIVOTS AND HUBS	4131-10	1-D0:
IP. PUMP		1	WHEELS	4161-11	1-D0
<del></del>	3912-10	1-C02		4,61-,1	1-00
		1	WHEEL CAPS		1
IP.PUMP-BRACKET	3913-10	1-C03	- UP TO O 4740	4162-10	1-E0
- EXCEPT GTI 16V - GTI 16V	3913-20	1-C03	- SINCE O 4741	4162-20	1-E0
- G11 10V	3313-20	1-004	"LIGHT ALLOY" WHEEL		1
PRESSURE REGULATOR-BRACKETS-ACCUMULATOR			l distribution	4163-20	1-E0
	3916-10	J-C05			1
PRESSURE REGULATOR-BRACKETS	1	1	REAR ARM		1
THE TEST OF BUILDING TO	3917-10	1-C07		4220-10	1-E0
			REAR AXLE - FLEXIBLE MOUNTS		
AFETY VALVE				4221-10	1-E0
	3921-10	1-C08	FRONT SUSPENSION CYLINDER		1
IYDRAULIC FLUID TANK .	}		FROM SUSPENSION CYLINDER	4345-10	1-E0
	3930-10	1-C09			1
TIPBLY CHARLES THE			FRONT SUSPENSION CYLINDER-COPONENTS		
UPPLY SUSPENSION PIPING	3941-10	1-C10		4346-10	1-E0
	3941-10	1-010	REAR SUSPENSION CYLINDER		
RAKE PIPING				4347-10	1-E1
- WITH ABS BRAKES	3942-10	1-C12			İ
TEERING AND BRAKE MPING	-		HEIGHT CORRECTORES		١
THE SHARE I HAVE	3943-10	1-C14	•	4351-10	1-E1
			ANTI-ROLL BARS-CONNECTING RODS .		1
ETURN PIPING				4352-10	1-E1
- UP TO O 5167	3944-10	1-D15	P		1
- SINCE O 5168	3944-12	7-D13	MANUL HEIGHT CONTROL	4370-10	1-F1
IPING BRACKETS		l		1-570-10	)-F1
- 1ST PART	3945-10	1-D11	TEERING WHEEL - ANTITHEFT DEVICE		1
- 2ND PART	3945-11	1-D09	•	4412-10	J-F1
IPING-PLATE-BRACKET			STEERING BOX AND RODS		1
- 1ST PART	3946-10	1-008	OTELINO DON AND RODS	4420-11	1-F1
- 2ND PART	3946-11	1-D07	1	1	1
	30.70.11	, 557	STEERING BOX AND RACK		1
IPING-SHEATH-COLLAR	1			4425-11	1-F0
	3947-10	1-D06	STEERING ASSISTANCE VALVE		1
RONT ARMS				4426-10	1-F0
	1		1	i	1
	4123-10	1-D04	STEERING DISTRIBUTOR	ř	1


30/01/98 GB B03 T 30/06/98 1235 INDEX PAGE 1 NUMERO PAGE NUMERO PAGE NUMERO REP PAGE NUMERO PAGE REP NUMERO PAGE REP 5 410 179 03-3921-10 03-4163-20 75 522 920 03-4163-20 95 499 137 03-3945-10 03-3944-10 95 573 142 5 410 402 03-4351-10 5 508 768 03-4163-20 03-4163-20 75 522 921 03-4163-20 75 529 889 03-4425-11 95 499 138 03-3945-10 95 573 142 03-3944-12 95 574 124 03-4345-10 03-3944-12 5 410 403 5 508 770 03-4163-20 21 073 009 03-3947-10 03-4351-10 95 499 139 95 499 140 03-3945-10 5 410 404 | 03-4351-10 5 410 405 | 03-4351-10 75 531 823 03-3930-10 )3-3945-10 95 575 448 03-3946-10 21 889 009 03-3947-10 22 707 009 03-3916-10 75 532 224 95 575 448 03-3946-10 95 575 641 03-4370-10 95 576 879 03-4345-10 95 577 323 03-4347-10 95 577 401 03-3946-10 95 577 401 03-3946-10 95 499 148 03-3945-10 5 410 406 03-4351-10 95 499 149 03-3945-11 95 499 196 03-3945-10 95 534 068 03-4428-10 91 500 053 | 03-4220-10 03-4351-10 03-4351-10 5 410 407 91 501 057 | 03-4220-10 91 501 058 | 03-4220-10 91 501 059 | 03-4220-10 22 709 009 03-3916-10 5 410 407 03-4351-10 5 410 408 03-4351-10 5 410 732 03-4351-10 23 452 319 03-3916-10 23 746 509 03-4428-10 24 826 009 03-4345-10 95 536 696 03-3930-10 95 558 565 03-4420-11 95 559 360 03-4220-10 91 501 059 03-4220-10 91 501 060 03-4220-10 91 501 061 03-4220-10 91 501 062 03-4220-10 91 501 063 03-4220-10 91 501 065 03-4220-10 91 501 066 03-4220-10 91 501 066 03-4220-10 91 504 593 03-4220-10 91 504 593 03-4220-10 91 506 516 03-4420-11 91 507 342 03-4420-11 91 507 342 03-4420-11 5 411 956 03-3947-10 5 412 538 03-3916-10 24 826 009 03-4346-10 24 831 009 03-3921-10 95 578 248 03-4351-10 95 579 468 03-4345-10 5 412 539 03-3916-10 95 563 031 03-4347-10 95 563 033 03-4347-10 95 563 385 03-4131-10 5 412 540 03-3916-10 5 412 543 03-3916-10 24 880 009 | 03-3916-10 95 579 470 03-4345-10 95 579 689 03-3944-12 95 579 689 03-3944-10 24 881 009 03-3916-10 - 24 887 009 03-3916-10 - 24 890 009 03-3916-10 95 563 925 02-4131-10 95 563 928 03-4345-10 95 563 928 03-4345-10 95 565 975 03-4337-10 95 565 794 03-4220-10 95 565 802 03-4221-10 95 566 391 03-4221-10 95 566 391 03-4352-10 95 566 395 03-4352-10 95 566 395 03-4352-10 95 566 395 03-4352-10 95 566 395 03-4352-10 95 566 395 03-4352-10 95 566 395 03-4352-10 95 566 649 03-4345-10 5 412 797 | 03-3916-10 5 412 798 03-3916-10 5 412 801 03-3916-10 95 581 337 03-3946-10 25 355 019 03-4221-10 25 358 019 03-4352-10 95 581 339 03-3946-10 95 581 943 03-3946-10 5 413 090 | 03-3946-10 5 415 508 | 03-3921-10 5 415 510 | 03-3921-10 5 416 868 | 03-3916-10 26 140 919 | 03-4347-10 95 582 490 03-3946-10 95 582 491 03-3946-10 95 582 858 03-4347-10 95 582 859 03-4347-10 26 141 629 03-3947-10 26 141 639 03-3947-10 5 417 660 03-3942-10 5 420 595 03-3916-10 91 507 343 | 03-4420-11 91 507 609 | 03-4163-20 26 158 339 03-4370-10 26 189 549 03-4370-10 26 189 549 03-3947-10 26 192 359 03-4370-10 26 197 759 03-3946-11 26 197 999 03-3946-11 26 198 259 03-3946-11 95 584 324 03-4163-20 95 584 325 03-4163-20 95 584 326 03-4163-20 5 420 596 03-3916-10 5 420 596 03-3916-10 5 426 325 03-4370-10 5 438 353 03-3941-10 5 438 353 03-3943-10 5 449 669 03-3945-10 5 447 466 03-3930-10 5 447 189 03-3941-10 5 447 189 03-3941-10 91 507 997 03-4220-10 91 513 608 03-4425-11 91 513 609 03-4425-11 91 536 303 03-3912-10 07 06 04 06 06 06 06 06 06 09 03 03 02 02 04 03 01 14 27 02 12 95 584 326 03-4163-20 95 584 327 03-4420-11 95 584 926 03-3946-10 95 588 632 03-3946-10 95 588 632 03-3916-10 95 588 632 03-3916-10 95 589 173 03-4370-10 95 589 173 03-4370-10 95 589 766 03-4428-10 95 590 023 03-4131-10 95 591 142 03-3944-10 95 591 182 03-4420-11 95 591 953 03-3420-11 95 591 953 03-4420-11 95 591 953 03-4420-11 95 591 953 03-4420-11 95 591 953 03-4420-11 95 566 649 03-4345-10 95 566 652 03-4345-10 95 567 065 03-4351-10 91 540 474 | 03-4161-11 91 540 476 | 03-4161-11 91 540 478 | 03-4161-11 26 199 449 03-3945-10 26 199 569 03-3945-10 26 199 999 03-3945-10 95 567 065 03-3944-12 95 567 065 03-3944-10 95 567 431 03-3941-10 91 540 480 03-4161-11 91 540 482 03-4161-11 91 540 484 03-4161-11 26 208 089 03-3947-10 26 208 159 03-3947-10 26 208 169 03-3947-10 5 450 795 03-4351-10 5 451 210 03-3944-12 5 451 210 03-3944-10 5 451 213 03-3944-10 95 567 431 03-3941-10 95 567 450 03-3942-10 95 567 450 03-3942-10 95 567 451 03-3942-10 95 567 451 03-3942-10 95 567 452 03-3944-10 95 567 472 03-3943-10 95 035 532 03-4220-10 95 050 061 03-3921-10 95 050 064 03-3921-10 95 412 542 03-3916-10 26 212 599 03-4370-10 26 212 819 03-3916-10 26 213 549 03-4426-10 26 214 429 03-3916-10 5 451 213 03-3944-12 5 451 376 03-3916-10 5 458 582 03-4163-20 95 488 446 03-3930-10 95 494 867 03-4163-20 95 494 963 03-3921-10 26 230 579 03-3947-10 26 235 579 03-3944-12 26 235 579 03-3944-10 5 461 058 03-3930-10 5 461 317 03-3930-10 5 464 978 03-3930-10 5 464 979 03-3930-10 95 568 520 03-4370-10 95 568 521 03-4370-10 95 568 525 03-4370-10 95 495 439 03-4420-11 95 495 440 03-4420-11 95 496 044 03-4420-11 95 591 953 03.44163.20 95 592 593 577 03.4425.11 95 593 572 03.4425.11 95 593 577 03.4425.11 95 595 605 03.3942.10 95 595 609 03.3944.10 95 595 609 03.3944.10 95 588 525 03-4370-10 95 588 527 03-4370-10 95 568 737 03-4347-10 95 571 695 03-4220-10 95 571 696 03-4220-10 95 572 354 03-4131-10 5 474 836 03-3942-10 5 483 959 03-3930-10 95 496 044 03-4420-11 95 496 072 03-4420-11 95 496 146 03-4220-10 95 496 583 03-4161-11 95 496 828 03-3941-10 95 499 060 03-3945-10 95 499 060 03-3945-10 5 488 129 | 03-3930-10 5 488 788 03-3930-10 5 491 085 03-3930-10 5 503 515 03-4161-11 01 03 07 06 95 572 462 03-3946-10 5 508 681 03-3930-10 95 572 463 | 03-3946-10 95 572 469 | 03-3921-10 5 508 765 03-4163-20

95 499 136 | 03-3945-10

	554 6 1	30/06/	ne .												
30/01/98 GB 1235	B04 🕇	30/06/	38								-				
PAGE 2								IN	DE	K					
PAGE 2	- 1									•					
NUMERO	PAG	E R	P NUMER	0	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP
95 595 676	03-3943-	10 0	95.6	5 14E	03-4345-10	02	96 004 282	03-3942-10	04				l	1	
95 595 676	03-3942-			5 724		01	96 004 283	03-3942-10	07	96 056 235 96 056 235	03-3944-12 03-3944-10	05 05	96 119 263	03-3942-10	30
95 595 677	03-3943-		95 61	5 725	03-4420-11	01	96 004 285	03-3942-10	09	96 059 168	03-4131-10	07	96 119 301 96 119 301	03-3944-10 03-3944-12	20
95 595 682	03-3941-			5 973		01	96 004 287	03-3942-10	10	96 061 241	03-4370-10	07	96 119 302	03-3944-12	20
95 595 683	03-3941-				03-4220-10	02	96 004 290	03-3942-10	03	96 061 540	03-3946-10	20	96 119 932	03-3943-10	02
95 595 684 95 595 685	03-3941-			6 046		01	96 004 291	03-3942-10	05	96 061 543	03-3946-10	19	96 119 932	03-3942-10	12
95 596 539	03-3941- 03-3943-			6 549		02	96 004 292	03-3942-10	06	96 061 612	03-3947-10	08	96 119 933	03-3944-12	18
95 596 540	03-3943-		95 67	9 160	03-4131-10 03-4345-10	05	96 004 293	03-3942-10	15	96 065 619	03-4425-11	11	96 136 046	03-4131-10	08
	03-3941-		95 62	2 7 7 7 7	03-4345-10	09	96 004 372	03-4346-10	05	96 067 666	03-4351-10	03	96 140 643	03-4412-10	08
	03-3917-		05.62	3 754	03-3921-10	13	96 004 951 96 009 844	03-3946-10 03-4161-11	09	96 068 033	03-4425-11	09	96 141 827	03-4345-10	05
	03-3941-		95 62		03-3941-10	01	96 012 967	03-4162-10	01	96 068 399	03-4131-10	10	96 162 039	03-3947-10	03
	03-4346-				03-3941-10	l oi l	96 013 643	03-4420-11	10	96 070 064 96 070 144	03-4123-10 03-4123-10	03	96 995 040	03-3945-10	27
95 597 955	03-4352-	10 03			03-4220-10	15	96 014 107	03-3941-10	02	96 070 145	03-4123-10	01	96 995 085 96 995 332	03-3947-10	19
	03-3946-	10   07	95 63	0 094	03-4426-10	03	96 016 910	03-3941-10	03	96 070 197	03-4412-10	06	96 995 332 96 995 410	03-4352-10 03-3945-11	09
	03-4346-		95 63	0 227	03-4220-10	01	96 019 016	03-4161-11	03	96 075 164	03-3941-10	02	96 995 493	03-3945-11	08
	03-4346-		95 63	0 228	03-4220-10	01	96 021 419	03-4412-10	13	96 078 385	03-4163-20	08	96 995 718	03-3944-10	21
	03-4420-			0 575	03-4345-10	03	96 024 123	03-4426-10	07	96 084 709	03-4163-20	01	96 995 749	03-4352-10	10
	03-4351-			0 952		16	96 024 565	03-4345-10	03	96 085 395	03-4412-10	04	96 995 784	03-3945-10	28
	03-4351-			0 952	03-4347-10	13	96 024 567	03-4347-10	02	96 085 499	03-4163-20	loil	96 995 831	03-3945-11	02
	03-4347-		95 63		03-3916-10	16	96 024 569	03-4345-10	03	96 085 783	03-3947-10	18	96 995 893	03-3945-10	20
	03-4347-1		95 63		03-4123-10	06	96 026 117	03-3942-10	28	96 085 785	03-3947-10	18	96 995 897	03-3941-10	19
	03-4347-1		95 63		03-4351-10	03	96 026 117	03-3943-10	14	96 087 641	03-4345-10	03	GX 13 308 01A	03-3946-10	18
	03-3944-1		95 63		03-4221-10	02	<b>-96 026 603</b>	03-4347-10	03	96 087 642	03-4347-10	02	SRV 000 015	03-3947-10	07
	03-3917-1		95 63 95 63		03-4221-10	02	96 030 258	03-3944-10	02	96 090 490	03-4425-11	06	SRV 000 017	03-3947-10	02
	03-4420-1		95 63		03-3942-10 03-4221-10	17 01	96 030 258	03-3944-12	02	96 090 490	03-3943-10	10	77 00 560 788	03-3942-10	23
	03-4420-1		95 63		03-4221-10	05	96 031 947 96 031 949	03-4352-10 03-4352-10	05 05	96 090 491	03-3943-10	111	77 00 591 002	03-4428-10	05
	03-4426-1		95 63		03-3942-10	18	96 032 545	03-4412-10	08	96 090 491 96 093 534	03-4425-11	07	79 03 001 028	03-4426-10	09
	03-4426-1	10 01	95 63		03-4221-10	05	96 033 161	03-3941-10	04	96 093 534	03-3942-10 03-3943-10	06	79 03 001 043	03-3913-10	08
95 603 421	03-3944-1	10 01	95 63		03-4412-10	04		03-3941-10	04	96 093 536	03-3943-10	06	79 03 001 315	03-4221-10	08
	03-3941-1	10   06	95 63		03-4347-10	02	96 033 163	03-3943-10	09	96 093 536	03-3942-10	01	79 03 001 623 79 03 001 783	03-3913-10	04
	03-3941-1		95 63.	5 526	03-4352-10	04	96 033 164	03-3943-10	09	96 093 538	03-3943-10	03	79 03 001 783	03-3917-10 03-3913-10	07
95 603 832	03-4131-1		95 63		03-4352-10	06		03-3912-10	01	96 093 540	03-3942-10	29	79 03 002 009	03-4352-10	100
95 603 836	03-4131-1		95 63		03-4352-10	06	96 034 024	03-3913-20	01	96 093 540	03-3943-10	15	79 03 002 009	03-4370-10	14
95 604 346	03-4420-1		95 63		03-4352-10	02		03-3941-10	02		03-3943-10	16	79 03 009 039	03-3913-10	05
	03-3917-1		95 63	549	03-4352-10	02		03-3913-20	02		03-3942-10	27	79 03 009 039	03-3942-10	24
95 605 131	03-4131-1		95 63		03-3930-10	16		03-3944-10	19	96 093 880	03-3945-11	07	79 03 009 256	03-4426-10	10
	03-3943-1		95 63		03-3942-10	22		03-3944-12	19	96 105 771	03-4131-10	07	79 03 032 006	03-4370-10	19
	03-4425-1 03-4425-1		95 63		03-3942-10	22		03-3912-10	04	96 108 332	03-4351-10	06	79 03 032 252	03-4428-10	08
	03-4425-1 03-3943-1		95 63		03-4345-10	01		03-4162-20	01	96 111 243	03-3945-11	11	79 03 033 007	03-4345-10	17
	03-3943-7 03-4346-1		95 63 95 63	090	03-4123-10	02		03-4162-20	02	96 115 517	03-3944-10	20	79 03 033 012	03-3913-20	09
	03-4346-1 03-4346-1		95 63		03-4352-10	01		03-4131-10	03	96 117 584	03-3943-10	02	79 03 033 012	03-4370-10	20
	03-4346-1 03-391 <i>6-1</i>		95 64		93-4412-10 93-3913-10	07		03-3942-10	08	96 117 584	03-3942-10	12	79 03 033 015	03-4221-10	14
	03-4123-1		95 64		03-3913-10	10		03-3942-10	01	96 117 585	03-3943-10	06	79 03 033 027	03-4221-10	13
	03-4123-1		95 64		03-4428-10	03		03-3942-10 03-4161-11	30	96 117 586	03-3941-10	07	79 03 034 007	03-4420-11	16
	03-4352-1		95 65		03-4346-10	08		03-3921-10	02	96 118 502 96 118 503	03-3946-10	21	79 03 034 071	03-4426-10 03-4412-10	13
	03-4345-1		95 65		03-4412-10	- 10		03-3921-10 03-3942-10	02		03-3945-11	10	79 03 034 079 79 03 034 087	03-4412-10	12
	03-3912-1		95 65		03-4352-10	02		03-4351-10	01		03-3944-12	09		03-4221-10	16
95 612 961	03-4162-1				03-4412-10	06		03-4351-10	61		03-3944-12	31		03-4370-10	16
i				į	•		1		i `` i	30 113 251	00-3342-111	31	, , (1.7 0.52 540		] ]
										1					


30/06/98 30/01/98 GB B05 Î MOEX 1235 PAGE 3 REP NUMERO PAGE REP NUMBRO PAGE PAGE REP PAGE REP NUMERO PAGE REP NUMERO NUMERO 79 03 053 115 03-4221-10 10 79 03 079 200 | 03-3945-11 03 79 05 026 869 03-3944-12 07 79 03 053 392 03-3913-20 117 79 03 080 002 | 03-4412-10 12 79 05 026 872 03-3944-12 10 03-4428-10 06 79 03 083 209 03-4420-11 07 79 05 026 872 03-3944-10 14 79 03 053 394 79 03 053 510 | 03-4412-10 16 79 03 083 250 03-3947-10 Oi 79 05 026 874 03-3944-10 03 06 79 03 085 044 03-3947-10 05 79 05 026 874 03-3944-12 03 79 03 053 516 03-4426-10 79 03 085 045 03-3947-10 79 05 026 874 79 03 053 517 | 03-4426-10 06 06 03-3930-10 14 79 03 053 518 03-4426-10 06 79 03 087 098 03-4220-10 11 79 05 026 944 03-3944-12 13 79 03 053 519 03-4426-10 08 79 03 090 258 03-4426-10 02 79 05 026 944 03-3944-10 13 06 79 03 101 201 03-4352-10 11 79 05 026 949 03-3944-10 68 79 03 053 520 | 03-4426-10 79 03 053 521 03-4426-10 06 79 03 101 591 03-4370-10 12 79 05 026 949 03-3944-12 80 79 03 053 522 03-4426-10 06 79 03 101 600 03-4370-10 13 79 05 026 983 03-3947-10 16 06 79 03 101 753 03-4351-10 17 79 10 007 584 03-4425-11 04 79 03 053 523 03-4426-10 05 79 03 053 524 03-4426-10 79 03 101 756 \ 03-4351-10 16 79 10 009 748 03-4426-10 79 03 053 530 03-4426-10 79 03 101 770 03-3917-10 04 79 10 015 662 03-4161-11 05 79 03 053 531 03-4426-10 03 79 03 201 001 03-4412-10 14 79 10 023 867 03-4426-10 04 79 03 056 003 | 03-4412-10 15 79 03 201 012 03-3916-10 21 79 10 034 958 03-4420-11 08 79 03 056 008 03-3942-10 79 03 201 027 03-3921-10 79 20 080 939 03-3944-10 27 îï 79 03 056 014 03-3913-20 79 03 201 035 | 03-3913-20 03 94 71 001 765 03-4425-11 01 79 03 057 003 03-4426-10 12 79 03 201 036 03-3913-10 08 94 71 001 865 03-4425-11 01 79 03 057 005 | 03-3913-10 10 79 03 201 038 | 03-3913-20 03 95 568 517 FXX 03-4370-10 01 79 03 057 100 | 03-3913-10 10 79 03 201 038 03-4352-10 21 95 602 717 ZN 03-4163-20 03 79 03 058 019 03-4352-10 12 79 03 201 038 | 03-4221-10 95 631 185 FCH 03-4412-10 01 79 03 058 027 03-4370-10 15 79 03 201 151 03-3913-20 95 631 185 FLE 03-4412-10 01 04 79 03 058 028 03-3921-10 12 79 03 201 828 03-3913-20 95 631 185 FYL 03-4412-10  $\Omega 1$ 05 79 03 232 017 03-4352-10 03-4412-10 79 03 058 029 | 03-3917-10 08 15 95 631 185 FXX 01 79 03 058 030 103-3913-10  $n_9$ 79 03 232 024 03-4428-10 09 95 631 185 TR 03-4412-10 ល៖ 79 03 058 030 | 03-4412-10 17 79 03 232 035 03-4/20-11 17 95 631 186 FCH 103-4412-10 02 79 03 058 043 03-4420-11 10 79 03 232 056 03-4123-10 07 95 631 186 FLE 03-4412-10 02 79 03 058 052 03-4352-10 13 79 03 234 011 03-4131-10 95 631 186 FTL 03-4412-10 02 79 03 058 087 03-4425-11 12 79 03 234 011 03-4420-11 15 95 631 186 FXX 03-4412-10 02 79 03 056 168 03-4131-10 06 79 03 234 024 03-4412-10 20 95 631 186 TR 03-4412-10 02 79 03 066 225 03-4351-10 13 79 03 234 049 03-4131-10 95 631 259 XX 03-4412-10 01 79 03 067 023 03 79 03 234 055 95 635 736 XX 03 103-3913-10 03-4412-10 18 103-4412-10 79 03 074 114 | 03-4220-10 07 79 03 234 072 03-4123-10 08 95 666 968 XX 03-4412-10 03 79 03 079 004 03-3945-10 23 79 03 234 072 03-4220-10 16 79 03 079 018 03-3945-10 23 79 05 026 703 03-3942-10 16 79 03 079 093 103-3945-10 79 05 026 747 03-3944-12 16 79 03 079 098 03-3945-10 17 79 05 026 747 03-3944-10 16 79 03 079 099 03-3945-10 18 79 05 026 749 03-3944-10 04 79 03 079 108 03-3945-10 15 79 05 026 749 03-3944-12 0.4 79 03 079 109 03-3945-10 08 79 05 026 777 03-3944-12 67 79 03 079 110 03-3945-10 03 79 05 026 777 03-3944-10 07 79 03 079 111 03-3945-10 04. 79 05 026 851 03-3944-10 17 79 03 079 126 03-3945-10 79 05 026 851 03-3944-12 17 79 03 079 134 03-3945-10 24 79 05 026 852 03-3944-12 15 79 03 079 163 03-3945-10 25 79 05 026 852 03-3944-10 15 79 03 079 173 03-3945-10 79 05 026 853 | 03-3944-10 09 03-3945-10 79 05 026 853 79 03 079 175 10 03-3944-12 09 79 03 079 192 03-3945-10 13 79 05 026 855 03-3944-12 06 03 79 05 026 855 03-3944-10 79 03 079 197 03-3945-11 06 05 07 79 03 079 199 03-3945-11 79 05 026 869 03-3944-10


30/01/98 GB C02 1	30/06/98	
1235 04 <b>3140</b> 10 PAGE 1	PEDAL GEAR - BRAKE - CLUTCH	BVM LEFT HAND DRIVE
	1 ,	1 96 080 508 01 TOE BOARD ASSY
2	14 12	2 95 636 691 01 CONTROL CABLE LON 698
10 000		3 95 576 135 01 SHEATH SLEEVE
5 N 5		4 95 567 179 01 SHEATH STOP
900		5 96 035 654 01 CABLE GUIDE GTI 16V
		6 95 596 054 01 CABLE END-PIECE DIAM 45X6,5-22
15 ) 6		7 95 575 913 02 PEDAL COVER RP 2130 14 01
,		8 95 593 620 01 PEDAL SPRING DIAM EXT15,3 LON 105
-48		9 79 10 033 931 01 CONTACT SWITCH RP 4534 02 01
37		10 92 518 983 D1 LOCK FIX FORK RP 9172 04 01-G71 16V
	$\sim$	11 95 593 655 01 SPACER
	112 /b2  E3140100	12 79 03 009 108 02 SOCKET SCREW CHC 6X1,00-20
		13 79 03 001 342 O2 WASHER-SCREW THRI 8X1,25-16
		14 95 623 758 03 WASHER DIAM 6X18 RP 79 03 058 063 01
		15 79 03 032 121 02 HEXAGONAL NUT 10X100-3,2
		16 95 623 754 O1 NUT WITH BASE DIAM 6X1,00
	•	
	E5140100	





01/98 GB C04 T 235 04 <b>3141</b> 10 AGE 1	950/06/98  PEDAL GEAR FOR BRAKE					BVA
		1	,	95 595 837	01	TOE BOARD ASSY -LEFT HAND DRIVE
"				95 601 027	01	RIGHT HAND DRIVE
CAHA.	. 9 1	2	2	5 445 181	01	PEDAL COVER
		3	3	79 10 033 931 RP <b>4534 02</b>	01 01	CONTACT SWITCH
	ATTO Q	4	4	95 593 655	01	SPACER
		5	5	79 03 201 463 RP 6922 54	02 01	CAPSCREW RI 6X1,00-20
		6	;  ;	79 03 058 028 RP 6962 99	01	SPRING WASHER DIAM 6X14X1,4
DAD		7	·   <del>,</del>	79 03 058 011 RP 6962 70	02 01	DIAM 7,2X14,2-1,7
	10 6	8		79 03 032 121	02	HEXAGONAL NUT 10X100-3,2
	(Z) (E)M1:		7	79 03 032 036 RP 6932 05		DIAM 7X100
		10	2	25 260 019 RP <b>79 03 232 016</b>	01 01	DIAM 6X1,00
		11	1	95 591 611	01	PLAIN WASHER 6X19,5-4 -RIGHT HAND DRIVE
		12	7	'9 03 234 016 RP 6935 86	01 01	SELF LOCKG NUT 6X100 -RIGHT HAND DRIVE
					ľ	
				-		
	E314	41100		Ţ	i	


001/98 GB C05 1 30/06/98 235 04 <b>3711</b> 15 DRIVE SHAFTS AGE 1	16 TZI EXCEPT WITH ABS BRAKES
	16 TZI WITH ABS OPTION: LOOK AT SUBGROUP 3711 30
13 14 15 15 16 17 18 17 17 18 17 17 18 17 17 18 17 17 17 18 17 17 18 17 17 17 17 17 17 17 17 17 17 17 17 17	DRIVE-SHAFT NEW  1 3272 A8 01 LEFT REPERE 8GN04 8GN84 8GN86 8HN92 8HN98 (8HN98)  2 3273 K4 01 RIGHT REPERE 8GN05 8GN85 8GN87 8HN93 8HN99 (8HN99)  8 02 COTE PONT (REP SOUFFLET 9500916680)  3293 59 02 COTE PONT (REP SOUFFLET 9502508880  3287 74 02 COTE PONT (REP SOUFFLET 9563978280)  6 3247 03 01 BEARING 30 X 55 - 13  7 3248 06 01 DRIV SHAFT BUSH RIGHT  8 3252 04 02 SCREW 7X100-44  9 96 995 619 02 TRANS SNAP RING  10 3255 03 01 DEFLECTOR RIGHT 26 X 60 - 12  11 79 03 083 153 04 BOOT CLAMP LON 240  12 6935 84 02 SELF LOCKG NUT 7X100-7-11  13 3297 00 02 HUB FIXING NUT 24 X 150  14 3297 03 02 PIN
	,
E371115	






























0/01/98 GB B01 ↑ 30/06/98 235 PAGE 1 04 BRAKES-TRANS	MISSION-REAR AXE			
PEDAL GEAR - BRAKE - CLUTCH		<u> </u>		
- BVM LEFT HAND DRIVE	3140-10	1-C02		
- BVM RIGHT HAND DRIVE	3140-11	1-C03		
PEDAL GEAR FOR BRAKE				
- BVA	3141-10	1-C04		- 1
DRIVE SHAFTS				i
- 16 TZI EXCEPT WITH ABS BRAKES	3711-15	1-C05		
	3711-30	1-C06		
FRONT BRAKES - CALIPERS AND DISCS				Ì
	4512-10	1-C08		1
REAR BRAKE CALIPERS AND DICS		1		ı
	4516-10	1-C10		ł
BRAKE CONTROL VALVE				1
BRANE CONTROL VALVE	4540-10	1-C12		ŀ
BRAKES-HYDRAULICO - WITH ABS BRAKES	4542-10	1-C13		
				ł
BRAKES-FEELERS-BRACKETS	4543-10	J-C14		
- WITH ABS BRAKES	4543-10	/		ļ
BRAKES-COMPUTOR-RELAYS-BRACKETS	45.0.0	1015		ļ.
- WITH ABS BRAKES	4546-10	1-C15		-
HANDBRAKE - LEVER - CABLES			p <sup>i</sup>	
	4555-10	1-D15	lije.	ļ
			(;``  i- s	ľ
			[i*	
				1
			<u>l</u>	
		1	1	
		1		
		1		
			,	
		i		
		ì		1


30/01/98 GB B03 T 30/06/98 1235 **INDEX** PAGE 1 NUMERO PAGE NUMERO NUMERO PAGE REP PAGE REP NUMERO PAGE NUMERO PAGE REP 5 424 455 04-4540-10 04-3140-10 ZC 9617 067 U 04-4516-10 79 03 066 207 04-4540-10 5 431 086 04-4540-10 5 438 689 04-4516-10 95 598 986 04-3140-11 95 601 027 04-3141-10 95 602 266 04-3140-11 95 608 524 04-4516-10 ZF 13 301 111L 04-4512-10 3247 03 04-3711-30 3247 03 04-3711-15 79 03 077 099 04-4555-10 79 03 079 005 04-4543-10 79 03 079 005 04-4543-10
79 03 079 055 04-4543-10
79 03 081 073 04-4546-10
79 03 081 073 04-3546-10
79 03 081 073 04-3711-30
79 03 083 153 04-3711-30
79 03 083 153 04-3711-30
79 03 201 020 04-4516-10
79 03 201 020 04-4516-10
79 03 201 623 04-4555-10
79 03 201 759 04-4555-10
79 03 234 016 04-3141-10
79 10 033 931 04-3141-10
79 10 033 931 04-3141-10
79 10 033 931 04-3141-10
79 41 401 043 04-4516-10 5 438 690 04-4516-10 5 438 691 04-4516-10 5 445 181 04-3141-10 3248 06 04-3711-15
3248 06 04-3711-30
3252 04 04-3711-30
3252 04 04-3711-15
3255 03 04-3711-15
3255 03 04-3711-30
3272 A8 04-3711-30
3272 A8 04-3711-30
3273 K4 04-3711-30
3273 K4 04-3711-30
3273 K4 04-3711-30
3273 K7 04-3711-30
3293 59 04-3711-30
3293 59 04-3711-30
3293 59 04-3711-30
3293 59 04-3711-30
3293 59 04-3711-30
3293 59 04-3711-30
3293 59 04-3711-30
3293 59 04-3711-30
3297 00 04-3711-15
3297 02 04-3711-15
3297 02 04-3711-15
3297 02 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3297 03 04-3711-15
3293 03 04-3711-15
3293 03 04-3711-15
3293 04-3711-15
3293 05 04-3711-15
3293 05 04-3711-15
3293 05 04-3711-15
3293 05 04-3711-15
3293 05 04-3711-15
3293 05 04-3711-15
3293 05 04-3711-15
3293 04-3711-15
3293 04-3711-15
3293 04-3711-15
3293 04-3711-15
3293 04-3711-15
3293 04-3711-15
3293 04-3711-15
3293 04-3711-15
3293 04-3711-15
3293 04-3711-15
3293 05 04-3711-15
3293 04-3711-15
3293 05 028
3294 04-3711-15
3293 05 028
3294 04-3711-15
3293 05 028
3294 04-3711-15
3293 05 028
3294 04-3711-15
3293 05 028
3294 04-3711-15
3293 05 028
3294 04-3711-15
3293 05 028
3294 04-3711-15
3293 05 028
3294 04-3711-15
3293 05 028
3294 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 05 04-3711-15
3295 0 5 454 927 04-4516-10 25 260 019 04-3141-10 08 10 10 01 01 02 02 05 05 05 05 04 09 13 25 260 019 | 04-4555-10 26 159 839 04-4542-10 75 434 306 04-4540-10 91 501 258 04-4512-10 91 537 759 04-4546-10 91 537 913 04-4543-10 91 539 398 | 04-4543-10 92 518 983 | 04-3140-10 92 518 983 | 04-3140-11 95 495 759 | 04-4540-10 95 499 186 04-4543-10 95 565 090 04-4516-10 95 567 179 04-3140-11 95 567 179 04-3140-10 95 567 179 04-3140-10 95 574 973 04-4555-10 95 575 080 04-4512-10 95 575 913 04-3140-10 95 576 135 04-3140-10 79 41 401 043 04-4516-10 95 567 611 FXX 04-4555-10 95 572 023 FXX 04-4555-10 01 05 95 576 135 (4-3140-10 95 578 346 (4-4516-10 95 578 347 (04-4516-10 95 587 148 (04-4516-10 95 588 829 (04-4512-10 95 588 899 | 04-4512-10 95 588 900 | 04-4512-10 95 590 796 | 04-4512-10 95 590 796 | 04-4512-10 95 590 798 | 04-4512-10 95 590 838 | 04-4512-10 95 591 611 | 04-3140-11 95 591 611 | 04-3140-10 95 593 630 | 04-3140-10 95 593 635 | 04-3140-10 95 593 655 | 04-3140-10 95 593 655 | 04-3140-10 95 593 655 | 04-3140-10 95 593 655 | 04-3140-10 95 593 659 | 04-3450-10 

79 03 058 087 04-4516-10 79 03 065 984 04-4540-10

97 521 600 | 04-4546-10


95 593 695 04-4540-10 95 593 696 04-4540-10 95 595 837 04-3141-10 95 596 054 04-3140-11








30/01/98 GB C04 1 30/06/98	·			
1235 05 <b>5012</b> 10 ENGINE HARNESS				
PAGE 1				
				ENGINE HARNESS
न्नि	E	1	96 087 448 0	!
	<b>₩</b>		95 634 918 0	SALOON 19 TRI SALOON 19 TZI
(*)	1		96 041 132 0	I-ESTATE 19 TRI
	/		30 04. 152	-ESTATE 19 TZI
	//			-GTI
	F			GTI 16V UP TO O 4922
	\ \\\\		1	-GTI 16V SINCE O 4923
		2	96 087 447 01	SAFETY HARNESS -16 TZI
			95 599 769 94	
	2		99 599 760 01	ELECTRIC HARNES SECURITE DEMAREUR -19 TRI
	$\sim 91$			-19 TZI -GTI
	10 6			
			ĺ	
	' /			
	(Series)		1	
			1	
[06/	96]		İ	
	İ		}	
	E5612100			
	C3012100	1		


30/01/98 GB C05 1 30/06/98	
1235 05 <b>5012</b> 20 ENGINE HARNESS	
PAGE 1	
	INJECTION HARNESS: ENGINE SIDE
	CER: COMPACT CONNECTOR (SOME VEHICLES 16TZI CAN BE EQUIPED)
	INJECTN HARNESS
	1 96 102 571 01 COTE MOTEUR
to be the second	-16 TZI UP TO O 5074
	96 113 423 01 COTE MOTEUR
	-16 TZI SINCE O 5075 UP TO O 5284
	96 124 661 01 COTE MOTEUR
	-16 TZI SINCE O 5285
	96 141 978 01 PARTIE MOTEUR
	-16 TZI SINCE O 5474 UP TO O 5683
	COMPACT CONNECTOR (CER)
	6543 SR 01 PARTIE MOTEUR
	RP 96 141 978 01-16 TZI SINCE O 5684 COMPACT CONNECTOR (CER)
	95 634 054 01 COTE MOTEUR -SALOON 19 TRI
	-SALOON 19 TZI UP TO O 5074
	96 123 686 01 COTE MOTEUR
	-SALOON 19 TZI SINCE O 5075
	96 031 884 01 COTE MOTEUR -ESTATE 19 TRI
	-ESTATE 19 TZI
	-GTI
	96 032 184 01 COTE MOTEUR
	-GTI 16V UP TO O 4922
[06/96]	96 104 393 01 COTE MOTEUR
	-GTI 16V SINCE O 4923
E5012200	
























30/01/98 GB C14 1 30/06/98 1235 05 <b>5018</b> 51 FACIA PANEL CONSOLE HARNESS	
	1 95 637 362 01 RADIO HARNESS AV
[09/96] D5018510	
D5018510	


30/01/98	GB C15	30/06/98	Т			
1235 05	5018 50	FACIA PANEL CONSOLE HARNESS				
PAGE 1	5018 59		İ			
1 95 613	127 NFP	01 ELECTRIC HARNES MASSE BOIT INTER CON	t		Τ	
					l	
	-	1				
					ı	
	1					
1						
	l		l			
	1	İ				
ŀ						
1						
1					1	
1				ļ		
	ŀ					
		:				
	1					
	ĺ					
	1			į		
	ļ					
	[					
	[					
+						
i	-					











































30/01/98 GB D01 I 30/06/98		
1235 05 <b>5123</b> 10 TONGUE H	OLDER	
		(A) — NATURAL (B) — WHITE (C) — BLUE (D) — GREY (E) — YELLOW (F) — CHESTNUT (G) — MALLOW (H) — BLACK (J) — ORANGE (K) — RED (L) — GREEN
	1	BLADE-HOLDER 1 95 558 841 99 (A) 1 VOIE DE 6,35
		95 589 988 99 (B) 2 VOIES DE 5 RP 6542 Q4 01
		95 589 991 99 (B) 3 VOIES DE 5
		95 600 098 99 (B) 5 VOIES DE 5
		92 525 012 99 (B) 8 VOIES DE 5 RP 79 05 521 693 01
		95 589 987 99 (E) 2 VOIES DE 5
		95 600 097 99 (E) 3 VOIES DE 5
		95 600 096 99 (E) 6 VOIES DE 5
1230	02 /88 5-512-11	95 600 099 99 (E) 10 VOIES DE 5
		95 589 986 99 (F) 2 VOIES DE 5 RP 6542 VA 01
		95 589 989 99 (F) 3 VOIES DE 5
		95 589 992 99 (F) 4 VOIES DE 5
		95 589 993 99 (F) 7 VOIES DE 5
	,	95 589 990 99 (L) 3 VOIES DE 5
	E5123100	













00 500 1	30/06/98					
30/01/98 GB E06 † 1235 05 <b>5212</b> 10 PAGE 1	INSTRUMENT PANEL - SPEEDOMETER CABLE					
		1	96 085 890 NFP		INSTRUM CLUSTER -16 TZI	
1	5		95 631 645 NFP		-19 TRI -19 TZI	
			96 077 191 NFP		-671	
3	2		96 077 192 NFP		-G7I 16V	
17	10	2	95 600 677	01	SPEEDOMET CABLE COTE COMPTEUR -LEFT HAND DRIVE SPPEDOMETER SIDE	
©_6			96 027 855	01	LON 1050 -RIGHT HAND DRIVE SPEEDOMETER SIDE	
		3	96 073 325	01	LON 485 COTE BV GEARBOX SIDE	
	\[\(\partial 27/92\)\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\		95 496 555	01	LON 570 - COTE BV -GTI 16V LEFT HAND DRIVE GEARBOX SIDE	
		4	96 046 743	01	SPEED SENSOR	
		5	95 577 957	01	GROMMET	-
		6	97 506 603 RP 2644 04	01 01		
		7	00 88 910 200 RP 6988 06		RING-SEAL COTE BV	
			79 03 065 165	01	SENSOR SEAL DE CAPTEUR	
		8	79 030 880 80 RP 8209 10		FIXING STOP	
		9	79 03 016 151 RP 6910 89		CAPSCREW DIAM 4,2X19	
	E5232100		l	Í	1	1


01/98 GB E07 1	30/06/98 INSTRUMENT PANEL - SPEEDOMETER CABLE		
35 05 <b>5212</b> 10 IGE 2	Manager Paris		
		10 79 03 046 048 02 SPEED NUT 4,2X11,8-9	
		11 05 22 395 100   01 STOP PIN RP 2650 07 01	
4	5 1		
and the same			
	1		
3/			
n- //			
1 B_			
<b>\9-0</b> _7	<b>1</b>		
<u>—</u> е	9		
•			
	02/92 E5212100		
	E52+2100		








30/01/98 GB E10 † 1235 05 <b>5213</b> 12 PAGE 1	30/06/98 INSTRUMENT PANEL-CHECKING APPARATUS	JAEGER 16 TZI 19 TRI 19 TZI
1235 US 32 13 12 PAGE 1		1 95 619 405 01 SPEEDOMETER 2 95 619 407 01 REVLTN COUNTER 3 95 619 409 01 GAUGE INDICATOR DE NIVEAU CARBURANT 4 95 619 411 01 INDICATOR DE NIVEAU D'HUILE OIL LEVEL (WITH PRINTED CIRCUIT) 5 95 619 416 01 CLUSTER HOUSING 6 95 619 418 01 INSTRUMT VISOR 7 95 619 420 01 PRINTED CIRCUIT 8 95 619 421 01 FIXING KIT 9 95 619 572 01 BUTTON BULB HOLDER 10 75 470 822 RP 75 467 140 01
9	9 E 521 3130	11 DX 9521 299 A RP 6112 16 01
	E5213120	


001/98 GB E11 <b>†</b> 235 05 <b>5213</b> 13 AGE 1	30/06/98 INSTRUMENT PANEL-CHECKING APPARATUS			JAEGER GTI
	A)	1	95 619 405	01 SPEEDOMETER
9- /1	12	2	1 1	01 REVLTN COUNTER
3,000		3	95 619 409	01 GAUGE INDICATOR DE NIVEAU CARBURANT
		4	1 1	OIL PRESS GAUGE PRESS + NIVEAU HUILE OIL PRESSURE AND LEVEL
		5	95 619 413	TEMP GAUGE WTR TEMPERATURE D EAU WATER TEMPERATURE
		6	95 619 414	OIL TEMP GAUGE TEMPERATURE D HUILE OIL TEMPERATURE
4		7	95 619 416	CLUSTER HOUSING
المسلم ك	\$ 8° 11 11 11 11 11 11 11 11 11 11 11 11 11	8	95 619 418	INSTRUMT VISOR
	8	9	95 619 420	PRINTED CIRCUIT
4-2		10	95 619 421	FIXING KIT
3-		11	95 619 572	BUTTON
12:30	Ø/se 5.521.3)	12	75 470 822 RP 75 467 140	BULB HOLDER
		13	i I	11 CHARGING CONTROL
	E5213130			






















30/01/98 GB F12	
30/01/30 GB   1/2 4	1 95 587 064 01 LEFT 95 587 063 01 RIGHT CIBIE 2 95 637 354 06 ADJUSTMT SCREW LONG:75 3 95 619 445 06 FIXING RING SEIMA FRONT LIGHT LH 95 619 034 01 SEIMA 95 619 656 01 CIBIE FRONT LIGHT RH 95 619 657 01 CIBIE 5 95 616 037 02 95 619 658 02 CIBIE 6 95 619 444 02 SOCKET UP TO O 4679
	95 654 100 02 LAMP SLEEVE DE VEILLEUSE CIBIE SINCE O 4680  7 95 598 511 02 MOUNTING ASSY CIBIE 8 5 484 036 02 FLY NUT 6X100-11 9 96 041 035 RP 6325 59 01
E54:0100	

































0/01/98 GB G01 T	30/06/98		
235 05 <b>5642</b> 10	REAR WINDOW WASCHER		
AGE 1		1 97 518 987 O1 WDW WASHER PUMP RP 6434 46 01	
1	3 9	2 95 633 057 01 TANK	
		3 95 610 342 01 FLANGE	
		4 97 518 936 01 PLUG	
	,	RP 6432 30 D1	
<b>6</b>		5 95 499 014 01 PIPE D 3,5X6,5-3500	
/ '		6 95 495 149 01 WDW WASHER JET	
g		7 79 03 074 183 01 PLUG DIAM 9 H 23 8 97 511 123 01 WASH PUMP SEAL DIAM 21	
•		RP 6434 45 01	
2——		9 24 325 039 01 CAPSCREW 6X100-25 RP 6921 81 01	
	. !	10 95 623 758 01 WASHER DIAM 6X18	
		11 26 158 889 01 CAGED NUT 6X10015,5-13,7-6	
1730	O7/88 3.564.20	RP 79 03 044 001 01	
	E5642100		








30/01/98 GB G05 1 30/05/98 CHECKING S PAGE 1 05.6145.10	TAND AND HOUSING  5  6  7  106/92  D6156100	2 3 4 95 5 6 95 7 26 8 26	RP 6500 12 96 035 929 95 635 752 593 200 RP 6500 01 95 634 666 639 587 RP 8221 54 131 869 RP 6949 10 131 859 RP 8220 EF	OI -WITH ABS BRAKES OI SHUNT BOX OI RETAINER BAR OI FUSE BOX COVER OI BOX BRACKET OI LOCKING OI PLAIN WASHER 5X20-1,5 OI LOCKING CAM
	£6156100			





/01/9	98 GB G08	30/06/98						
235 AGE	05 <b>6533</b> 10	AERIAL - SP GRILLE - STATICS SUPPRESSING	•					
+		AERIAL WIRE		3	95 631 250 FXX	0.	1 RIGHT	
	97 512 672	CHROME BLANC	Ì	F	RP 95 631 250 XX	0	1 ON DASHBOARD	
		SILVER PLATED	6	ا	95 632 532 FCH	10.	LEFT AV	
	97 512 685	CHROME NOIR	١		RP 95 632 532 CH			
ļ		SADITEL	ŀ	1				
		BLACK			95 632 532 FLE R <b>P 95 632 532 LE</b>	1 -	LEFT AV	
	ŀ	AERIAL BASE	1	ľ	(P 93 032 332 LE	١٧	IION DOOR	
ŀ	97 512 669	1 CHROME BLANC	1		95 632 532 TR	01	LEFT AV	
		MAG					ON DOOR	
		SILVER PLATED	l	15	5 632 532 FXX	01	LEFT AV	
97	512 670	CHROMEE NOIRE			P 95 632 532 XX			
	RP 6561 10	1 BLACK		1	C 000 504 50H		DIOLET ALC	
	05 405 000	AERIAL TELESCOPIQUE	į		95 632 531 FCH P 95 632 531 CH			
	93 493 392	MARIAL TELESCOPIQUE		r	r 33 032 331 Cn	10	I DOOK	
		LDSPKR BRACKET					RIGHT AV	
95 :		LEFT SUR CUSTODE		IR	P 95 632 531 LE	01	IJON DOOR	
	NFP	-SALOON ON QUARTER PANEL		ı	95 632 531 TR	01	RIGHT AV	
		ON QUARTER PANEL		ľ	30 00k 301 110	Ι.	ON DOOR	
95		1 RIGHT SUR CUSTODE		٦	E 000 E04 EVV		DIGITE 414	
	NFP	-SALOON ON QUARTER PANEL			5 632 531 FXX P <b>95 632 531 XX</b>		RIGHT AV	
	i	ON QUARTER PANEL		ľ	1 35 002 501 AA	١.	len Bean	
		LOUDSPKR GRILLE	7	1	95 573 744	02	ON QUARTER PANEL	
		1 LEFT	8	ı	95 580 019	02	LDSPEAKER PLUG	
KP	95 633 967 CH	1 ON DASHBOARD	١٠	l	33 300 013	١٣	ON QUARTER PANEL	
95 (	633 967 FLE	1 LEFT		l		١		
RP	95 633 967 LE	1 ON DASHBOARD	9	1	95 634 767	01	RADIO BRACKET AR	
	95 633 967 TR	1 FET		ı		ļ	LOUDSPEAKER	
	33 033 307 11	ON DASHBOARD	10	ı	95 599 444	02		
^-			1	l			ON DASHBOARD	
		1 LEFT 1 ON DASHBOARD	1		95 599 625	02	15W	
	33 033 307 AA	TON BASINGARD				1	ON DASHBOARD	
		1 RIGHT	111	1	95 495 389	02	SALOON	
RP	95 631 250 CH	1 ON DASHBOARD	1	l	33 433 303	٦	ON QUARTER PANEL	
95 <del>6</del>	531 250 FLE	RIGHT	1		05 000	_	• • • • • • • • • • • • • • • • • • • •	
		1 ON DASHBOARD	!	1	95 633 172	02	20W  -ESTATE	
	05 621 250 TD	IPICHT	j .				ON REAR SHELF	
	95 631 250 TR	ON DASHBOARD		1				
				1			1	

30/01/98 GB G09	†  30/06/98
1235 05 <b>6533</b> 10 PAGE 2	AERIAL - SP GRILLE - STATICS SUPPRESSING
12 ZC 9865 887 U NFP	OI HEADPHONE
13 ZC 9865 841 U NFP	01 HDPHONE PICK-UP POUR CASQUE ECOUTE
14 95 561 136	01 CO-AXIAL CABLE LONG 3255
15 95 588 122	2 02 EARTH BRAID
16 79 03 016 150 RP 6925 54	02 TAPPING SCREW 4,2X13 01
17 79 03 074 186	6 02 FLOOR PLUG DIAM 10 H 12
18 5 490 966 NFP	01 CONDENSER DE BOBINE IGNITION COIL
<u> </u>	


30/01/98 GB B01 1 30/06/98					
1235			CLIP HOLDER		
PAGE 1 05 ELECTRICAL EQUIPER	MENT		1	5120-10	1-D06
	·		_	5120-40	J-D02
FRONT FACE HARNESS			TONGUE HOLDER		
	5010-02	1-002	1	5123-10	1-D01 ·
MAIN WIRING HARNESS		1	01.100		
{	5011-10	1-C03	CLIPS-TONGUES-COVERINGS-ADAPTERS	5405.40	
ENGINE HARNESS	ł			5125-10	1-E01
- Indiana indiana	5012-10	1-C04	WIRING SECURING		
	5012-10	1-C05		5126-10	1-E02
	5012-30	1-C06		5126-11	1-E04
CALCOTAN EL COTTONIA MANTE ANTIGONA			LAMP KIT	1	
FAISCEAU ELECTROVANNE ANTIPOLLUTION				5127-10	1-E05
	5013-02	1-C07	INCTRIBUTE DAME		
FAISCEAU ALLUMAGE	ł	1	INSTRUMENT PANEL - SPEEDOMETER CABLE	5212-10	4.500
	5014-01	1-C08	<u> </u>	3212-10	1-E06
FAISCEAU FREINS		i	INSTRUMENT PANEL-CHECKING APPARATUS		
	5017-01	1-C09	- VEGLIA - 16 TZI 19 TRI 19 TZI	5213-10	1-E08
	5017-02	1-C10	- VEGLIA - GTI GTI 16V	5213-11	1-E09
FACIA PANEL CONSOLE HARNESS	ŀ	1	- JAEGER - 16 TZI 19 TRI 19 TZI - JAEGER - GTI	5213-12	1-E10
TACIA PAREL CONSOLE MARNESS	5018-05			5213-13	1-E11
	5018-40	1-C11 1-C12	DOOR INDICATOR ON DASHBOARD		
	5018-50	1-C13		5218-10	1-E12
	5018-51	1-C14	switch	1	1 1
	5018-59	1-C15		5219-10	1-E13
	5018-60	1-D15	INCTRUSED DAME: CHARACTER	1	
INTERIOR LAMP HARNESS		l	INSTRUMENT PANEL-SWITCHES	5222-10	
The state of the s	5021-02	1-D14		3222-10	1-E14
FAIROFALL BODGE	1	' '	ACCESSORIES F. INSTRUMENT PANEL	ŀ	] ]
FAISCEAU PORTES	5000.04			5223-10	1-F15
•	5023-01	1-D13	INSTRUMENT PANEL AND CONSOLE ACCESSORIES		
INTERMEDIATE RIGHT-LIGHT HARNESS	]			5230-10	I-F14
	5024-05	1-D12	BATTERY		
	5024-30	1-D11		5310-10	1-F13
	5024-50	1-D10		155.0.0	'"'"
	5Q24-51	1-D09	FRONT LIGHTING		] ]
REAR WIRING HARNESS				5410-10	1-F12
	5025-01	1-D08	FRONT LIGHTING - FOG LIGHTS		
•	5025-30	1-007		5411-10	1-F11
	ì	li li		- 1	: 1


30/01/98 GB B02 ↑ 30/06/98 1235 PAGE 2 <b>05</b> ELECTRICAL EQUIPE	MENT	
	·	
REAR LIGHTING - SALOON - ESTATE	5440-10 5440-20	1-F10 1-F08
INTERIOR LIGHTING - EXCEPT SUN-ROOF	5450-10	1-F07
ADJUSTING CEILING LIGHTS - SUN-ROOF	5454-10	1-F06
SWITCH	5455-10	1-F05
FRONT WINDOW WIPER	5611-10	1-F04
REAR WINDOW WIPER - SALOON - ESTATE	5612-10 5612-20	1-F03 1-F02
FRONT WINDSCREEN WASCHER	5641-10	1-F01
REAR WINDOW WASCHER	5642-10	J-G01
HORN	5710-10	1-G02
RELAYS - FUSES	6145-10	
CHECKING STAND AND HOUSING	6156-10	1-G03
BINACLE ELECTRONIC EQUIPMENT	6160-10	1-G05
ELECTRONIC AQUIPMENT UNDER BONNET	6161-10	1-G06
AERIAL - SP GRILLE - STATICS SUPPRESSING	6533-10	1-G07
	6533-10	1-G08

235 AGE 1							IN	DEX						
NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	_
5 407 175			92 556 346		08	95 579 681	05-5120-10	01	95 589 993	05-5123-10	01	95 618 762	05-5213-10	-
5 412 143	05-5125-1		92 556 630	05-5213-10	09	95 579 813	05-5120-10	10	95 592 024	05-5126-10	08	95 618 763	05-5213-10	ı
5 414 554	05-5126-10		92 560 507	05-6160-10	03	95 579 815	05-5120-10	01	95 592 409	05-5454-10	02	95 618 765	05-5213-10	1
5 446 067	05-5440-10		95 493 782	05-5455-10	03	95 579 817	05-5120-10	01	95 593 200	05-6156-10	04	95 618 765	05-5213-11	
5 451 681	05-5120-1		95 494 778	05-5440-10	05	95 580 019	05-6533-10	08	95 593 947	05-5310-10	03	95 618 766	05-5213-11	
5 484 036	05-5410-10		95 494 828	05-5611-10	01	95 580 039	05-5126-10	05	95 595 408	05-5126-10	03	95 618 767	05-5213-11	
5 490 966	05-6533-16		95 495 141	05-5219-10	03	95 581 404	05-5310-10	05	95 596 596	05-6145-10	10	95 618 768	05-5213-11	
21 435 009	05-5017-01		95 495 143	05-5455-10	02	95 582 951	05-6145-10	07	95 597 857	05-6160-10	06	95 618 768	05-5213-10	
21 435 009	05-5126-10		95 495 149	05-5642-10	06	95 583 386	05-6533-10	04	95 598 511	05-5410-10	07	95 619 034	05-5410-10	
24 325 039	05-5642-10		95 495 389	05-6533-10	111	95 583 387	05-6533-10	04	95 598 782	05-5014-01	01	95 619 035	05-5410-10	į
24 325 039	05-5641-10		95 495 448	05-5450-10	01	95 585 851	05-5310-10	03	95 598 948	05-5455-10	05	95 619 036	05-5440-10	- 1
25 903 009	05-5127-10		95 495 449	05-5450-10	01	95 586 648	05-5611-10	08	95 599 444	05-6533-10	10	95 619 037	05-5440-10	
25 908 009	05-5127-10		95 495 578	05-5223-10	01	95 587 053	05-5440-10	03	95 599 625	05-6533-10		95 619 405	05-5213-12	
25 919 009	05-5127-10		95 495 714	05-5641-10	06	95 587 055	05-5440-10	04	95 599 760	05-5012-10	10	95 619 405	05-5213-12	
25 926 009	05-5127-10		95 495 992	05-6533-10	03	95 587 060	05-5440-10	03	95 600 095	05-5120-10		95 619 407	05-5213-13	
25 928 009	05-5127-10	04	95 496 232	05-5455-10	01	95 587 063	05-5410-10	01	95 600 096	05-5123-10	22			
26 101 009	05-5127-10	07	95 496 482	05-5454-10	04	95 587 064	05-5410-10	l oi l	95 600 097		01	95 619 407	05-5213-12	
26 131 859	05-6156-10	08	95 496 555	05-5212-10	03	95 587 390	05-6145-10	12	95 600 098	05-5123-10	01	95 619 409	05-5213-12	i
26 131 869	05-6156-10	07		05-5454-10	03	95 588 122	05-6533-10	15	95 600 099	05-5123-10	01	95 619 409	05-5213-13	
26 146 849	05-5127-10	02	95 499 014		05	95 589 140	05-5611-10	02		05-5123-10	01	95 619 411	05-5213-12	-
26 158 889	05-5641-10	12		05-5642-10	05	95 589 141	05-5611-10	03	95 600 677	05-5212-10	02	95 619 412	05-5213-13	
	05-5642-10	111		05-5120-10	03	95 589 142	05-5611-10		95 604 774	05-6160-10	02	95 619 413	05-5213-13	- 1
26 162 709	05-5310-10	07		05-5440-20	05	95 589 964	05-5120-10	04	95 606 763		01	95 619 414	05-5213-13	- 1
	05-5126-10	09		05-5120-10	01	95 589 965	05-5120-10	01		05-5455-10	07	95 619 416	05-5213-13	-
75 467 140		09		05-5120-10	oi l	95 589 966	05-5120-10	01		05-5641-10	03		05-5213-12	- 1
	05-5213-13	12		05-5213-10	10	95 589 967	05-5120-10			05-5642-10	03	95 619 418	05-5213-12	- 1
	05-5213-10	09		05-5120-10	01	95 589 968	05-5120-10	01		05-6160-10	05	95 619 418	05-5213-13	ı
	05-5213-12	10		05-5123-10	01	95 589 969	05-5120-10	01		05-5612-20	04	95 619 420	05-5213-13	- 1
75 470 822		09		05-5120-10	05	95 589 970		01		05-5024-50	01	95 619 420	05-5213-12	н
75 526 214		07		05-6533-10	14		05-5120-10	01		05-6160-10	01	95 619 421	05-5213-12	ı
	05-6161-10	05		05-5611-10	14		05-5120-10	01	95 612 506	05-5126-10	10	95 619 421	05-5213-13	- 1
	05-6161-10	02		05-5310-10	04		05-5120-10 05-5120-10	01		05-5018-59	01	95 619 444	05-5410-10	Į
	05-6161-10	02		05-5025-30	01			01	95 613 177		05	95 619 445	05-5410-10	1
	05-6145-10	05		05-5025-01	01		05-5120-10	01	95 614 616		01	95 619 572	05-5213-13	ı
	05-5120-10	01		05-5230-10	03		05-5120-10	01		05-5411-10	03		05-5213-12	ı
92 525 010		01		05-6533-10	07		05-5120-10	01	95 615 150	05-5411-10	02	95 619 575	05-5213-11	ı
	05-5120-10	l oi l		05-5025-30	03		05-5120-10	01		05-5410-10	05		05-5213-10	1
92 525 012		or		05-5025-30	01		05-5120-10	01		05-5440-10	02		05-5455-10	1
	05-5126-10	16		05-5126-10	01		05-5120-10	01		05-5440-10	02		05-5410-10	1
92 535 967		l io		05-5126-10	03		05-5120-10	01		05-5440-10	03	95 619 657	05-5410-10	ı
	05-5125-10	03					05-5120-10	01		05-5440-10	04		05-5410-10	J
	05-5125-10	03		05-5126-10	02		05-5120-10	01		05-5440-20	01		05-5612-10	1
	05-5125-10	01		05-5310-10 05-6161-10	02		05-5120-10	01		05-5440-20	01		05-5611-10	ı
	05-5120-10	01		05-5025-01	01		05-5120-10	01	95 616 753	05-5440-20	02		05-5611-10	1
	05-5120-10	01		05-5025-01	03		05-5120-10	01		05-5440-20	02		05-5641-10	1
	05-5120-10	01			02		05-5123-10	01		05-5411-10	06		05-5642-10	1
	05-5120-10	01		05-5212-10 05-5126-10	05		05-5123-10	01		05-5223-10	03		05-5611-10	ł
	05-5120-10	01		05-5126-10	03		05-5123-10	01		05-5213-10	04		05-5120-10	1
	05-5120-10	04		05-5126-10	07		05-5123-10	01		05-5213-10	07		05-5612-10	ı
92 553 495		08			06		05-5123-10	01		05-5213-11	07	95 624 928	05-5411-10	ı
	05-5440-20	03		05-5025- <b>30</b> 05-5230-10	04	95 589 991	05-5123-10	01		05-5213-11	08	95 624 929		ı
3E 334 U37	JJ-3440-20	103	AD 2/8 280	NO-2530-10	07	95 589 992	05-5123-10	<b>მ</b> 1	95 618 758	05-5213-10	08	95 624 982	05-5440-10	1

	i							DEX	•					
NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	R
95 630 109		04	95 640 714	05-5710-10	03	96 034 632	05-5120-10	01	96 111 725	05-5012-10	01	79 03 009 072	05-6161-10	+
	05-5612-20	06	95 649 416	05-5126-10	08	96 035 781	05-5011-10	01	96 113 423	05-5012-20	01	79 03 016 150	05-6533-10	
	05-5025-01	03	95 649 417	05-5126-10	08	96 035 929	05-6156-10	02	96 123 686	05-5012-20	01	79 03 016 151	05-5212-10	1
	05-6160-10 05-5021-02	04	95 653 961	05-5440-10	02	96 040 244	05-5014-01	01	96 124 661	05-5012-20	01	79 03 016 256	05-5454-10	1
	05-5021-02	01	95 653 962	05-5440-10	02	96 041 035	05-5410-10	09	96 133 222	05-5024-05	01	79 03 016 282	05-5455-10	-1
	05-5025-30	02	95 653 963	05-5440-10	03	96 041 132	05-5012-10	01	96 141 977		01	79 03 032 006	05-6160-10	П
	05-5212-10	01	95 653 964	05-5440-10	03	96 041 697	05-5024-30	02		05-5012-20	01	79 03 032 232	05-5612-10	-1
	05-5212-70	01	95 654 100	05-5410-10	06	96 042 790	05-5126-10	13	96 142 463		01	79 03 033 009	05-6156-10	-1
	05-5411-10	04	95 656 434 95 656 434	05-5213-11	02	96 044 799	05-5011-10	01	97 506 603		06	79 03 046 036	05-5411-10	
	05-6145-10	11	95 656 448	05-5213-10 05-5440-10	02	96 046 539	05-6161-10	06		05-5642-10	08	79 03 046 048	05-5212-10	
	05-5642-10	02	95 656 447		01	96 046 743	05-5212-10	04	97 511 123	05-5641-10	07	79 03 057 005	05-5612-10	
	05-5641-10	02	95 656 533	05-5440-10 05-5213-11	01	96 048 371	05-5219-10	01	97 512 669		02	79 03 058 027	05-6160-10	
	05-5612-20	01	95 658 515		02	96 056 155	05-5013-02	01	97 512 670		02	79 03 058 041	05-5611-10	1
95 633 172		1 11 1		05-6160-10	08	96 057 716	05-5125-10	08	97 512 672		01	79 03 061 125	05-5611-10	-1
	05-5025-30	01		05-5213-11 05-5213-10	02	96 060 844	05-5018-05	01	97 512 685		01	79 03 065 165	05-5212-10	-
	05-5012-20	01		05-5018-50	02	96 060 846	05-5018-05	01		05-5219-10	01	79 03 073 024	05-5126-10	-
	05-6156-10	05		05-5018-05	01	96 060 848	05-5012-30	01	97 517 535		03	79 03 074 183	05-5642-10	1
	05-6533-10	09	96 004 520	05-5024-50	01	96 060 851	05-5018-05	01	97 518 936	05-5641-10	04	79 03 074 186	05-6533-10	-
	05-5012-10	01		05-5018-05	02	96 060 852	05-5018-05	01	97 518 936	05-5642-10	04	79 03 076 150	05-5611-10	1
	05-5023-01	01			01	96 060 853	05-5018-05	01	97 518 987	05-5642-10	01	79 03 076 169	05-6161-10	ı
	05-5023-01	01		05-5018-40	01	96 060 854	05-5018-05	01	97 518 987	05-5641-10	01	79 03 077 143	05-5126-10	1
	05-5023-01	01		05-5017-02	01	96 061 046	05-5024-05	01		05-5710-10	01	79 03 077 166	05-5126-10	ı
	05-5219-10	02		05-5455-10 05-5230-10	08	96 061 501	05-5126-10	21		05-5710-10	02	79 03 078 024	05-5641-10	П
	05-6145-10	15		05-5230-10	05	96 067 317	05-6161-10	02		05-5222-10	05	79 03 079 168	05-5126-10	П
	05-6145-10	13		05-5024-05	01	96 073 325	05-5212-10	03		05-5222-10	01		05-5454-10	1
	05-5024-50	01		05-5024-05	01	96 075 406	05-6145-10	05		05-5223-10	02	79 03 097 003	05-5127-10	ı
	05-5021-02	l ŏi l		05-5024-05	01	96 077 191	05-5212-10	01		05-5222-10	02		05-5127-10	1
	05-5021-02	l ŏi		05-6145-10		96 077 192	05-5212-10	01	97 534 988	05-6145-10	02		05-5125-10	1
	05-5024-30	01			05	96 081 489	05-5012-10	01		05-5125-10	07	79 03 097 391	05-5125-10	1
	05-6160-10	09		05-5126-10	07	96 085 588	05-5310-10	03		05-5125-10	01		05-5120-10	1
	05-5612-20	02		05-5126-10	17	96 085 598	05-5011-10	01		05-5213-13	13	79 03 097 395	05-5120-10	1
	05-6156-10	03		05-5126-10	17	96 085 890	05-5212-10	10		05-5213-12	11 }	79 03 097 450	05-5125-10	1
	05-5010-02	01		05-5011-10	01	96 086 987	05-5126-10	20		05-5127-10	09	79 03 097 507	05-5120-10	1
	05-5025-30	02		05-5455-10	06	96 087 447	05-5012-10	02		05-5310-10	01		05-5120-10	1
	05-5410-10	02		05-5018-40 05-5120-10	01	96 087 448	05-5012-10	01	ZC 9865 841 U	05-6533-10	13		05-5120-10	1
	05-5018-51	01		05-5212-10	01	96 090 780	05-5018-05	01		05-6533-10	12	79 03 097 523	05-5125-10	1
	05-5024-51	01			02	96 090 782	05-5018-05	01		05-5230-10	06		05-5120-10	П
	05-5017-01	01		05-6161-10	04	96 091 774	05-5310-10	03		05-5612-20	03	79 03 097 526	05-5120-10	П
	05-5126-10	12		05-5120-40 05-5120-40	01	96 095 069	05-5011-10	01		05-5612-10	03		05-5120-10	П
	05-5126-10	19		05-5120-40	02	96 095 089	05-5011-10	01		05-5611-10	05		05-5120-10	1
	05-5126-10	13		05-5120-40	01	96 102 571	05-5012-20	01		05-5612-10	03		05-5612-10	1
	05-5025-30	04			02	96 104 393	05-5012-20	01		05-5612-20	03		05-5611-10	1
	05-5025-30 05-6145-10	15		05-5120-40 05-5120-40	03	96 104 394	05-5012-30	01		05-5127-10	01	79 03 201 129	05-6160-10	
	05-6145-10	14		05-5120-40	03	96 104 455	05-5011-10	01		05-6160-10	07	79 03 201 139	05-6161-10	1
	05-5018-60	01			01	96 104 462	05-5011-10	01		05-5212-10	07	79 03 201 150	05-5611-10	İ
	05-5018 <b>-</b> 60	15		05-5012-20	01	96 104 474	05-5011-10	01		05-5212-10	11		05-5710-10	1
	05-5126-10 05-6156-10	06		05-5012-30	01	96 104 476	05-5011-10	01		05-5213-10	01		05-5710-10	1
	05-6156-10 0 <b>5-6156-10</b>	01	96 037 935	05-5455-10	01	96 107 249	05-5017-02	01		05-5213-11	01	79 03 232 017	05-5612-10	ı
	05-6156-10	01	96 032 340	05 5012 20	01		05-5012-30	01		05-5012-30	-01	79 03 232 017	05-5611-10	╪
	05-5611-10	07		05-5012-30	01	96 107 262	05-5012-30	01	6543 SR	05-5012-20	01	79 03 233 002	05-6161-10	1


235 PAGE 3	İ						Ai Ai	IDEX						
NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	Mines	·	·
79 030 880 80	05-5212-10	08	95 634 839 FLE	05-5222-10	06			1	HOMERO	FAGE	KEP	NUMERO	PAGE	RE
	05-5310-10	06	95 634 839 FXX	05-5222-10	06			1 1						+
79 05 521 015	05-6145-10	08	95 634 839 TR	05-5222-10	06			1			1 1			- 1
	05-6145-10	08	95 634 843 FCH	05-5222-10	04		1	1 1		Į.	1 1			- 1
	05-6145-10 05-6145-10	08	95 634 843 FLE	05-5222-10	04		I	1 1		1			1	- 1
	05-6145-10	08	95 634 843 FXX	05-5222-10	04		1			]	1 1		i	- 1
	05-6145-10	08	95 634 843 TR	05-5222-10	04		1	1 1		i	1 1		1	- 1
	05-6145-10	04	95 634 878 FCH	05-5230-10	02		1	1 1		ľ	1 1		1	- }
	05-5455-10	04	95 634 878 FLE	05-5230-10	02		l	1 !		i	1 1			
	05-5454-10	05	95 634 878 FXX	05-5230-10	02			1 1			1 1		ı	1
	05-5230-10	08	95 634 878 TR 95 634 879 FCH	05-5230-10	02		1			1			l	İ
79 20 037 454	05-6145-10	09	95 634 879 FLE	05-5230-10	04		1	1 1		I			Ì	1
79 20 072 498		06		05-5230-10	04		1	1 1		j	1 1			1
2 530 169 CH		04		05-5230-10	04					ſ	1		l	1
	05-5450-10	04		05-5454-10	01		ļ	1 1			1 1		ļ	
556 913 FXX		01		05-5454-10	ŏi					ļ	1 1			1
	05-5127-10	10	95 638 338 TL	05-5454-10	oi						1 1			1
5 495 163 CT		03	96 008 430 CH	05-5222-10	03				ì		1 1			1
	05-5450-10	03	96 008 430 LE	05-5222-10	03			1 1			1			
	05-5450-10	03	96 008 430 TR	05-5222-10	03			1 1			1			1
631 250 FCH	05-5450-10	02	96 008 430 XX	05-5222-10	03			1 1			1 1	İ		
	75-6533-10 75-6533-10	05	1											1
	75-6533-10 75-6533-10	05	1		1			1 1	i		1 1			1
5 631 250 TR		05			1 1			1 1				Į.		ŀ
5 631 254 CH 10	5-5218-10	02						1 1						
631 254 FLE C	5-5218-10	02						1				į		
631 254 FTR C	5-5218-10	02	ĺ					1	1		1 1	ł		1
631 254 FXX 0	5-5218-10	02				į.		1 1	ŀ		1 1			1
632 531 FCH 0	5-6533-10	06	ŀ		1			1 1			!!	1		I
632 531 FLE 0	5-6533-10	06	l		ı				1		1	ì		ľ
632 531 FXX 0	5-6533-10	06	j			l						İ		1
5 632 531 TR   0 632 532 FCH   0	5-6533-10	06	1			[			i		] ]	ľ		
632 532 FLE 0	5-6533-10 5-6533-10	06 06	1				- 1		[					1
632 532 FXX 0		06		1	- 1				ļ			i		1
632 532 TR 0		06				l			1			l l		1
33 967 FCH 0	5-6533-10	05	J	i	- 1			'	1		l			ı
633 967 FLE [ 0.	5-6533-10	05				!		1	1		' 1			1
633 967 FXX 🛭 O.	5-6533-10	05	ł	- 1	- 1	ľ	Ī	- 1	. [		- 1	1		ł
633 967 TR 0	5-6533-10	05	1	l	- 1	1	ļ	- 1	1	1		į		1
634 B29 FCH   0:	5-5222-10	03		j	1	i	ľ	ı	- 1		- 1			
634 829 FLE 0	5-5222-10	03	1	- 1		ł	ļ		- 1	j	i	1		i
634 829 FXX 05	5-5222-10	03	. 1	ſ	`	1	į	1	ŀ		1			!
634 829 TR   05 534 831 FCH   05	5-5222-10 5-5222-10	03	·	I	- 1		- 1	1	ŀ	•		ļ		l
634 831 FLE 05		07		I	1		İ	1	1	ı		1		l
	5-5222-10	07 07	j.	ł	- 1		ļ.	i		l	1			
634 831 TR   05		07		1	- 1	ľ	1		ł	J	I	- 1	l	1
34 839 FCH   05	E222 10	06		- 1		ŀ	;	1			I		1	ı







30/01/98 GB C04   30/06/98 1235 06 <b>1331</b> 10 PAGE 1	16 TZI 19 TRI 19 TZI GTI
14-9 9 9 9 9	1 79 03 201 175 01 DIAM 10X1,50-80 RP 6922 16 01
	2 91 595 041 01 12X175-65 RP 1803 32 01
5 12	3 79 03 201 645 02 10X125-70 RP 6922 96 01
	79 03 001 917 01 DIAM 10X1,25-80 RP 6918 93 01
	4 79 03 001 864 04 10X150-30 RP 6917 78 01
0-10	5 79 03 057 100 10 FLEXIBLE WASHER 10,4X21,3-0,8 RP 6962 11 01
	6 91 507 329 01 SUSPENS WASHER DIAM 12 RP 1841 05 01
5-/	7 79 03 053 392 02 PLAIN WASHER 8,5X16-1,5 RP 6947 78 01
	8 79 03 057 005 02 FLEXIBLE WASHER DIAM 8X14 RP 6962 13 01
1230 fox/8d 6.133.3	9 79 03 033 027 01 WASHER-NUT DIAM 10X1.50 RP 6936 30 01
	10 79 03 032 017 02 HEXAGONAL NUT HE 8X1,25 RP 6936 80 01
	SELF LOCKG NUT 79 03 034 018 01 10X150-10,5
	12 25 322 019 02 12X175-11,5-18
	13 79 03 033 007 02 DIAM 8X1,25 RP 6936 80 01
	14 79 03 232 018 04 HEXAGONAL NUT 10X150-8,3 01
E1331100	


30/01/98 GB C05 <b>†</b> 1235 06 <b>1331</b> 20 PAGE 1	30/06/98 ENGINE BRACKET - SECURING	GTI 16V	
10 5 5 S	5 2 11—6 13 4 12 13 13 13 13 14 12 14 12 14 13 13 13 13 13 13 13 13 13 13 13 13 13	1 79 03 201 052	
9 1 5	[11/93] D1331120	4 79 03 201 175 01 DIAM 10X1,50-80  5 79 03 057 100 08 10,4X21,3-0,8  FLEXIBLE WASHER  10 10,4X21,3-0,8  10 10 10,4X21,3-0,8  10 10,4X21,3-0,8  10 10 10,4X21,3-0,8  10 10 10,4X21,3-0,8  10 10 10,4X21,3-0,8  10 10 10,4X21,3-0,8  10 10 10,4X21,3-0,8  10 10 10,4X21,3-0,8  10 10 10,4X21,3-0,8  10 10 10,4X21,3-0,8  10 10 10,4X21,3-0,8  10 10 10,4X21,3-0,8  10 10 10 10 10 10 10 10 10 10 10 10 10 1	
777 7 <del>77</del> 7 8 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	, £1331200	9 79 03 033 027 04 WASHER-NUT DIAM 10X1,50 RP 6936 30 01 01 0 79 03 232 018 - 01 HEXAGONAL NUT 10X150-8,3 RP 6932 15 01	








30/01/98 GB C09 1 30/05/98 1235 06 <b>1730</b> 30 FUEL PIPING PAGE 1				GTI 16V
		6 7 8 9	95 603 300 95 637 268 95 499 104 96 995 009 RP 1577 63 95 655 310 96 995 008 95 633 801 95 594 178 97 1563 89 79 05 026 803	RUBBER HOSE 01 DIAM INT 7,5-190 01 DIAM INT 9-1070 01 DIAM INT 7-5000 CL 01 DIAM INT 7-1310 01 DIAM INT 7-1310 01 FUEL FEED PIPE DIAM EXT 10-1535 01 RETURN PIPE DIAM EXT 8 LON 1645 01 PULSATN BUFFER
	E1/30300			







0/01/98 GB C12 T 235 06 <b>1734</b> 10 AGE 1	FUEL PIPING - SECURING					16 TZI
			1	95 613 807	01	PIPE BRACKET
		15	2	91 517 316	01	PROTECT BRACKET
18	- <b>Q 3</b> 11 15		3	5 474 776	01	BUSHING
<b>⊕</b> —16	CONTROL OF		4	95 499 100	01	SUPPORT CLIP DIAM 30
1/			5	96 995 806 RP 6992 J5	01 01	SWIVEL CLIP 3 DIAM 11
16—@ //	15	15	6	79 03 079 006 RP 6995 J5		CLIP 2T 4,5-5,5
	15 19 13	, 	7	96 995 688 RP 1635 E5	02	SWIVEL CLIP 27 13
9	12		8	95 499 094	02	2T 11-13 ET 20-22
			9	95 499 172	01	2T 18-4
Ĺ	2 7		10	79 03 079 193	01	SUPPORT CLIP 2T 14-16
J 7-	- m 12		11	95 499 115	01	SWIVEL CLIP 4T 18-18-4-4
			12	95 598 490	01	PIPE BRACKET
8—⊕₩	5		13	26 140 239		ADJUST CLAMP
			14	SRV 000 016 RP 6981 36		DIAM 12 A 22 LARG 9
	03/93	E 1734 100	15	SRV 000 017 RP 6981 37		DIAM 16 A 27 LARG 9
			16	79 03 053 028 RP 6947 77	02	PLAIN WASHER 6X12-1,2
			17	79 03 053 508 RP 6946 28		12,5X24-1,5
			18	79 03 033 009 <b>RP 6934 27</b>		WASHER-NUT 6X1,00
		E1734100	19	95 637 241	01	FIXING NUT DIAM M 8X1.25


10/01/98 GB C <u>13 </u> 1235 06 <b>1734</b> 20 PAGE 1	FUEL PIPING - SECURING		19 TRI 19 TZI GTI
15 — 9 13 — 9 12 — 1 12 — 9	B 6 11 11 11 11 11 10 10 11 11 11 11 11 11		1 95 613 807 01 PIPE BRACKET 2 91 517 316 01 PROTECT BRACKET 3 5 474 776 01 BUSHING 4 79 03 079 007 01 CLIP 1T 14 5 95 499 172 01 SWIVEL CLIP 2T 18-4 6 79 03 079 193 01 SUPPORT CLIP 2T 14-16 7 95 499 115 01 SWIVEL CLIP 4T 18-18-4-4 8 95 598 490 01 PIPE BRACKET 9 26 140 239 02
11		į.	10 SRV 000 016 RP 6981 36 01 DIAM 12 A 22 LARG 9 11 SRV 000 017 RP 6981 37 01 12 79 03 053 028 RP 6962 99 01 13 79 03 053 508 RP 6962 89 01 PLAIN WASHER DIAM 6X14X1.4 14 79 03 053 508 RP 6946 28 01
	[11/93] D1734120	\$ <b>*</b>	15 25 260 019
	51734120		


30/01/98 GB C14 1 30/06/98	
1235 06 <b>1734</b> 30 FUEL PIPING - SECURING	GTI 16V
	1 95 613 807 01 PIPE BRACKET
12—14—15	2 95 584 926 01 LINE BRACKET UP TO O 4676
	96 086 350 01 SUPPORT BRACKET SINCE O 4677
13-9 19	3 5 474 776 01 BUSHING
10 77-9	4 79 03 079 007 01 CLIP 1T 14
2-/2	5 95 499 172 01 SWIVEL CLIP 2T 18-4
	6 79 03 079 193 01 SUPPORT CLIP 2T 14-16
5 0	95 499 115 01 SWIVEL CLIP 4T 18-18-4-4
	8 26 140 239 02
10	9 SRV 000 016 01 DIAM 12 A 22 LARG 9 RP 6981 36 01
	10 SRV 000 017 08 DIAM 16 A 27 LARG 9 RP 6981 37 01
[GZ/88] 6.173.18	CAPSCREW 11 79 03 201 463 01 RI 6X1,00-20 RP 6922 54 01
	12 79 03 201 129 01 DIAM 5X0,80-12 RP 6921 38 01
	13 79 03 053 028 02 PLAIN WASHER 6X12-1,2 RP 6947 77 01
	14 79 03 058 028 01 SPRING WASHER DIAM 6X14X1,4 RP 6962 99 01
	15 79 03 053 508 01 PLAIN WASHER 12,5X24-1,5
	15 25 260 019 01 HEXAGONAL NUT DIAM 6X1,00
·	95 637 241 01 FIXING NUT DIAM M 8X1,25
E1734300	







17/98 GB D14 1 30/06/98 15 06 1751 10 TANK FILLING DUCTS - PIPE	SALOON
17738 GB 514 \$	SALOON  1
E175	











17	235 06 <b>1754</b> 20 ANTIPOLUTION (PIPING)					UP TO O 5172
18 16 2 2 5 482 643 01 UP TO 0 5099 96 091 809 01 SINCE 0 5100 15 SINCE 0 5100 16 SINCE 0 5100 17 SINCE 0 5100 17 SINCE 0 5100 18 SINCE 0 5100 18 SINCE 0 5100 19 SINCE 0 5100 11 SINCE 0 5100	AGE 1		1	5 413 837		
17 18 16 17 18 18 16 19 24 22 19 3 3 5 5 8 7 15 10 11 11 11 11 11 11 11 11 11 11 11 11				96 091 806		
18 16 22 22 22 23 3 95 587 296 RP 1538 34 01 FIXING STRAP 01 TANK BRACKET 95 597 959 02 -ESTATE 95 640 583 01 -ESTATE 91 72 1 -E1754200 10 -E1754200 10 -ESTATE 91 72 -E1754200 10 -ESTATE 91 72 -E1754200 10 -ESTATE 91 72 -E1754200 10 -ESTATE 91 72 -E1754200 10 -ESTATE 91 72 -E1754200 10 -ESTATE 91 72 -ESTATE 9	25 10		2	5 482 643		
RP 1538 34 01 TANK BRACKET  95 597 959 02 -SALOON 95 640 583 02 -ESTATE  95 639 849 01 -6 72 RP 1502 33 01  6 96 035 888 RP 1628 KS 01 -16 72 95 640 315 RP 1626 23 01-5 ALOON 19 TRI -SALOON 19 TRI -SALOON 19 TRI -STATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -ESTATE 10 TANK PROTECTOR DIAM INT 80 EP 33  95 640 584 01 SUPPORT LUG -ESTATE  10 79 05 026 709 01 RUBBER HOSE DIAM 4,5X6 LON 4500 11 95 655 309 01 FILEL FEED PIPE DIAM 5 LON 5000	17 &	14	١	96 091 809	01	SINCE O 5100
12		19	3			
5 95 639 843		27 _4	4	95 597 959		
15 95 639 848 RP 1502 33 01 ABSORBER  8 96 035 888 RP 1628 K5 01 -16 TZI  95 640 315 RP 1626 23 01 DRAIN VALVE 95 640 315 RP 1626 23 01 DRAIN VALVE 96 003 087 RP 1628 F0 01 -ESTATE 19 TRI -ESTATE 19 TZI -GTI 16V  7 95 637 234 01 FILTER BRACKET 8 96 004 115 RP 1505 75 01 9 95 640 584 01 SUPPORT LUG -ESTATE 10 79 05 026 709 01 RUBBER HOSE DIAM 4.5X6 LON 4500 11 95 655 309 01 FUEL FEED PIPE DIAM 5 LON 5000	24			95 640 583	02	-ESTATE
6 96 035 888 RP 1628 K5 01 -16 TZI	5 22 6	<b>×</b> /	5			
RP 1626 23 01-SALOON 19 TRI -SALOON 19 TRI -SALOON 19 TRI -SALOON 19 TRI -SALOON 19 TRI -SALOON 19 TRI -SALOON 19 TRI -SALOON 19 TRI -SALOON 19 TRI -SALOON 19 TRI -SALOON 19 TRI -SALOON 19 TRI -STATE 19 TRI -ESTATE 19 TRI -ESTATE 19 TRI -GTI 16V  7 95 637 234 01 FILTER BRACKET  8 96 004 115 RP 1505 75 01 TANK PROTECTOR DIAM INT 80 EP 33 9 95 640 584 01 SUPPORT LUG -ESTATE 10 79 05 026 709 01 RUBBER HOSE DIAM 4.5X6 LON 4500 11 95 655 309 01 FUEL FEED PIPE DIAM 5 LON 5000			6			
RP 1628 F0 01 -ESTATE 19 TRI -ESTATE 19 TZI -GTI -GTI -GTI -GTI -GTI -GTI -GTI -GT	N 900 - 1 1 3 3 1	6 20				-SALOON 19 TRI
FILTER BRACKET   10   79 05 026 709   01   FUEL FEED PIPE DIAM 5 LON 5000   11   95 655 309   01   FUEL FEED PIPE DIAM 5 LON 5000   1   1   10   10   10   10   10	3 26					-ESTATE 19 TRI
8 96 004 115	[02/92]	E 1754200				-GTI
RP 1505 75 01  9 95 640 584 01 SUPPORT LUG -ESTATE  10 79 05 026 709 01 RUBBER HOSE DIAM 4,5X6 LON 4500  11 95 655 309 01 FUEL FEED PIPE DIAM 5 LON 5000			7	95 637 234	01	FILTER BRACKET
10 79 05 026 709 01 RUBBER HOSE DIAM 4,5X6 LON 4500			8			
11 95 655 309 01 FUEL FEED PIPE DIAM 5 LON 5000			9	95 640 584	01	
			10	79 05 026 709	01	RUBBER HOSE DIAM 4,5X6 LON 4500
RP 1573 31 [01]			11			

















30/01/98 GB D03		
3	1 95 637 164 01 SOUS TABLIER -LEFT HAND DRIVE UNDER BULKHEAD	
	95 593 211 O1 -RIGHT HAND DRIVE SOUS TABLIER	
3	2 95 612 082 01 SOUS PLANCHER UNDER FLOOR	
	3 95 562 756 01 RESERVOIR CARBURANT UNDER FUEL TANK	
	4 79 03 074 073 01 PLUG DIAM 13,5 RP 7518 21 01	
	5 79 03 077 134 04 CLIP DIAM 6,6 RP 6992 C6 01	
10	6 79 03 201 463 04 CAPSCREW RI 6X1,00-20 RP 6922 54 01	
6	7 79 03 015 124 02 CAGE SCREW 6X100-20 RP 6984 03 D1	
(03/ pil   01823110	8 79 03 061 122 04 RUBBER WASHER 6X25-5	
	9 79 03 053 031 04 PLAIN WASHER 6X18-1,2	
	10 79 03 033 009 07 WASHER-NUT 6X1,00 RP 6934 27 01	
	11 79 03 044 014 02 CAGED NUT 6x100-12-18 RP 6941 11 01	
	12 79 03 046 076 01 SPEED NUT 6X1.00 RP 6943 23 01	
E1823100		


0/01/98 GB D02   30/06/98   235 06 1832 10   EXHAUST FRONT ANTIPOLUTION   246E 1	16 TZI
AGE 1	1 96 075 060 01 PIPE ASS PSA K009
8   	2 96 036 827 01 OXYGEN PROBE DIAM 18 X 1,50 RP 1628 L4 01
	3 96 123 503 01 EXH TEMP PROBE LON FAISCEAU 1125 RP 1628 X5 01
10 5	4 91 537 797 01 EXHT PIPE BALL RP 1798 75 01
	5 91 509 516 02 PIPE RING DIAM 20 H 10
	6 91 509 174 02 SPRING REST CUP DIAM 6X21 E 5
	7 96 092 921 02 PIPE SPRING DIAM EXT 20,4 -33,5
	8 79 03 085 043 04 STRAP DIAM 100 RP 6980 30 01
6	9 96 118 504 01 17 4,8 PINC E0,5A3 UP TO O 5684
[-7-] E1832100	95 499 148 01 1 DIAM RP 96 118 504 01 SINCE O 5685
	10 96 097 060 02 PIPE FIX SCREW DIAM 6X1,00-50,1
	11 96 039 459 02 PIPE WASHER DIAM 9X21 E 2,4 RP 1712 28 01
	12 79 03 234 016 02 SELF LOCKG NUT 6X100 RP 6935 86 01
E1832100	










30/01/98 GB E03 1 30/06 1235 06 <b>2353</b> 10 WAT PAGE 2	98 ER PIPING - REGULATOR		16 TZI			
6 19 19 13 13	10 9 16 17 17 12 3 1 2 14	18	RP 8249 18 95 576 552	01 PASSAGE SEAL		
	E2353	1100				






701/98 GB E06 † 30/06/98 235 06 2353 30 WATER PIPING - REGULATOR	GTI 16V
AGE 1 9——23	1 96 020 348 RP 1338 03 01 THERMOSTAT
26	2 79 03 065 023 02 THERMOST GASKET DIAM INT 53,5 RP 1339 10 01 UP 70 0 5138
10 10	3 91 539 886 01 WATER OUTLET RP 1336 G1 01
6 4 27	4 96 044 482 01 WATER INTK TANK PLASTIQUE NOIR RP 1336 64 01
21 11 21	5 96 032 803 01 RING-SEAL 42,8X35,6 EP 3,6 RP 1339 79 01
20 12 9	6 96 029 479 01 DIAM INT :32-36-16 UP TO 0 5138
22	96 107 117 01 DIAM INT 32/32/14
9 0 24 3	7 96 015 307 01 WTR INLET HOSE DIAM INT 32
18 8	8 96 031 587 01 WATER PIPE METALLIQUE
17 13 14	9 96 016 145 01 DIAM INT 19,2
	10 96 016 146 01 DIAM 19,2X27,4
	11 96 008 097 01 2 WAY UNION DIAM 19,2X27 RP 1351 59 01
13	12 96 008 098 01 WTR OUTLET HOSE DIAM19,2X27ET20,7X29 RP 1351 61 01
10/93	13 95 637 161 01 WATER PIPE
	15 95 630 937 01 HTR WATER HOSE DIAM INT 20 ET 22
	16 95 637 120 01 WTR OUTLET HOSE DIAM UNT15,2 ET 17,2
	17 91 540 086 01 CASING UNION RP 1307 J7 01
	18 91 537 940 01 WTR OUTLET HOSE RP 1351 56 01
E2353300	






30/01/98 GB E10 T 1235 06 <b>2354</b> 30 PAGE 1	30/06/98 WATER PIPING - SECURING				GTI 16V
PAGE	5	1	96 021 838	01	HOSE SUPPORT
	ĭ , , , , , , , , , , , , , , , , , , ,	2	96 015 828		
		3	96 015 826	01	CONNECT BRACKET
7		4	96 031 590	01	SUPPORT LUG EP:2
	7 9	5	96 016 142	01	RUBBER GROMMET DIAM INT 20
"		6	91 595 320	02	HOSE SUPPORT
		7	SRV 000 018 RP 6981 38		METALLIC CLAMP DIAM 20 A 35 LARG 9
		8	SRV 000 016 RP 6981 36		ADJUST CLAMP DIAM 12 A 22 LARG 9
		9	79 03 083 005 RP 6981 81		METALLIC CLAMP DIAM 14,5
0		10	SRV 000 021 RP 6981 41		ADJUST COLLAR DIAM 20 A 60 LARG 9
3.	977/60 2- D2354M	11	SRV 000 019 RP 6981 39		METALLIC CLAMP DIAM 25 A 47 LARG 9
		12	79 03 009 245 RP 6913 93		SOCKET SCREW 7X100-25
		13	79 03 057 003 RP 6962 12		FLEXIBLE WASHER 7,4X14,2X0,8
	E2354300				
	£2J54300	<u>L</u>		1	i


30/01/98 GB E11	16 TZI
	1 95 495 038 01 RADIATOR NEW 22,6 DM2
16 17 I	2 96 009 035 01 AIR DEFLECTOR ASS
3	3 95 568 321 01 FILLER PLUG 1 BAR
	4 97 519 151 01 LEVEL DETECTOR RP 1306 47 01
12 18	5 97 517 535 01 WATER LEVEL BOX
15—	6 95 576 325 01 TEMPERAT SWITCH RP 1264 17 01 V E B E
10 6	7 95 602 673 01 DRAIN PIPE DIAM INT 8 UP TO 0 5286
	8 95 588 274 01 DRAIN SCREW
LARG	9 95 548 417 01 SEAL SUP VALEO (THERMIQ)
2	10 79 03 062 002 01 PLUG SEAL 22X30-2 RP 0164 56 01
12	11 95 568 325 01 DIAM INT 18
<u> </u>	12 95 592 530 03 DIAM 12 EXT 24
1 11 14	13 96 143 542 01 PLUG RP 1414 05 01 SINCE O 5287
05/93 E2355100	14 79 03 083 117 02 METALLIC CLAMP DIAM 12 01 01
	15 79 03 201 463 05 RI 6X1.00-20 RP 6922 54 01
	16 79 03 201 139 01 6X100-16 RP 6915 69 01
	17 79 03 058 028 01 SPRING WASHER DIAM 6X14X1.4
E2355100	/








30/01/98 GB E14 ↑ 1235 06 <b>2355</b> 20 PAGE 2	30/06/98 COOLING RADIATOR	19 TRI 19 TZI GTI
13 6 3 4	13 14 15 16 E2355200	17 79 03 201 463 RP 6922 54  18 79 03 201 139 RP 6915 69  19 79 03 058 028 RP 6962 99  20 79 03 044 020 RP 6941 93  01 CAGED NUT 6x100-14-12,4-6
l	£2355200	


35 06 <b>2355</b> 30	COOLING RADIATOR				GTI 16V
	COOLING RADIATOR	2 6 7 8 9 10 6 11	96 03 96 01 95 63 97 517 535 RP 13 95 608 918 RP 95 64 95 60 95 59 79 03 201 46 RP 69 79 03 058 02 RP 69	32 254 0 19 305 0 35 732 0 36 41 0 39 432 0 39 432 0 39 22 530 0 39 39 0 315 69 0	RADIATOR NEW AIR DEFLECTOR ASS TEMPERAT SWITCH ABS DIAM 22 -150 RADIATR BRACKET WATER LEVEL BOX DRAIN SCREW SEAL RUBBER GROMMET DIAM 12 EXT 24 CAPSCREW SRI 6X1,00-20 11 15 SPRING WASHER DIAM 6X14X1,4 11 11 CAGED NUT 6X100-14-12,4-6
















0/01/98 GB F09 1 30/06/98 235 06 <b>6410</b> 10 AIR CONDITIONING - COMPRESOR				16 TZI 19 TRI 19 TZI GTI	
AGE 1 24 2 6 6	1		01	COMPRESSOR SD709 4 VES UP 10 0 4739	
7+25+28 3 2 (100 %)			01 01	5 VOIES 2 FILS	
13		96 118 281 RP 6453 H6	01	5 VES SANDEN INT- SINCE O 5091 UP TO O 5347	
8 19 20 20 15 15 15 15 15 15 15 15 15 15 15 15 15		96 133 404 RP 6453 H6	01	5 VES SANDEN INT- SINCE O 5348	
1200 1200		95 659 531	1	WITHOUT CLUTCH SD 709	
13	2		01	5 VES ( 1 FIL ) UP TO 0 4739	
22-14	:			5 VES SINCE O 4740 UP TO O 1990	
23 [63/68] 19 E641010X		RP 6453 T7	01	5 VES 2 FILS SINCE O 5091 UP TO O 5347	
		6453 K9	:	5 VES SANDEN INT- SINCE O 5348	
	3	91 536 229 RP 5750 H2		ALTERNATOR BELT 4 VOIES LON 1245	
	4	95 634 991		CONDENSER CHAUSSON	
	5		H	RADT DEFLECTOR ANTI RECYCL	
	6	95 592 534	1 1	COWL BOX PANEL DRIER UNIT	
	7	95 633 186 RP 6455 R1	01/	RANCO	
		6455 R1	01	SANS PRESSOSTAT	
E6410100					


11200 00 0410 10 1	ING - COMPRESOR				16 TZI 19 TRI 19 TZI GTI
PAGE 2	24	В	95 496 899		DHYD PRSS SWTCH 4 VOIES MURAY
7+	25+26 3	9	95 633 188	01	U BOLT ASS
5	2 0000	10	91 511 640	01	COMPR PROTECTOR 2 DIAM 8,5
	27	11	95 592 530	04	RUBBER GROMMET DIAM 12 EXT 24
		12	95 601 818 RP 6457 RO		RING-SEAL DIAM 9,24 X12,8
	10 20	13	95 536 897		PULLEY HUB SACHET FIXAT UP TO 0 4739
21	19 21 15		95 651 000		FIXING SET SINCE O 4740
	14	14	91 001 054 RP <b>6453 54</b>		SUPPORT CUP
10		15	79 03 067 115 RP <b>6968 74</b>		PIN 10,6X12
6 22 7	19 21 19 19 19 19 19 19 19 19 19 19 19 19 19	16	79 03 001 623 NFP	01	CAPSCREW 8X125-30
/23		17	79 03 201 039 RP <b>6921 42</b>	04 01	8X125-55 UP TO O 4739
			79 03 201 040 RP 6921 20	04 01	8X125-60 SINCE O 4740
		18	79 03 201 463 RP 6922 54		RI 6X1,00-20
		19	79 03 057 005 RP 6962 13		FLEXIBLE WASHER DIAM 8X14
		20	79 03 053 487 RP 6949 27		PLAIN WASHER DIAM 8X20 EP 3,5
		21	96 995 857 RP 6936 80		WASHER-NUT HERI 8X1,25
	E6410100				







235 06 <b>6410</b> 20 AIR CONDITIONING - COMPRESOR	GTI 16V
AGE 2	8 95 633 188 01 U BOLT ASS
6+28+29	9 96 014 527 01 TENSION ROLLER LAR 23 ET 37,5
	10 91 511 640 01 2 DIAM 8,5 UP TO O 4738
2	91 541 722 01 2 DIAM 10.5 ENTR 104 SINCE O 4739
26	11 95 592 530 04 RUBBER GROMMET DIAM 12 EXT 24
	12 95 601 818 01 RING-SEAL DIAM 9,24 X12,8 RP 6457 R0 01
11 3 - 14	13 00 56 829 300
5 30 22 20 19	14 79 03 201 053
18-09	15 79 03 001 864 01 10X150-30 RP 6917 78 01
24 19 13	16 96 011 125 01 SCREW COLUMN DIAM 10X1,5 ET8X1,25 RP 5703 35 01
	17 79 03 201 463 03 CAPSCREW RI 6X1,00-20 RP 6922 54 01
25 8 653 28 14 22 18	18 79 03 057 100 04 FLEXIBLE WASHER 10.4X21,3-0.8 RP 6962 11 01
O3/96) E8410200	19 79 03 053 998 04 SCREW WASHER DIAM 22,2X10,2X3
	20 91 541 667 02 10X22-6 RP 6947 91 01
	21 79 03 053 046 01 DIAM 8X22-2,5 RP 6947 79 01
	22 79 03 232 018 05 10X150-8,3 RP 6932 15 01
E6410200	KP 0932 13  01


01/98 GB F04 1 30/06/98 35 06 <b>6410</b> 20 AIR CONDITIONING - COMPRESOR				GTI 16V	
23 06 04 10 20 AGE 3 27 6+28+22 4 4 25 8	- 00	24 25 26 27 28 29 30	RP 6932 38 79 03 033 009 RP 6934 27 79 03 044 074 RP 6941 92 95 651 000 6453 K8 6457 Y6 6457 X0	HEXAGONAL NUT 01 8X1,25-6,5 01 01 WASHER-NUT 6X1,00 01 03 CAGED NUT DIAM 6X100 01 FIXING SET	
	504 t020				











1 95 603 852 01 LEFT 2 95 603 852 01 LEFT 3 95 639 000 02 CONTROL MOTOR 4 95 583 715 NEP 96 118 615 01 RIGHT 11X129 EP 10 UP TO 0 5109 96 118 615 01 LEFT 111X129 EP 13 SINCE O 5110 WITH ADMESIVE SIDE 96 118 616 01 LEFT 111X129 EP 13 SINCE O 5110 WITH ADMESIVE SIDE 97 5 586 684 03 SPRING WASHER 2.6X5.5-0,8 7 79 03 232 016 02 HEXAGONAL NUT 6X100-5.5


























30/01/98 GB B01 ↑ 30/06/98 1235 PAGE 1 06 ENGINE ENVIRONME	NT-MISCELLANE.		EXHAUST FRONT ANTIPOLUTION  - 16 TZI  - 19 TRI 19 TZI GTI GTI 16V	1832-10 1832-20	1-D02 1-D01
ENGINE BRACKET - 16 TZI 19 TRI 19 TZI GTI - GTI 16V	1330-10 1330-20	1-C02 1-C03	- 19 TRI 19 TZI GTI GTI TGV  WATER PIPING - REGULATOR - 16 TZI - 19 TRI 19 TZI GTI - GTI 16V	2353-10 2353-20 2353-30	1-E02 1-E04 1-E06
ENGINE BRACKET - SECURING - 16 TZI 19 TRI 19 TZI GTI - GTI 16V	1331-10 1331-20	1-C04 1-C05	WATER PIPING - SECURING - 16 TZI	2354-10 2354-20	1-E08 1-E09
FUEL PIPING - 16 TZI	1730-10 1730-20	1-C07 1-C08	- 19 TRI 19 TZI GTI - GTI 16V	2354-30	1-E10
- 19 TRI 19 TZI GTI - GTI 16V	1730-20	1-C09	COOLING RADIATOR - 16 TZI - 19 TZI GTI	2355-10 2355-20	1-E11 1-E13
ELECTRIC PETROL PUMP - FILTER  - 16 TZI  - 19 TRI 19 TZI GTI GTI 16V	1731-10 1731-20	1-C10 1-C11	- GTI 16V FRONT BUMPER	2355-30	1-E15
FUEL PIPING - SECURING - 16 TZI	1734-10	1-C12	- 16 TZI 19 TRI 19 TZI GTI - GTI 16V	6171-10 6171-20	J-F15 J-F13
- 19 TRI 19 TZI GTI - GTI 16V	1734-20 1734-30	1-C13 1-C14	REAR BUMPER - 16 TZI 19 TRI 19 TZI GTI	6172-10 6172-20	1-F12 1-F11
FUEL TANK	1750-10	1-D15	- GTI 16V - ESTATE	6172-30	1-F10
TANK FILLING DUCTS - PIPE - SALOON - ESTATE	1751-10 1751-20	1-D14 1-D13	AIR CONDITIONING - COMPRESOR  - 16 TZI 19 TRI 19 TZI GTI  - GTI 16V	6410-10 6410-20	1-F09 1-F06
- SALOON ANTI POLUTION - FUEL TANK	1751-30	1-D12	AIR CONDITIONER - CIRCUIT	6411-10	1-F03
- SINCE O 5173 ANTIPOLUTION (PIPING)	1753-20	1-D11	AIR CONDITIONER - BLOWER UNIT	6412-10	1-F01
- UP TO O 5172 - SINCE O 5173	1754-20 1754-21	1-D10 1-D07	AIR CONDITIONER INLET CASING	6417-10	1-G01
EXHAUST - EXPANSION CHAMBER - SILENCER - 16 TZI - 19 TRI 19 TZI GTI GTI 16V	1822-10 1822-20	1-D05 1-D04	HOOD AIR CHANEL	6421-10	1-G02
EXHAUST - SCREENS	1823-10	1-D03	HEATER UNIT - VALEO (THERMIO)	6423-10	1-G03
			HEATER UNIT - RADIATOR	6425-10	1-G04

30/01/98 GB B02 ↑ 30/06/98 1235 PAGE 2 <b>06</b> ENGINE ENVIRONI	MENT-MISCELLANE.			
HEATING AND VENTILATION CONTROL	6431-10	1-G05		
EVAPORATOR - PRESSURE REDUCING VALVE - VALEO (THERMIQ)	6445-10	1-G07		
VENTILATION DUCT AND NOZZLE	6470-10	1-G08		
VENTILATION BOX AND DUCT	6482-10	1-G09		
AIR INLET BOXES	6486-10	1-G11		
	:			
				ı
		İ		
		i	1 , 1	í

GE 1							IN	DEX						
NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMBERO		
	06-1754-20	01	91 517 975	06-2353-20	14	95 499 102		01	95 577 637	06-1751-30		NUMERO	PAGE	RE
5 474 776	06-1734-20	03	91 518 122	06-2353-20	05	95 499 102	06-1730-20	01	95 579 762	06-1754-21	08	95 603 852		10
5 474 776	06-1734-10	03	91 519 122	06-2354-20	02	95 499 102		01	95 580 038	06-1832-20	14	95 603 853	06-6417-10	(
5 474 776	06-1734-30	03	91 521 582	06-1330-10	07	95 499 104	06-1730-10	04	95 581 409	06-6411-10	10	95 604 802	06-6411-10	- (
5 482 643	06-1754-20	02	91 521 582	06-1330-20	07	95 499 104	06-1730-20	04	95 581 846	06-6431-10	15	95 606 278	06-1750-10	(
22 470 009	06-2353-20	22	91 521 622	06-1330-10	03	95 499 104	06-1730-30	04	95 581 943	06-1754-20	09	95 608 790	06-1832-20	-10
23 019 029	06-1751-10	10	91 535 176	06-2353-20	04	95 499 115	06-1734-10	111			16	95 608 918	06-2355-30	10
23 019 029	06-1751-20	10	91 535 255	06-2353-20	06	95 499 115		07	95 583 715	06-6417-10	04	95 608 919	06-2355-30	-10
25 260 019		15	91 536 229	06-6410-10	03	95 499 115	06-1734-30		95 584 085	06-2353-20	24	95 609 652	06-6172-30	10
25 260 019	06-1734-30	16	91 537 797	06-1832-20	04	95 499 128		07	95 584 085	06-2353-10	19	95 610 329	06-6421-10	-14
25 260 019	06-6412-10	14	91 537 797	06-1832-10	04	95 499 128	06-6171-10	08	95 584 085	06-2353-30	27	95 610 428	06-1750-10	10
25 322 019	06-1331-10	12	91 537 823	06-1330-20	03		06-6172-10	04	95 584 926	06-1734-30	02	95 610 724	06-6425-10	-10
	06-1331-20	1 11	91 537 940	06-2353-30		95 499 148	06-1832-10	09	95 586 683	06-6417-10	05	95 610 901	06-2353-10	
	06-6470-10	06	91 538 806		18	95 499 172	06-1734-30	05	95 586 684	06-6417-10	06	95 610 901	06-2353-20	16
	06-1734-30	08	91 539 325	05-1731-20	01	95 499 172	06-1734-20	05	95 587 296	06-1754-20	03	95 611 589	06-2353-20	Т
	06-1734-10	13	91 539 325	06-1730-30	10	95 499 172	06-1734-10	09	95 587 296	06-1753-20	05	95 611 589	06-2353-10	
	06-1734-20	09	91 539 325	06-1730-20	09			10	95 588 272	06-2355-20	10	95 612 082	06-1823-10	1
26 140 239	06-2354-10	08	91 539 325	06-1730-10	10		06-6410-10	13	95 588 273	06-2355-20	11	95 612 501	06-2353-20	
	06-2354-20	06	91 539 869	06-2353-20	13	95 538 909	06-6445-10	06	95 588 274	06-2355-20	10	95 613 807	06-1734-30	13
	06-1754-20	25		06-2353-30	03	95 538 910	06-6412-10	04	95 588 274	06-2355-10	08	95 613 807	06-1734-20	
	06-1734-30			06-2353-30	17	95 548 417	06-2355-20	11		06-6486-10	01	95 613 807	06-1734-10	13
		19		06-2353-30	22	95 548 417	06-2355-10	09 1		06-2354-10	02	95 617 111	06-1730-20	15
	06-6423-10	05		06-1330-20	01	95 562 756	06-1823-10	03	95 592 530	06-2355-10	12	95 619 107		19
	06-1832-20	12		06-6410-20	20		06-6470-10	05		06-2355-20	13	95 619 108	06-6172-30	19
26 233 519	06-1751-20	04		06-6410-20	10		06-1751-20	03		06-2355-30	08	95 619 489	06-6172-30	0
	06-1754-21	13		06-1330-10	09		06-6172-10	03		06-6410-10	11	95 619 489	06-6423-10	0
	06-2353-20	17	91 595 041	06-1331-10	02		06-6172-20	02		06-6410-20	;;	95 619 720	06-6171-10	0
	06-6431-10	13	91 595 041	06-1331-20	03		06-6425-10	06		06-6410-10	06		06-6171-10	0
	06-6482-10	05	91 595 314	06-1331-20	01		06-2355-10	03		06-1823-10	01		06-6172-30	0
	06-6431-10	14		06-2354-30	06		06-2355-20	05	95 594 178	06-1730-20		95 619 723	06-6172-30	0
	06-1754-20	22	92 521 060	06-6445-10	05		06-2355-10	11		06-1730-20	08	95 619 724	06-6172-30	0
	06-6411-10	05	92 527 277	05-6445-10	04		06-2355-20	14	95 594 178	06-1730-10			06-1734-30	1
	06-6410-10	14	92 528 222	06-6172-30	34		06-6445-10	02	95 595 456	06-6486-10	09		06-6412-10	0
	06-1822-10	04	92 529 969	06-1832-20	09		06-6425-10	03		06-6421-10	02		06-6431-10	10
	06-1822-20	04	92 552 015	06-1750-10	02		06-6425-10	05		06-6486-10	01	95 630 058	06-1731-20	10
91 506 208	06-1734-20	67	93 501 958	06-2353-30	23		06-6486-10	03		06-6486-10			06-1731-10	0
	06-1331-10	06	93 501 958	06-2353-20	18		06-6423-10	06		06-6486-10	03		06-1731-10	10
91 507 329	06-1331-20	07	93 501 958	C6-2353-10	16		06-1754-21	09			02		06-1731-20	0
	06-1832-10	06	95 470 530	06-1731-20	02		06-6470-10	01		06-1754-20	04		06-1731-10	0
	06-1832-20	07	95 470 530	06-1731-10	02		06-1751-20	07		06-1734-10	12		06-1731-20	10
	06-1832-20	06	95 483 762	06-1822-20	08		06-1751-10	06		06-1734-20	08	95 630 064	06-1750-10	1
91 509 516   (	06-1832-10	05		06-1822-10	08		06-6482-10	04		06-6412-10	02		06-2355-20	0
	06-1832-20	08		06-2355-10	01		06-2355-10	06		06-2353-10	15		06-1751-10	1
	06-6410-10	10	95 495 038		01		06-2355-20	08		06-2353-20	16	95 630 937	06-2353-20	1 1
	06-6410-20	10	95 495 316	06-6425-10	01		06-1822-10	05	95 601 818	06-6410-20	12		06-2353-30	1
	06-2353-20	23	95 495 617	06-1822-10	07		06-1822-20	05	95 601 818   95 602 673	06-6410-10	12		06-6171-10	01
91 514 763 (	06-2353-20	03		06-1822-20	07		06-6425-10	02		06-2355-20	09	95 631 043	06-6171-20	0:
91 517 316 (	06-1734-20	02	95 496 899	06-6410-20	07		06-2353-30		95 602 673	06-2355-10	07		06-6171-10	0
91 517 316 (	06-1734-10	02		06-6410-10	08			26	95 603 241	16-2354-10	03	95 631 224	06-6470-10	0:
	06-1330-10	04		06-6486-10	05		06-2353-10	18	95 603 300	06-1730-10	02	95 631 245	06-6470-10	02
	06-1330-20	04		06-1734-10	08		06-2353-20	21	95 603 300 10	06-1730-30	02	95 631 246	06-6470-10	02
	06-1330-10	01		06-1734-10	04		06-6431-10	08 i	95 603 306 (6 95 603 489 (	6-1730-20	02		06-6470-10	62
							06-1751-20				04		06-1751-20	

235 AGE 2							IN	DEX	(					
NUMERO	PAGE		NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	7
95 631 848 95 631 879	06-6172-3		95 637 241	06-1734-10	19	96 007 142	06-1751-20	06	96 073 371	06-1330-20	02		06-2353-10	4
95 631 881	06-6431-1		95 637 241	06-1734-30	17	96 008 095	06-2353-30	19	96 073 371	06-1330-10	02	96 143 542	06-2353-10	
95 631 960	06-6172-3		95 637 241	06-1734-20	16	96 008 097	06-2353-30	11	96 075 060	06-1832-20	01	96 143 542	06-2355-20	
95 632 507	06-2353-2		95 637 268		03	96 008 098	06-2353-30	12	96 075 060	06-1832-10	01	96 156 487	06-2353-20	
95 632 688	06-2353-2		95 637 268	06-1730-20	03	96 009 035	06-2355-10	02	96 075 061	06-1832-20	l oi l	96 166 936	06-2353-10	
95 632 859	06-1751-1		95 637 268 95 638 252	06-1730-30	03	96 011 125	06-6410-20	16	96 076 185	06-1730-10	07	96 995 008	06-1730-30	
95 632 860	06-1751-1		95 638 738	06-1751-20	02	96 014 241	06-6410-20	03	96 076 236	06-1730-10	05	96 995 009	06-1730-30	
95 632 862	06-1751-3		95 638 738	06-6411-10	03	96 014 527	06-6410-20	09	96 077 418	06-1754-21	03	96 995 038	06-6431-10	
95 632 863	06-1751-3			06-6411-10	02	96 015 307	06-2353-30	07	96 079 051	06-6410-10	01	96 995 375	06-1754-20	
95 632 881	06-1751-3		95 639 000 95 639 807		03	96 015 826	06-2354-30	03	96 079 051	06-6410-20	01	96 995 449	06-1754-20	
95 633 061	06-1751-3		95 639 843	06-1731-20 06-1754-20	06	96 015 828	06-2354-30	02	96 086 350	06-1734-30	02	96 995 463	06-6171-10	
95 633 182	06-6411-1		95 640 315	00-1/54-20	05	96 015 909	06-2353-10	13	96 091 806	06-1754-20	01	96 995 463	06-6171-20	
95 633 183	06-6411-1		95 640 315	05-1754-20	06	96 016 142	06-2354-30	05	96 091 809	06-1754-20	02	96 995 463	06-6172-20	
95 633 184	06-6411-1		95 640 583	06-1754-20	01	96 016 145	06-2353-30	09	96 092 921	06-1832-10	07	96 995 463	06-6172-10	
95 633 185	06-6411-1		95 640 584	06-1754-20	04	96 016 146	06-2353-30	10	96 092 921	06-1832-20	08	96 995 688	06-1754-20	
95 633 186	06-6410-2			06-1750-10	09	96 019 305	06-2355-30	03	96 093 121	06-6172-20	04	96 995 688	06-1734-10	
95 633 186	06-6410-1		95 646 314	06-6431-10	01	96 019 777	06-6431-10	10	96 093 121	06-6172-10	05	96 995 727	06-1754-20	
95 633 188	06-6410-1		95 650 999	06-6410-20	02	96 020 348	06-2353-30	01	96 093 121	06-6171-20	07	96 995 727	06-1754-21	
95 633 188	06-6410-2		95 650 999	06-6410-10		96 021 838	06-2354-30	01	96 093 121	06-6171-10	10	96 995 728	06-1754-21	
95 633 801	06-1730-3			06-6410-10	02	96 029 054	06-6410-20	01	96 097 060	06-1832-20	14	96 995 756	06-1754-20	
95 633 801	06-1730-2			06-6410-20	13	96 029 479	06-2353-30	06	96 097 060	06-1832-10	10	96 995 806	06-1734-10	
95 633 801	06-1730-1			06-1754-20	111	96 029 572	06-1330-20	08		06-2353-10	10	96 995 857	06-1822-10	
95 633 843	06-6410-1			06-1730-20	06	96 029 572	06-1330-10	08	96 103 059	06-2353-20	07	96 995 857	06-1822-20	
95 633 901	06-2353-2			06-1730-20	06	96 029 582	06-1330-10	10	96 103 060	06-2353-20	08	96 995 857	06-6410-10	
95 634 071	06-1751-1			06-1730-10	06	96 029 582	06-1330-20	10		06-2353-10	07	97 517 535	06-2355-30	
95 634 257	06-6171-1		95 655 311	06-6410-20	02	96 031 587 96 031 590	06-2353-30	08		06-2353-10	14	97 517 535	06-2355-20	
95 634 349	06-1822-20			06-6410-10	02	96 032 254	06-2354-30	04	96 103 061	06-2353-20	15	97 517 535	06-2355-10	
95 634 349	06-1822-10	0 03		06-6172-30	02	96 032 254	06-2355-30	02	96 107 117	06-2353-30	06	97 519 151	06-2355-10	
95 634 351	06-1822-10	0 01		06-6410-10	02	96 033 565	06-2353-30	05		06-2353-10	06	97 519 151	06-2355-20	
95 634 351	06-1822-20	0   01		06-6410-20	02	96 033 565	06-1330-20	05	96 111 927	06-1753-20	02	97 520 833	06-6412-10	
95 634 724	06-2355-20	03		06-6410-20	01		06-1330-10	05	96 115 198		02	97 521 579	06-6445-10	
95 634 991	06-6410-10	04		06-6410-10	l öi l	96 035 819	06-1330-10 06-1330-20	06	96 118 281	06-6410-10	01	97 523 016	06-2353-10	
95 635 035	06-2354-10	0   01		06-1754-21	OB			06		06-6410-20	01	AM 644 69	06-6423-10	
95 635 035	06-2354-20	01		06-1754-21	04		06-1754-20	06		06-1832-10	09		06-6423-10	
95 635 188	06-6171-10			06-6171-10	01		06-1754-21	01		06-1832-20	11	GX 50 449 01A	06-6412-10	
95 635 238	06-2353-10	)   11		06-6171-10	01		06-1832-20	02		06-6417-10	04	SRV 000 015	06-2354-20	
95 635 475	06-1750-10	07		06-6171-10	01		06-1832-10 06-1731-10	02		06-6417-10	04	SRV 000 016	06-2354-30	
95 635 475	06-1751-30			06-6171-20	01		06-1731-10	01		06-6445-10	01		06-1754-21	
95 635 732	06-2355-30	04		06-6171-20	05			06		06-1832-20	03		06-1734-10	
95 635 951	06-6171-10	09		06-6172-10	01		06-1832-10 06-1832-20	11		06-1832-10	03	SRV 000 016	06-1734-20	
	06-6410-20			06-6172-10	01			15		06-1754-20	15		06-1734-30	
95 636 643	06-6410-20	05		06-6172-30	01		06-6410-10	01		06-1754-20	14		06-1734-30	
95 636 832	06-2355-30			06-6172-20	01		06-2353-30	04		06-2353-10	05	SRV 000 017	06-1734-20	
95 636 844	06-1751-30			06-1832-20	05		06-1832-20 06-1822-20	01		06-1753-20	01		06-1734-10	
	06-1751-10			06-1754-21	01		06-1822-20 06-1822-10	. 02		06-1753-20	04	SRV 000 017	06-2354-10	
	06-2353-30			06-1754-20	06			02		06-1754-21	05		06-2354-10	
	06-2353-30			06-1754-20	08		06-1822-20	02	96 129 429	06-1754-21	12	SRV 000 018	06-2354-20	
95 637 164				06-1753-20	06		06-2353-10 06-1754-21	01	96 133 404	06-6410-20	_01		06-2354-30	J
95 637 234	06-1754-20			05-6412-10	05		06-1754-21 06-1754-21	05 08		06-6410-10	01		06-2354-30	1
95 637 234			96 007 142		03		06-1754-21 ;			06-6172-30	32		06-2354-20	1
		1	54 551 174		0.5	90 073 364	00-2353-10	ie	96 139 633	06-6171-1A	30	SRV 000 019	06-2354-10	1

30/01/98 GB B06 T **INDEX** 1235 PAGE 3 PAGE PAGE NUMERO PAGE RFP NUMERO NUMERO NUMERO PAGE REP NUMERO DEP PAGE RFP 06-6410-20 79 03 079 006 79 03 201 463 SRV 000 020 06-2354-10 05 79 03 033 007 06-1331-10 79 03 053 492 06-1734-10 06-1734-10 06-1734-20 06-1734-30 06-1754-20 06-1751-20 06-1751-10 06-1734-30 06-1734-10 79 03 201 463 06-2355-30 79 03 201 463 06-2355-20 79 03 201 463 06-2355-20 79 03 201 463 06-6410-10 06-2354-20 06-2354-30 79 03 033 007 06-1331-20 79 03 033 009 06-1734-10 79 03 053 508 79 03 053 508 06-1734-20 06-1734-30 79 03 079 007 79 03 079 007 SRV 000 020 SRV 000 021 06-1751-30 06-1751-10 06-1751-30 06-6423-10 79 03 079 011 79 03 033 009 06-6410-20 79 03 053 508 06-1734-10 79 03 079 163 79 03 079 163 79 03 079 193 79 03 201 463 06-2355-10 79 03 201 463 06-1823-10 79 03 201 464 06-6486-10 79 03 033 009 06-6410-10 79 03 033 009 06-1823-10 79 03 053 536 79 03 053 998 06-6425-10 SRV 000 022 79 03 053 998 06-6410-20 79 03 056 003 06-6425-10 SRV 000 027 SRV 000 027 ZC 9619 892 U ZC 9866 208 U 00 56 829 300 1340 10 6453 K8 79 03 033 027 06-1331-20 79 03 033 027 06-1331-10 79 03 034 018 06-1331-10 06-6471-20 06-6410-20 79 03 056 008 79 03 056 008 06-6425-10 06-6412-10 79 03 079 193 79 03 079 193 79 03 201 645 06-1331-10 79 03 201 695 06-1331-20 79 03 201 695 06-1331-20 79 03 232 016 06-6417-10 79 03 079 216 06-1754-21 79 03 080 998 06-1822-10 79 03 080 998 06-1822-20 79 03 081 073 06-6412-10 06-2353-20 06-6410-20 06-6410-20 79 03 034 018 06-1331-20 79 03 041 038 06-6425-10 79 03 044 003 06-1751-30 79 03 057 003 06-2354-30 79 03 232 017 06-6410-20 79 03 232 017 06-1331-20 79 03 232 018 06-1331-20 79 03 057 003 06-2354-20 79 03 057 003 06-2354-10 6453 K9 79 03 057 005 06-6410-10 79 03 057 005 06-1331-20 79 03 057 005 06-1331-10 6453 K9 6453 P1 06-6410-10 06-6410-10 79 03 044 014 06-1753-20 79 03 044 014 06-1823-10 79 03 083 005 06-2354-30 79 03 083 117 06-2355-10 79 03 232 018 06-1331-10 79 03 232 018 06-6410-20 79 03 232 018 06-6410-20
79 03 234 016 06-1832-10
79 03 234 016 06-1832-10
79 03 234 016 06-1832-10
79 05 026 705 06-1754-21
79 05 026 709 06-1754-20
79 05 026 803 06-1730-20
79 05 026 803 06-1730-10
79 05 026 803 06-1730-10
79 05 026 801 06-1730-10
79 05 026 801 06-1730-10
79 05 026 881 06-1822-10
79 05 026 880 06-1822-10
79 05 026 880 06-1822-10
79 05 026 80 06-1822-10
79 05 026 80 06-1822-10
79 05 026 80 06-1822-10
79 05 026 80 06-1822-10
79 05 026 80 06-2353-20
94 01 336 650 06-2353-20
94 01 336 650 06-2353-20
95 577 524700 06-1750-10
95 619 540 CH 06-6431-10
95 619 540 FTR 06-6431-10 6453 P1 6455 R1 6455 R1 06-6410-20 06-6410-20 06-6410-10 70 03 044 014 06-1754-20 79 03 057 005 06-1331-10 79 03 057 013 06-2354-20 79 03 057 019 06-1331-20 79 03 057 100 06-1331-10 79 03 057 100 06-61331-10 79 03 058 027 06-1754-20 79 03 058 028 06-1754-20 79 03 058 028 06-1754-20 79 03 058 028 06-2355-10 79 03 058 028 06-2355-10 79 03 083 117 06-2355-20 79 03 083 250 06-1751-10 79 03 083 250 06-1751-20 79 03 044 020 06-2355-10 79 03 044 020 06-2355-30 6457 V1 06-6410-10 79 03 044 020 | 06-2355-20 79 03 044 020 06-2355-20 79 03 044 074 06-6410-10 79 03 046 047 06-6410-20 79 03 046 047 06-1750-10 79 03 046 048 06-6423-10 79 03 046 048 06-6412-10 79 03 046 053 06-1751-30 79 03 046 053 06-1751-20 79 03 046 053 06-1751-20 79 03 085 034 06-1751-20 79 03 085 043 06-1832-20 79 03 085 043 06-1832-10 06-6410-20 06-6411-10 6457 V1 6457 X0 6457 X0 6457 X0 06-6411-10 06-6410-20 06-6410-10 79 03 085 045 06-1751-20 79 03 085 045 06-1751-10 79 03 097 003 06-6431-10 79 03 058 028 06-2355-10
79 03 058 028 06-2355-30
79 03 058 028 06-1734-30
79 03 058 028 06-1734-20
79 03 058 028 06-1734-20
79 03 058 028 06-6411-10
79 03 061 066 06-2353-30
79 03 061 066 06-2353-10
79 03 061 130 06-1523-10
79 03 061 130 06-1751-20
79 03 061 130 06-1751-20
79 03 061 130 06-2353-20
79 03 062 002 06-2355-20
79 03 062 002 06-2355-20
79 03 065 023 06-2355-20
79 03 065 023 06-2353-30
79 03 065 023 06-2353-30
79 03 065 023 06-2353-30
79 03 065 023 06-2353-30
79 03 065 116 06-6411-10
79 03 065 117 06-6411-10
79 03 065 139 06-1751-30
79 03 067 115 06-6411-10
79 03 067 115 06-6411-10
79 03 067 115 06-6411-10
79 03 067 115 06-6411-10
79 03 067 115 06-6411-10
79 03 077 073 06-1823-10
79 03 077 073 06-1823-10
79 03 077 134 06-1823-10
79 03 079 006 06-1524-21 6457 YE 06-6411-10 04 05 06 06 01 01 02 02 02 02 02 01 01 01 02 02 02 03 03 03 03 03 03 6457 X7 6457 Y3 06-6411-10 06-6411-10 79 03 101 392 | 06-2354-20 79 03 101 602 | 06-1750-10 79 03 101 602 | 06-1751-30 843/13 10-8411-20 8437 YS 06-8410-10 8437 YS 06-8410-10 8921 81 06-6172-30 8921 81 06-6172-30 903 001 864 06-1331-10 903 001 864 06-1331-10 79 03 007 864 06-1331-10 79 03 007 864 06-1331-10 79 03 007 054 06-1754-20 79 03 007 136 06-1751-20 79 03 007 136 06-1751-20 79 03 007 136 06-1751-20 79 03 007 84 06-645-10 79 03 016 184 06-6445-10 79 03 016 184 06-6445-10 79 03 016 189 06-645-10 79 03 016 189 06-645-10 79 03 016 189 06-645-10 79 03 016 189 06-645-10 79 03 016 284 06-6486-10 06-6410-20 6457 Y6 79 03 046 070 06-6486-10 79 03 046 076 06-6421-10 79 03 046 076 06-6412-10 79 03 101 756 06-2354-20 79 03 101 756 06-2354-10 79 03 201 021 06-1754-20 79 03 046 076 06-6425-10 79 03 046 076 06-6172-30 79 03 046 076 06-6171-10 79 03 201 024 06-6425-10 79 03 201 034 06-1750-10 79 03 201 038 06-1822-10 79 03 046 076 06-6171-20 79 03 046 076 06-6171-20 79 03 046 076 06-1823-10 79 03 053 025 06-6412-10 79 03 201 038 06-1822-20 79 03 201 039 06-6410-10 79 03 201 040 06-6410-10 79 03 201 052 06-1331-20 79 03 053 028 06-1734-10 79 03 053 028 06-1734-30 79 03 053 028 06-1734-20 79 03 053 028 06-1734-20 79 03 053 031 (66-6425-10 95 619 540 FTR | 06-6431-10 95 619 540 FXX | 06-6431-10 95 619 540 LE | 06-6431-10 95 631 225 FLE | 06-6482-10 95 631 225 FTR | 06-6482-10 95 631 225 FTR | 06-6482-10 79 03 201 052 | 06-1331-20 79 03 201 053 | 06-6410-20 79 03 201 057 | 06-1331-20 79 03 201 073 | 06-1331-20 79 03 201 129 06-1734-30 79 03 201 139 06-6172-30 79 03 201 139 06-2355-20 95 631 225 FXX 106-6482-10 95 631 226 FLE 106-6482-10 95 631 226 FTX 106-6482-10 95 631 221 FCX 106-6482-10 95 631 251 FCL 106-6482-10 95 631 251 FLE 106-6482-10 95 631 251 FLE 106-6482-10 79 03 053 046 06-1750-10 79 03 053 324 06-2355-20 79 03 053 372 06-6171-20 79 03 201 139 06-2355-30 79 03 201 139 06-2355-10 79 03 201 140 06-1751-30 79 03 016 284 06-6486-10 79 03 018 284 06-0486-10 79 03 017 055 06-6431-10 79 03 027 316 06-1330-20 79 03 032 017 06-1331-10 79 03 053 372 06-6486-10 79 03 053 392 06-1331-10 79 03 053 392 06-1331-20 79 03 053 487 06-6410-10 79 03 201 141 06-6412-10 79 03 201 147 06-6472-10 79 03 201 175 06-1331-20 79 03 201 175 06-1331-10 79 03 201 325 06-1753-20 79 03 032 036 79 03 053 492 06-6172-30 79 03 201 463 06-1734-30 95 631 251 FXX | 06-6482-10

30/06/98

0/01/98 GB 235 AGE 4	50, 1						IN	IDEX						
NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REP	NUMERO	PAGE	REF
95 631 251 TR	06-6482-10	03		t										Т
95 631 880 CH		05			1 1		ļ	1 1			1		1	- 1
5 631 <b>880 FTR</b>		05					1	1 1						ı
5 631 880 FXX		05			1 1			1 1		1	1 1		i .	- 1
95 631 880 LE		05			1 1		]	1 1		1	1 1		1	ı
95 631 882 CH		03			1 1		ŀ			1	1 1		1	- 1
5 631 <b>882 FTR</b>		03			1 1		İ	1 1		1	1 1		ľ	- 1
631 882 FXX		03		ľ			l .			1	1 1		Į.	- 1
95 631 882 LE		03			1 1		ļ			I	1 1		1	1
5 634 775 FCH		03		ł	1 1		1	1 1		Į	1 1		1	i
5 634 775 FLE		03		i	1 1		1	1 1			I			1
5 634 775 FTL		03		!	1 1		1	1 1		i				
634 775 FXX		03			1 1		1	1 1		1	1 1			1
5 634 775 TR		03			1 1		1	1 1		ı	1 1			-
5 643 658 XX		05		1	1 1		1			}	1 1			1
5 643 658 YB		05		ļ	1 1		i	1 1			1 1		1	- 1
95 648 529 XX		03		1	1 1		i	1 1			1 1		1	- 1
95 648 533 XX		02		1				1 1		1	1 1		1	- 1
96 064 983 JX		03		1				1 1					1	- 1
6 064 983 XY		03		1				1 1			1 1		1	
96 064 984 JX		03						1 1			1 1		1	- 1
96 064 984 XY		03			1 1			1 1			1 1		1	
96 077 726 JX		04			- 1			1 1		1	i 1			- 1
96 077 726 XY	06-6171-20	04		1	1 1			1 1		1	i i		}	- 1
	ì	1 1		1	1 1			1 1		i	1 1		1	- 1
		1 1		ŀ	1 1		ļ	1 1		1	1 1			1
		1 1		1	1 1		ì				1 1			ŀ
		1 1		1	1 1		1	1 1			1 1			- 1
		1 1		1	1 1		1	1 1			1 1		Į	
		1 1			1 1		}	1 1		1			1	i
		1 1			1 1		1	1 1		1	1 1		1	- 1
	ł	1 1			1 1		1			1	1 1		1	1
	ŀ	1 1			1 1		1	1 1		i	1 1		i	1
	1	1 1			1 1		i	1 1			I I			- 1
	1	1 1		1	1 1		1			1	1 1		1	- 1
	l			1	1 1			1 1					1	Ţ
	ţ	1 1		ł	1 1		1	3 1			1 1			- 1
	l	1 1		Į.			1	1 1			1 1		ì	- 1
	1	1 1		1	1		1	1		1	1 1		1	- 1
		1 1		1			1	1 1		ļ	1 1		1	
	Į.	1 1		1	1		1	1 1		ļ	1		1	
	1	1		1			1	1		ì			Į.	ļ
		1 1		1			1	1 1		1	1 1			- 1
				l			1	1 }						
				1				1 1		1				1
	1			Ī				1 1			1 1		1	1
	Į.	1		1			1	1 1		1			1	1
		1		l .				1 1		1			1	
								1		1			<del> </del>	+-
	1	1 1		ŀ	1 1		1	!!!		į				
	1			!	-   -		1	1		1	1 '		1	}
	1	1 1		1	1 4		i			ŀ	1 1		1	

